K. A. Brewer R. J. Keehn K. L. Ahrenholtz

Multiplan Spreadsheets for Highway and Hydraulic Engineering Computations in County Engineering Offices

July 1987



lowa DOT Project HR-284 ERI Project 1844

ISU-ERI-Ames-88402

Final Report

Sponsored by the Iowa Department of Transportation, Highway Division, and the Iowa Highway Research Board.

Department of Civil and Construction Engineering, Civil Engineering Extension Program, and

Engineering Research Institute

College of Engineering

Iowa State University Ames, Iowa 50011

K. A. Brewer R. J. Keehn K. L. Ahrenholtz

Multiplan Spreadsheets for Highway and Hydraulic Engineering Computations in County Engineering Offices

July 1987

Iowa DOT Project HR-284

ERI Project 1844

ISU-ERI-Ames-88402

Final Report

Sponsored by the Iowa Department of Transportation, Highway Division, and the Iowa Highway Research Board.

Department of Civil and Construction Engineering, Civil Engineering Extension Program, and

Engineering Research Institute

College of Engineering

Iowa State University Ames, Iowa 50011

DISCLAIMERS

1. The opinions, findings, and conclusions expressed in this publication are those of the authors and not necessarily those of the Highway Division of the Iowa Department of Transportation.

2. The Iowa Department of Transportation, Iowa State University and the authors of any and all spreadsheet developed under this contract deny all responsibility and liability for any damages resulting from the use of such spreadsheets. All parties using these spreadsheets assume the responsibility to ensure that the spreadsheet program under which these spreadsheets are operating and the spreadsheets themselves are performing all calculations and relationships correctly. The authors of the spreadsheets retain copyright to the spreadsheets developed under this contract and by completion of this contract grant to the lowa Department of Transportation, and to all parties to whom the Iowa Department of Transportation releases copies of these spreadsheets, a license to use these spreadsheets and a site license to make copies for use within their respective organizations so as to properly conduct all lawful business. The authors of these spreadsheets also grant a license to use and a site license to make copies for the purpose of conducting education and research under its jurisdiction to Iowa State University.

i

Figure:	LIS: UF FIGURES Title:	Pade:
1	Ionut template for VERTCURV	30
• # •"}		
میلاد مید	Denematic of a vertical curve	
3	input form for example problem	يەت
4	Example problem template	33
5	Input template for HORIZCRV	41
6	Schematic of a horizontal circular curve	42
7	Input form for example problem	43
8	Example problem template	44
9	Input template for MAXTANG	52
10	Schematic of a horizontal circular curve	53
11	Input form for example problem	54
12	Example problem template	đđ
13	Input template for EARTHWKS	65
14	Input template for SUPERE	78
15	Schematic of a superelevated horizontal curve	79
16	Input form for example problem	80
17	Example problem template	81
18	Form of SIGNINV	96
19	Form of MAINTREC	102
20	Input template for Manning's equation - open channel geometric section	113
21	Description of input variables for channe cross-section	1 114
22	Cross section for the three example problems	114
23	Input form for DITCHFL	115

24	Example problem 1 template	117
25	Example problem 2 template	118
26	Example problem 3 template	119
27	Location of input data for RUNDFF	131
28	Input template with error message for RUNOFF	132
29	Hydrologic regions of Iowa	133
30	Input form for RUNOFF	134
31	RUNOFF completed	135
	Leftover input in RUNOFF	136
33	RUNOFF example - Bulletin 11, Region II	137
34	Input template for WSGEOM (part 1)	148
35	Description of input variables for channel cross-section	149
36	Input template for WSGEDM	150
37	Plane view for example problem	151
38	Input form for WSGEDM	152
39	Input form continuation for WSGEOM	153
40	Example problem template for first cross- section	154
41	Output for example problem (for first cross-section)	155
42	Output for example problem (for second cross-section)	155
43	Location of descriptive input data in CULVERT spreadsheet	170
44	Location of culvert input data in the CULVERT spreadsheet	171
45	Definition of the variables in site data for CULVERT	172
46	Display of informative record portion of CULVERT spreadsheet	173

47	Example problem site description	174
48	Results from the RUNOFF spreadsheet used in the CULVERT spreadsheet example	175
49	Input data form for use with CULVERT spreadsheet	176
50	Total output from the example problem for CULVERT spreadsheet	177
51	Data input for XSECT example problem	185
52	Example when inputting overbank data in XSECT	187
53	XSECT example cross-section	188
54	VAL program data input form	189
55	Output table from XSECT spreadsheet	190
56	VAL program output	191
57	Input of administrative data for WSNAT	207
58	Example cross-section	208
59	WSNAT spreadsheet format	209
60	WSNAT iteration illustration	211
61	Example output summary of WSNAT	212

. •

iv

LIST OF TABLES

Table:	Title:	Pager
1	Input for example problem	112
2	Values for LF	123
3	Limits on variables for RUNOFF	127
4	Various values for the energy coeffic- ient (according to finding of Chow, 1959)	142
5	Culvert types available	169
6	Various values for the energy coefficient (after Chow, 1959)	199

ACKNOWLEDGEMENTS

The project personnel wish to acknowledge the assistance in completing this research and development project of Mr. James Grove, Iowa Department of Transportation (formerly Assistant Story County Engineer); Mr. James Witt, Assistant Winnebago County Engineer; Mr. Darel Burns, Assistant Buena Vista County Engineer; Mr. Lloyd L. Kallsen, Woodbury County Engineer; Mr. Eldo Schornhorst, Shelby County Engineer; Mr. Richard King, Donohue; Mr. Brian Hunter, Assistant Pottawattamie County Engineer; Mr. Steve Holcomb, Grundy County Engineer; and the Office of Local Systems of the Iowa Department of Transportation. Various individuals associated with Microsoft Corporation, Lyon Computer Company, and Burroughs Computer assisted the research team.

TABLE OF CONTENTS

	Page
LIST OF FIGURES	ii
LIST OF TABLES	v
ACKNOWLEDGEMENTS	vi
Research and Development of Spreadsheets	
1. Introduction	1
1.1 Perceived Need	1
1.2 Identification of Initial Problem Set	2
1.3 Objectives of Project	3
2. Development of Spreadsheets	4
2.1 Selection of the Base Spreadsheet Program	4
2.2 Development Sources	4
2.3 Development Process	6
2.4 System Compatibility Difficulties	6
2.5 Computer to Computer Communication Solution	7
2.6 Spreadsheets Developed	8
2.7 Recommendations for Further Development and	ł
Refinements	12
2.8 Development Dissemination Workshops	13
2.9 Suggestions for Using Applications Manual	14

Applications Manual

1.	Multiplan Orientation					17
	1.1	Starting	With	MULTIPLAN	Initially	17

		Disk		18
	1.3	Saving a	Computation Result	20
	1.4	Contacts	for Froblems in Using MULTIPLAN	21
2.	Sprea	Jsheet Us	er Instructions	23
	2.1	Highway	Engineering Spreadsheets	24
		2.1.1	VERTCURV (calculating elevations on	
			a vertical curve)	25
		2.1.1.1.	Introduction	26
		2.1.1.2.	Using the Spreadsheet	26
		2.1.1.3.	Example Problem	28
		2.1.2	HORIZCRV (calculating the elements	
			for locating a horizontal curve	
	•		from known PI, known DELTA and	
			known degree of curvature)	36
		2.1.2.1.	Introduction	37
		2.1.2.2.	Using the Spreadsheet	38
		2.1.2.3.	Example Problem	39
•		2.1.3	MAXTANG (calculating the elements	
			for locating a horizontal curve	
			from a known PI, known DELTA and	
			maximum allowable tangent)	49
		2.1.3.1.	Introduction	50
		2.1.3.2.	Example Problem	50
		2.1.4	EARTHWKS (calculating mass diagram	
			ordinates from cut and fill of	
			cross sections)	60
		2141	Introduction	<u>~1</u>

viii

	2.1.4.2. Using the Spreadsheet	62
	2.1.4.3. Example Problem	63
	2.1.5 SUPERE (calculating field staking	
	instructions for a superelevated	
	transition to a horizontal curve)	71
	2.1.5.1. Introduction	72
	2.1.5.2. Using the spreadsheet	73
	2.1.5.3. Example porblem	75.
	2.1.6 SIGNINV (illustration of using a	
	spreadsheet for an sign inventory)	
	and MAINTREC (illustration of using	·
	a spreadsheet for a sign maintenance	
	record associated with an inventory)	88
	2.1.6.1. Introduction to SIGNINV	89
	2.1.6.2. Introduction to MAINTREC	90
	2.1.6.3. General introduction	91
	2.1.6.4. Using the spreadsheets	92
	2.1.6.5. SIGNINV	93
	2.1.6.6. MAINTREC	94
	2.1.6.7. Example problem	95
2.2	Hydraulic Engineering Spreadsheets	106
	2.2.1 DITCHFL (calculation of flow in a	
	regular shape section ditch based	
	on Manning's equation)	107
	2.2.1.1. Introduction	108
	2.2.1.2. Using the spreadsheet	108
	2.2.1.3. Example probelm	110

ix

2.2.2 RUNDFF (estimation of the water	
running off an Iowa watershed)	120
2.2.2.1. Introduction	121
2.2.2.2. Using the spreadsheet	121
2.2.2.3. Iowa Runoff Chart	123
2.2.2.4. Bulletin 11	124
2.2.2.5. Rounding the output	126
2.2.2.6. Example problem	128
2.2.3 WSGEOM (calculation of water depth	
along a trapezoidal channel)	138
2.2.3.1. Introduction	139
2.2.3.2. Using the spreadsheet	140
2.2.3.3. Example problem	145
2.2.3.4. References	146
2.2.4 CULVERT (determination of culvert	
size and type for roadway design)	156
2.2.4.1. Introduction	157
2.2.4.2. Using the spreadsheet	158
2.2.4.3. Example problem	166
2.2.5 XSECT (calculation of stage dis-	
charge curve across natural reach	
of stream)	179
2.2.5.1. Introduction	180
2.2.5.2. Using the spreadsheet	180
2.2.5.3. Example problem	184
2.2.6 WSNAT (calculation of water depth	
in natural cross sections)	104

x

· · ·

in natural cross sections)	196
2.2.6.1. Introduction	196
2.2.6.2. Using the spreadsheet	198
2.2.6.3. Reference	206
APPENDIX	
User Reference Instructions for KERMIT	213

xi

Research and Development of Spreadsheets

1. INTRODUCTION

1.1. Perceived Need

10

Beginning in 1983 the Civil Engineering Department, through its research and extension role, began providing assistance to the practicing engineering profession in making the transition from programmable calculator applications in engineering to the use of microcomputer applications. The early work with the engineering profession concentrated on hardware systems and commercially available software. Eventually the evaluation process identified a need to develop some specific software applications that civil engineering offices could make direct application with limited hands-on training. Educational research had identified the microcomputer spreadsheet as the coming general purpose programming environment for small scale computational work and routine accounting system work in a microcomputer environment. Computer industry reports also indicated that the general purpose programmable calculator was merging into the briefcase-sized microcomputer which typically has, among others, a spreadsheet program installed on an internal chip.

County engineering offices have made extensive use of programmable calculators in their engineering operations and have had some difficulty incorporating microcomputers into their operations. Combining the utility of a spreadsheet program with the need for county engineering offices to build a bridge between programmable calculator applications and microcomputers in the technological transition seemed the natural way to respond to the need. Applications in highway and hydraulic computations were selected as the specific application areas after conducting a survey of all 99 counties for priority preferences, should such a project be undertaken.

1.2. Identification of Initial Problem Set

The results of the preproject survey of all Iowa counties for priorities in application areas was presented to an advisory committee at the Hilton Inn in Des Moines on October 16, 1985. It was recommended that short-term priority should be given to developing spreadsheets for

* computing flow in ditches

* calculating vertical curve elevations

* determining bridge waterway opening

* determining the size of culverts in design and that long-term priority should be assigned to

* computing earthworks with an attempt to plot mass

diagram

* computing backwater analysis from drainage structures.

The advisory committee suggested a modular design on the spreadsheet programs with instructions on how to link these together.

1.3. Objective of the Project

The project had as a central objective development of Multiplan spreadsheets for a set of hydraulic and highway engineering computations of common interest to county engineers and to make these available to the various counties through a series of one-day workshops. This report is also one of the dissemination devices intended in the project objective.

2. DEVELOPMENT OF SPREADSHEETS

2.1. Selection of the Base Spreadsheet Program

Several surveys have been done regarding the variety of microcomputer hardware available in the 99 Iowa counties. Those surveys and the survey work of the project staff in the preproject stage convinced the project staff that the most appropriate spreadsheet program to use was Multiplan by Microsoft Corporation. This was based on the fact that it was available in versions that operated on the widest variety of hardware brands and models, and that, it was moderately priced for counties just beginning to acquire software. High cost software places a temptation to acquire pirate software or places an undue burden on the budget to make a trial installation. Multiplan seemed to offer the greatest potential to be low cost, widely implementable and flexible enough in structure to accomodate the range of computational needs. Subsequent research by the project staff identified that Multiplan had the most powerful equation capability which was critical in some of the hydraulic engineering spreadsheets.

2.2. Development Sources

Sources used as the basis of developing these spreadsheets were those that are either expected to be in most engineering offices desiring to use the particular spreadsheet or be readily available in a cooperating office. The highway engineering computation spreadsheets utilized equation relationships and table lookup materials from two primary sources:

- * <u>A Policy on Geometric Design of Highways and</u> <u>Streets, 1984</u>, American Association of State Highway and Transportation Officials.
- * <u>Route Location and Design</u>, <u>Fifth Edition</u>, Thomas F. Hickerson, McGraw-Hill, 1964.

The hydraulic engineering spreadsheets were based on a variety of sources. Among those were:

- * <u>Hydraulic Design of Highway Culverts</u>, Report FHWA-IP-85-15, Federal Highway Administration, September 1985.
- * VAL program on DOT T50, Iowa Department of Transportation.
- * <u>Open Channel Hydraulics</u>, Ven Te Chow, McGraw-Hill, Inc., New York, 1959, pp 27-28, 249-289.
- * "Federal Highway Administration Calculator Series for Hydraulics for the TI-55" equation was used for the critical depth for outlet control for culverts

Other sources include consultations with Mr. Phillip Thompson of the Federal Highway Administration in

Washington, DC, and staff personnel of the Iowa Department of Transportation Office of Preliminary Bridge Design.

NOTE: For culvert design and analysis, full flow was assumed in all cases with velocity defined by the ratio of flow to cross-sectional area of a culvert.

2.3. Development Process

The spreadsheets were developed by first laying out the computational process an engineer typically uses with a paper-pencil-calculator method. Then information was organized into an input screen which became a home base for the spreadsheet. The required computations were organized in a linear flow pattern since a spreadsheet calculates down and to the right unless special instructions are included. Then an output screen was organized into which the computational answers were placed. Testing with a known result example then followed. Modifications to the spreadsheet to enhance user understanding, add flexibility in use, and clarify results created several versions for some spreadsheets.

2.4. System Compatibility Difficulties

It was determined after testing thoroughly that

Multiplan versions were available for almost all microcomputers in use. One exception is the Hewlett-Packard 80 series. Furthermore, consultation with the Iowa State University Microcomputer Products Center and the Engineering Research Institute Electronics Laboratory resulted in a combined hardware-software method for transfering spreadsheets between MS-DOS based hardware and the various Apple microcomputers. One problem never fully resolved was the difficulty of interacting with the Burroughs B-20 series microcomputers.

2.5. Computer to Computer Communication Solution

With the assistance of the Iowa State University Computation Center Microcomputer Products Center it was determined that by connecting between two serial ports on any two computers for which a valid Multiplan program exists, it was possible to transmit spreadsheets between the two computers. A software communication program must exist in common for both computers. KERMIT is a public domain program to public agencies so that ISU can furnish a copy to a public agency (it can be purchased for \$40 by for profit organizations). KERMIT is available for a wide range of microcomputers. Using KERMIT permits the transmission of a Multiplan spreadsheet in the SYMBOLIC format code between, for example, IBM computers and APPLE

computers. Similarly, a county engineering office with a modem can use such a communication program to transmit a Multiplan spreadsheet to another office having a modem on a microcomputer. Interchange of spreadsheets can be made in this fashion between computer systems which cannot directly read each others disks.

2.6. Spreadsheets Developed

The following spreadsheets were developed to assist in highway engineering computations:

- A. HORIZCRV is a spreadsheet to permit entry of basic roadway design parameters for width of pavement and related facts, entry of PI station, the DELTA angle at the PI, and the design degree of curvature and the spreadsheet will compute the necessary information to locate the curve on the ground. It will also provide the typical design detail information to be included on a plan and profile sheet.
- B. VERTCURV is a spreadsheet to permit entry of vertical profile design information such as the VPI station and elevation, the grade entering and leaving the VPI and the distance between desired elevations along a vertical curve to compute vertical curve elevations. AASHTO criteria is used to determine the required length of vertical curve to be input. The spreadsheet will then calculate the vertical profile elevations.

A separate portion of the spreadsheet allows calculations at odd stations for driveways or similar points requiring profile elevations.

- C. SUPERE is a spreadsheet to utilize AASHTO criteria to define the centerline, left and right edge of pavement profile for a superelevation transition to a circular curve. The transition can be either tangent or spiral curve. If other than AASHTO criteria are desired, those can be specified.
- D. MAXTANG is a spreadsheet to permit an engineer to define a maximum length of tangent that can be accepted in a curve relocation as curve design control. The spreadsheet will then compute the curve which can be placed in the restricted geometry.
- E. EARTHWKS is a spreadsheet to permit entering cut and fill data from a series of cross-sections and then compute the mass diagram ordinates. It was hoped that this approach could lead to a quick method for entering limited cross section information resulting in a calculation of the cut and fill, definition of the mass diagram and a character plot of a mass diagram for preliminary adjustment of the design gradeline. This effort was not very successful.
- F. SIGNINV and MAINTREC are two spreadsheets included in this project report which were completed under a student special topic effort rather than this contract

effort. The student effort was coordinated with this project so that the inclusion of these two can be provided as an illustration of how a spreadsheet program can be used to perform an inventory and record keeping function. Some offices may not be interested in devoting the time needed to learn a microcomputer data base, which is better suited to this type task, and may find these spreadsheets a useful aid in developing other similar applications.

The following hydraulic engineering spreadsheets were developed:

- A. DITCHFL is a spreadsheet to compute flow in a regular section (trapezoid, V-bottom, rectangular, etc.) ditch from Manning's equation. The computation is often used for trapezoidal cross section roadside ditches and for lined channels were the depth of flow is not critical.
- B. RUNOFF is a spreadsheet developed to calculate the runoff flow from an Iowa watershed drainage area to yield a design flow for hydraulic structures. The hydrologic bases of this spreadsheet are the Iowa runoff chart and the current version of Bulletin 11. Bulletin 11 is being updated as of this report date. When the new version of Bulletin 11, upon which this spreadsheet was partially based, is issued, the spreadsheet can be updated to reflect any changes and a new spreadsheet revision issued.

- C. WSGEOM is a spreadsheet developed to calculate the water surface profile along a section of a trapezoidal channel. If the trapezoid is defined with a zero bottom width it becomes a V-bottom ditch. This is for use in estimating the backwater effects due to ponding by a culvert under the roadway at a downstream location.
- D. CULVERT is a spreadsheet developed to perform the necessary steps to size a culvert at a site. The program is less data intensive than the FHWA program and focuses on parameters with which county engineers are expected to be more familiar. The significant advantage of this spreadsheet over the FHWA program is that in the FHWA program all initial data must be reentered each time a single design trial revision is made. In the spreadsheet, only the design parameters the engineer wishes to change are modified to develop a new or alternate solution.
- E. XSECT is a spreadsheet developed to permit entry of elevations and distances across the natural reach of a stream to obtain the stage discharge curve. It was created and tested to conform to the Iowa Department of Transportation VAL program for the DOT T50. It provides a useful illustration of the degree to which computational activities can be made to reproduce a high level computer language program in a microcomputer spreadsheet.

F. WSNAT-1 and WSNAT-2 are two spreadsheets which compute the water surface profile for natural cross section channels much like WSGEOM does for a geometric cross section channel. Because of the complexity of the computation layout for the natural cross section channel, only three cross sections can be computed along the channel in WSNAT-1 (plus a data transfer cell area). If the channel under consideration requires more than three cross sections, then the Multiplan "external copy" function can transfer the transitional information to WSNAT-2 to continue computations for three more cross sections. If more cross sections are anticipated, the engineer can create multiple copies of WSNAT-2 under the names of WSNAT-3, WSNAT-4, etc., and continue using the "external copy" function to extend the computation as far as needed. The project staff did not expect most county engineering applications to require such analysis for an extensive distance due to the nature of most county projects.

2.7 <u>Recommendations for Further Developments and</u> <u>Refinements</u>

The project staff is of the professional opinion that coordination of interests in refinements and additional developments using Multiplan (or Lotus 1-2-3 for that

matter) can be conducted satisfactorily for the needs of public agencies in Iowa through the academic activities of the Center for Transportation and Public Works at Iowa State University. Many bright capable students in civil engineering are most interested in developing a program solution to a real world engineering need for laboratory credit. Modifications that might be pursued along this path include continued investigation of ways by which a mass diagram plot can be generated from a spreadsheet column of mass ordinates; methods of entering directly cross section elevations to compute cuts and fill areas for mass diagram computations; updating the hydrologic analysis curves and tables associated with revised reports; developing equipment analysis procedures on spreadsheets. Updates and revisions pursued in this manner should be relatively low cost (or no cost if done completely in an academic assignment context). for example, a student could prepare a horizontal curve calculation spreadsheet to make the necessary computations for spiraled circular curves.

2.8. Development Dissemination Workshops

Workshops were conducted on November 25, 1986, January 6, January 7, and February 13, 1987 to a total of 76 participants. At these workshops the participants were

briefed on the project. They were introduced to using Multiplan as a spreadsheet program. Participants were given detailed instruction in the use of one highway engineering spreadsheet and one hydraulic engineering spreadsheet. They were guided in a self-practice exercise in one additional spreadsheet in each of the highway and hydraulic engineering areas. Participants were briefly introduced to the other spreadsheets developed. All participants were given an opportunity to make suggestions and requests for changes or revisions in the spreadsheets. These suggestions and requests were used to modify the spreadsheets and documents between and after workshops.

Not all persons eligible to participate in the workshops chose to attend. It is suggested that the Civil Engineering Extension Program at Iowa State University conduct a workshop fall 1987 as a part of its regular program to enable additional interested persons to become familiar with the use of these spreadsheets.

2.9 Suggestions for Using Applications Manual

The project staff suggests that users of the Applications Manual (later portions of this report) make changes and modifications in it as needed for most efficient user operation. When a person first starts using these Multiplan spreadsheets it is anticipated that

an individual will follow the instructions closely. With a little familiarity with the spreadsheet, the developers anticipate that most of the user cues will be taken from the screen with only occasional reference to the Applications Manual. In that type of operation, it is suggested that copies be made of the sheets deemed critical to recalling steps needed to use the spreadsheet. This will produce a "quick reference guide" to each spreadsheet. Because it was not possible for the project staff to know what most people will need for quick reference, no such guide was developed in this contract. Again, if comments about the needs along this line are forwarded to the Center for Transportation and Public Works at the Civil & Construction Engineering Department of Iowa State University, some academic project may be able to develop a quick reference guide based on user input.

It has been assumed by the project staff that persons using this Applications Manual have worked with Multiplan enough to be aware of a few basic spreadsheet program operations. These include:

A. Entering a label as alphabetic information in a cell.
B. Entering a number (value) in a cell for computational purposes.

- C. Transfering a spreadsheet file from a disk into computer memory.
- D. Saving a spreadsheet from computer memory onto disk as

a file.

- E. Creating a window of row and column titles for maintaining headings while scrolling through a spreadsheet.
- F. Inserting rows or columns in a spreadsheet.
- G. Deleting rows or columns from a spreadsheet.
- H. Copying information from one row or column or cell to another.
- I. Using the options function to turn the recalculation and iteration functions off and on.
- J. Printing a spreadsheet out on a printer, setting the print ranges and print margins.
- K. Changing the format code of the spreadsheet from/to symbolic format and normal format.

Applications Manual

1. MULTIPLAN ORIENTATION

1.1. Starting With MULTIPLAN Initially

This project assumes some limited familiarity with Multiplan to be prepared to use these spreadsheets. The project staff considers it neither ethical nor prudent use of any computer software package to use it in an engineering design, analysis or management context without first gaining some minimal awareness of the capabilities and limitations of the software package. Microsoft Corporation has provided that for persons who are not interested in experimenting with work not of a critical nature in a learning mode. Microsoft documentation for Multiplan provides a very thorough and well written tutorial which it is suggested that the novice user complete before beginning use of these spreadsheets.

It is advisable to have several blank disks available which have been formatted in MS-DOS before beginning operations with these spreadsheets. The project staff suggests that two or more spare formatted empty disks are available at all times. That way if a person ever attempts to SAVE a spreadsheet file from computer memory

onto disk and the "disk full" message appears, the spreadsheet can be immediately re-SAVEd on one of the spare formatted disks. Note that when a disk full error is encountered in the process of saving a spreadsheet, there is no assurance that all the spreadsheet was saved, thus, the spreadsheet partially saved creating the "disk full" error should be DELETEd from the "full" disk. ALWAYS SAVE A SPREADSHEET TO TWO SEPARATE DISKS TO CREATE A WORKING COPY AND A BACKUP COPY.

When and if these spreadsheets begin to be used with any degree of frequency, all design and analysis spreadsheets should be dated when they are saved. This will enable the user to maintain only the most current version of solutions when "cleaning" files.

1.2. Transfering the SYMBOLIC Format Dissemination Disk

The disk issued as a portion of the dissemination documents has the spreadsheets stored on it in Symbolic Format. There several reasons for this. First, any MS-DOS computer or other computer which can read the disk will be able to read the symbolic format spreadsheet. Second, since a user will almost always want to load and save spreadsheets in a Normal Format for speed of operations, there is limited potential to erroneously use the dissemination disk as a regular working disk, thereby, altering or destroying the spreadsheets

furnished.

Because using spreadsheets in the symbolic format requires a long disk access time, it is suggested that the very first operation required is to transfer the spreadsheets furnished onto another formatted disk in normal format. The steps to follow are:

1. Prepare several formatted data disks.

2. Boot Multiplan on your computer.

- 3. Assuming a two floppy disk drive computer
 - configuration, insert the dissemination disk in Drive B (#2).
- 4. ALWAYS CLEAR THE SCREEN AND CLEAR COMPUTER MEMORY BY USING THE COMMAND Transfer ClearBEFORE LOADING A Symbolic File TO AVOID ADDING THE FILE TO UNWANTED MATERIAL. Enter the command Transfer, then Options, and "space" over to highlight Symbolic as the "mode". If desired, "tab" to the "setup" and identify the drive of the data disk. Press "Return" key.
- 5. Enter the command Transfer, then Load. When asked for a file name enter VERTCURV.MPS (preceding it by drive designation such as B: if the setup has not been specified for the data disk drive).
- 6. After several minutes of disk drive operation, the spreadsheet will come up on the screen of your computer. Now enter the command Transfer, then Options, and change the mode back to Normal.

- Remove the dissemination disk from the data disk drive and insert a new formatted data disk in the drive.
- 8. Enter the command Transfer, then Save. When asked for a file name, the program will retain the name VERTCURV.MPS. Change the name to VERTCURV deleting the extension MPS which stands for Multiplan Symbolic. That way there will be no confusion about the contents of the disk.
- 9. Repeat the steps 4 through 8 above until all the spreadsheet files on the dissemination disk have been converted from Symbolic mode to Normal mode and saved on a new data disk.
- 10. Repeat steps 4 through 8 above for the hydraulic engineering spreadsheets disk.

1.3, Saving a Computation Result

It is expected that when spreadsheets begin to be used commonly for engineering computations the program's power to recalculate alternative solutions immediately upon entering a changed design parameter will cause a person to test a wide range of alternatives. This suggests that a person may want to keep a large number of intermediate solutions before selecting the one to be incorporated in the final design. That suggests that a user should keep several formatted blank disks available upon which the

spreadsheet can be quickly saved before a parameter is changed to generate another solution. When a final solution is reached, a decision can be made about whether to obtain a printed record of any or all of the intermediate solutions for the project file and all but selected solutions can be erased from the data disk(s). Two things to bear in mind for efficient and effective use to spreadsheets. First, it is much faster to save a spreadsheet to disk in normal mode than it is to print a spreadsheet out on paper. Second, keeping unnecessary spreadsheets on disk file will quickly create a disk storage problem so that it is necessary to exercise some filing control.

1.4. Contacts for Problems in Using Multiplan

The Civil and Construction Engineering Department at Iowa State University maintains a commitment to service to the profession through the Extension and Research role. Persons in the Department who are knowledgable about Multiplan (and spreadsheets in general) include:

Charles S. Oulman (515) 294-6734

Edward J. Kannel (515) 294-6777

Kenneth A. Brewer (515) 294-6777

It is also appropriate to address an inquiry to the Manager, Center for Transportation and Public Works, Civil and Construction Engineering Department, Iowa State

University, Ames, Iowa 50011, to gain possible access to a knowledgable student advanced in the intracies of Multiplan. It would also be appropriate to inquire with either the Civil Engineering Extension Program Leader or the Technology Transfer Program Leader, Civil and Construction Engineering Department, Iowa State University, Ames, Iowa 50011.

2. SPREADSHEET USER INSTRUCTIONS
2.1 Highway Engineering Spreadsheets

2.1.1 VERTCURV

VERTCURV

2.1.1.1. Introduction

VERTCURV is a spreadsheet developed to layout a vertical curve. The spreadsheet will calculate the data required to layout a vertical curve onto plan and profile sheets.

The input data include: point of vertical intersection (V.P.I.), grade into and out of the V.P.I., elevation of the V.P.I., length of the vertical curve and station increment.

The output generated inlcudes:

curve data:

point of vertical curvature (V.P.C.), point of vertical tangency (V.P.T.), elevations of the V.P.C. and V.P.T., and location and elevation of the crest or sag;

curve layout data:

extended tangent elevation, curve profile elevation, curve gradient, and odd station curve elevations.

2.1.1.2. Using the spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred to the spreadsheet, and then input the data onto the spreadsheet. The data obtained from preliminary roadway layouts and design manuals can be transferred to an input form. Once this is done, the user can proceed to use the spreadsheet.

The first step is to load the file from the disk to Multiplan. These instructions assume the file has been stored on disk in Normal Format (transferred from Symbolic Format) under the name VERTCURV.MP. Once the spreadsheet has been loaded into your computer the initial screen will appear. Select the Options command and set Recalculation to OFF to enter the initial data. Input the informative data in rows 13-16 of the spreadsheet (see Figure 1). These data include the project number, project name, preparer, checker and dates the project was prepared and checked.

Once the informative data are input, the user then should input the point of vertical intersection (V.P.I.), elevation of the V.P.I., length of the vertical curve, and station increment into rows 23-28 in column 4 (see Figure 1). The point of vertical intersection, grades into and out of the V.P.I., and elevation of the V.P.I. can be obtained from the preliminary plans for the project (see Figure 2). The length of the vertical curve and station increment are determined using the AASHTO Green Book or the Iowa Department of Transportation Design Procedure Manual. The station increment is chosen

according to the policy used in the engineer's office. These are all the data that are required to be input on this spreadsheet. Before viewing the ouptut data generated by spreadsheet, remember to turn the Recalculation Mode back to the ON status by selecting the Options command again. (The spreadsheet will not produce any results unless the recalculation function is on.) After viewing the output data, the spreadsheet should be saved with a filename solely characteristic of the vertical curve and project for the purpose of reuse and editing. Do not save it under the same name that your blank master spreadsheet has in the disk directory or you will overwrite your master spreadsheet with one containing project data.

2.1.1.3. Example Problem

The following is an example application of the spreadsheet described above.

A farm-to-market paved county highway is to be designed and constructed in rural Iowa. From the preliminary plans, the point of vertical intersection is 107 + 78.50. The grades into and out of the V.P.I. are 6% and -4%, respectively. The elevation of the V.P.I. is 900 feet above sea level. The length of the vertical curve is set at 1000 feet by the engineer. The station increment is chosen as 100 feet. Several odd stations

were required to be found and are included in the output (see Figure 4).

The data are first entered on an input form. An example of the filled in input form is shown in Figure 3. Transferring information from the data entry form to the spreadsheet completed the process. Persons experienced with using the spreadsheet will probably bypass the data entry form and enter data directly into the spreadsheet.

The completed spreadsheet is shown in figure 4. The total output is contained on 3 pages, all of which are required when laying out the curve on the plan and

profile sheets.

Figure 1. Input Template for VERTCURV 2 З 4 1 VERTICAL CURVE COMPUTATIONS 2 3 ************* 4 5 ************ Multiplan Microcomputer Spreadsheets for County 6 -+ Hydraulic and Highway Engineering Computations 7 8 Copyright by Kent L. Ahrenholtz Version 1.0 G 1986 10 11 12 13 Project Number: 14 Project Name: 15 Prepared By: Date: 16 Checked By: Date: 17 18 19 20 CURVE INPUT DATA: 21 22 Point of vertical intersection, V.P.I. = 0.0000 stations 23 Grade into V.P.I., Gi = 0.00 percent 24 Grade out of V.P.I., G2 Grade out of V.P.I., G2 = 0.00 percent Elevation of the V.P.I. = 0.00 feet 25 26 Length of the vertical curve = 0.00 feet 27 28 Station increment 100 feet **.** 29 30 31 32 CURVE OUTPUT DATA: 3.3 34 Point of vertical curvature, V.P.C. = 35 0.0000 stations 36 Elevation of the, V.P.C. 0.00 feet = 37 Point of vertical 38 tangency, V.P.T. = 0.0000 stations 39 40 41 Location of the crest = #DIV/01 stations 42 Elevation of the crest ⇒ #VALUE! feet 43 44 Last even station 45 before the V.P.C. = 0.0000 stations 46 First even incremental 47 station beyond the V.P.C. = 1.0000 stations 48 49



****	VERTICAL CURVE INPL	JT WORKSHEET	••••••••••••••••••••••••••••••••••••••
Project N Project N Prepared	lumber: 87-1 lame: Story Co. E57 By: Ahrenholtz	Date: 03-19-8-	2
Checked B	IV: <u>Drewer</u>	Date: 03-20-8.	1
	UT DATA:		н і
	Point of Vertical Intersection, V.P.I.	- 107.7850	stations
н. Ал	Grade into the V.P.I., Gl	- +6	percent
	Grade out of the V.P.I., G2	-4	percent
	Elevation of the V.P.I.	= 900	feet
	Length of the Vertical Curve	- 1000	feet
	Station increment	= 100.00	feet
ale a suite de la companya de la co Companya de la companya de la company Companya de la companya de la company			

Figure 3. Input form for Example Problem

Figure 4. Example Problem Template

VERTICAL CURVE COMPUTATIONS

+ Hydraulic and Highway Engineering Computations + Copyright by Kest (Copyright by Kent L. Ahrenholtz + Version 1.0 +

┿╅╕┙╱┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍┍

Project Number: Project Name: Prepared By: Checked By:

Strain Strain

Date: Date:

11-

, içi tetlə Xəhifi

S. 1.2

a the Mary Mary

S. S. Sal

CURVE INPUT DATA:

Point of vertical intersection. V.P.I. = 107.7850 stations intersection, V.P.I. = 107.7000 Stations Grade into V.P.I., G1 = 6.00 percent Grade out of V.P.I., G2 = -4.00 percent Elevation of the V.P.I. = 900.00 feet Length of the vertical curve = 1000.00 feet Station increment = 100 feet

CURVE OUTPUT DATA:

1.1944月33

Point of vertical curvature, V.P.C. = 102.7850 stations Elevation of the, V.P.C. = 870.00 feet Point of vertical tangency, V.P.T. = 112.7850 stations = 108.7850 stations Location of the crest Elevation of the crest 888.00 feet . 🕿 Last even station before the V.P.C. = 102.0000 stations First even incremental station beyond the V.P.C. = 103.0000 stations

CURVE LAY	OUT DATA:		.		
	~~~~~~~	·	Extended	Curve	•
		Distance	Tangent	Profile	Curve
		from V.P.C.	Elevation	Elevation	Gradient
and the size she the she we	Station	(in feet)	(in feet)	(in feet):	(In percent)
VOC	102 7950	0.00	870.00	870.00	6.00
V.F.C.	102.7850	21 50	871 29	871.27	5.78
·	104.0000	121 50	977 29	876.55	4.78
	104.0000	221 50	993 29	880 84	3.78
	105.0000	221,50	003.23	894 12	2 78
	108.0000	JZ1.50	005.25	996 41	1 78
	107.0000	421.50	099.29	227 49	0.78
	108.0000	521.50	901.29	007.02	-0.70
	109.0000	701 50	707.27	007.90	-0.22
	110.0000	721.50	713.47	00/.20	-1.44
	111.0000	821.50	919129	000.00	-2.22
	112.0000	921.50	923.29	002.03	-3.22
V.P.1.	112.7850	1000.00	930.00	880.00	-4.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
· · ·	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
a de la companya de l La companya de la comp	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
1. A.	0.0000	0.00	0.00	0.00	0.00
5	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
•	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
·	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0,00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
	0.0000	0.00	0.00	0.00	0.00
· · · · · · · · · · · · · · · · · · ·					

34

)

# ODD STATIONS:

Description	Station	Curve Elevation (in feet)
FARM ENTRANCE   CMP	104.2500	877.72 885.94
INTERSECTION   FIELD ENTRANCE	110.5000 112.5000	886.53 881.10
		0.00
		0.00
		0.00
	· · ·	0.00
		0.00
	· · · · · · · · · · · · · · · · · · ·	0.00
		0.00

2.1.2 HORIZCRV

### HORIZCRV

### 2.1.2.1. Introduction

HORIZCRV is a spreadsheet to layout a horizontal circular curve. The spreadsheet will calculate the surveying data required to layout a horizontal curve onto plan sheets and in the field.

The input data include: total deflection angle (delta) at the point of intersection (P.I.), degree of curvature, point of intersection station, station increment along the circular curve, lane width of finished roadway cross section, and shoulder width (if area of pavement and area of shoulder along the curve is desired).

The output generated includes:

curve data:

radius of curvature, tangent distance, length of curve, external distance, long chord, and middle ordinate;

stationing information:

point of curvature (P.C.) and point of tangency
(P.T.);

curve layout data:

deflection angles, chord distances, offset distance both from curve to tangent and from tangent to curve, and areas of pavement and shoulder per station.

### 2.1.2.2. Using the spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred to the spreadsheet, and then input the data onto the spreadsheet. The data obtained from preliminary roadway layouts and design manuals can be transferred to an input form. Once this is done, the user can proceed to use the spreadsheet.

The first step is to load the file from the disk to Multiplan. The file is assumed in this discussion to be stored a disk in Normal Format under the name HORIZCRV.MP. Once the program is loaded, turn Recalculation OFF by selecting the Options command and then input the informative data in rows 13-16 (see Figure 5). These data inclue the project number, project name, preparer, checker, and dates the project was prepared and checked.

Once the informative data are input, the user should then input the total deflection angle, degree of curvature, point of intersection station, curve station increment, lane width and shoulder width (lane and shoulder width needed only if pavement areas desired) into rows 19-26 in column 4 (see Figure 5). The deflection angle and point of intersection can be obtained from the preliminary plans for the project (see

Figure 6). The degree of curvature, station increment, lane width and shoulder width are all determined by the engineer. For the degree of curvature, a maximum value can be obtained from the AASHTO Green Book or the Iowa Department of Transportation Design Procedures Manual using the design speed, but the value used should be chosen by a knowledgable engineer. The other values are chosen according to the policy used in the engineer's office. These data complete the input portion of the spreadsheet. Before the output data generated by the spreadsheet can be viewed the Recalculation function must be turned on by entering the Options command again. After viewing the the output data, the spreadsheet should be saved with a filename solely characteristic of the horizontal curve and the project for purposes of editing and reuse.

### 2.1.2.3. Example Problem

The following is an example application of the spreadsheet described above.

A farm-to-market paved county highway is to be designed and constructed in rural Iowa. From the preliminary plans, the total deflection angle is found to be 54 degrees 30 minutes and the station of the point of intersection is found to be 105 + 35.40. The engineer has set the degree of curvature at 3 degrees. The

station increment along the circular curve is chosen as 100 feet. Enginering criteria call for a lane width of 12 feet and a shoulder width of 10 feet for this particular roadway.

The data are first entered on an input form. An example of the completed input form is shown in Figure 7. Data entry to the spreadsheet is completed using this form.

The completed spreadsheet is shown in Figure 8. The total output of the spreadsheet is contained on 5 pages, but for layout of the curve onto plan sheets or layout in the field, only the second and third pages are needed.

#### Figure 5. Input Template for HORIZCRV

1 2 . З 57 HORIZONTAL CIRCULAR CURVE COMPUTATIONS ..... a 5 **<del>*</del>***** 6 -**i**-Multiplan Microcomputer Spreadsheets for County -**f**-7 Hydraulic and Highway Engineering Computations 4 بو.  $\mathcal{B}$ Copyright by Kent L. Ahrenholtz + - $\mathcal{D}$ 4 All Rights Reserved, 1986 10+ Version 2.0 11 12 13 Project Number: 14 Project Name : 15 Prepared By 5 Date: 16 Checked By . Date: 18 19 CURVE INPUT DATA: Deflection angle, Delta = 0.00 degrees 20 = 0.00 radians 21 Degree of curvature, D == 0.00 degrees 22 ***** 0.00 radians 23 Point of Intersection, PI= 0.0000 stations 24Station increment 100 feet 25 Lane width, L.W. = 0.00 feet 26Shoulder width, Sh.W. = 0.00 feet 27 28 29 CURVE OUTPUT DATA: 30 ~~ CURVE DATA: 31 32 Radius of curve, R = #DIV/0!feet Tangent distance, T 33 = #VALUE! feet 34 0.00 feet Length of curve, L *** 35 = #VALUE! feet External distance, E 36 Long chord, C = #VALUE! feet 37 Middle ordinate, M = #VALUE! feet 38 39 STATIONING INFORMATION: 40 Point of Curvature, PC = #VALUE! Point of Tangency, PT 41 = #VALUE! 42 43 44 CURVE LAYOUT DATA: و م ایند مرم دراد درم درم برس مرم درم درم درم درم درم درم در 45 ~~ = #VALUE! feet Chord length, c 46 Increment Angles, 0.00 degrees d = 47 -0.00 radians 48 d1= #VALUE! minutes 49 = #VALUE! degrees 50 = #VALUE! radians <u>117</u> 4 d2= #VALUE! minutes 52 = #VALUE! degrees 53 = #VALUE! radians = A



Project	Number: 87-1		
Project	Name: Story Co. ES7	and a second	
Prepared	By: Ahrenholtz	Date: 03-20-0	7
Checked	By: Brewer	Date: 03-22-8	1
			+
CURVE IN	PUT DATA: ~~~~~~ Deflection Angle, Delta	=_54.5	degrees
CURVE IN	PUT DATA: ~~~~~ Deflection Angle, Delta Degree of Curvature, D	= <u>   54,5</u> = <u>    3,0    </u>	degrees degrees
	PUT DATA: Deflection Angle, Delta Degree of Curvature, D Point of Intersection, PI	= <u>54,5</u> = <u>3,0</u> = <u>105.3540</u>	degrees degrees station
	PUT DATA: Deflection Angle, Delta Degree of Curvature, D Point of Intersection, PI Station Increment	= <u>54,5</u> = <u>3,0</u> = <u>105.3540</u> = <u>100.00</u>	degrees degrees station feet
	PUT DATA: Deflection Angle, Delta Degree of Curvature, D Point of Intersection, PI Station Increment Lane Width	= <u>54.5</u> = <u>3.0</u> = <u>105.3540</u> = <u>100.00</u> = <u>12.0</u>	degrees degrees station feet feet

Figure 7. Input form for Example Problem

#### Figure 8. Example Problem Template

 $\mathcal{D}$ 3 4 Ĵ. HORIZONTAL CIRCULAR CURVE COMPUTATIONS 2 ΖL. 5 1. + Multiplan Microcomputer Spreadsheets for County ••**?** -+-Hydraulic and Highway Engineering Computations Ω. ---Copyright by Kent L. Ahrenholtz \$D All Rights Reserved, 1986 10Version 2.0 11 12 13 Project Number: 87-1 14 Project Name : Story Co. E57 15 Prepared By :Ahrenholtz 16 Checked By :Brewer Date:03-19-87 Date:03-20-87 17 -----18 19 CURVE INPUT DATA: Deflection angle, Delta = 54.50 degrees 0.95 radians Degree of curvature, D  $\mathbb{Z}$  1 = 3.00 degrees = 0.05 radians 22 Point of Intersection, PI= 105.3540 stations 23 Station increment = 100 feet Lane width, L.W. = 12.00 feet 24 25 Shoulder width, Sh.W. = 10.00 feet 26 27 28 29 CURVE OUTPUT DATA: CURVE DATA: 31 = 1909.86 feet = 983.64 feet = 1816.67 feet Radius of curve, R 32 Tangent distance, T Length of curve, L 33 34 35 = 238.42 feet External distance, E = 1748.95 feet 36 Long chord, C 37 Middle ordinate, M = 211.96 feet 38 39 STATIONING INFORMATION: Point of Curvature, PC = 95.5176 40 41 Point of Tangency, PT = 113.6842 42 4.7 44 CURVE LAYOUT DATA: 45 - construction constructions and the construction · ±: • Chord length, c 99.99 feet 44 Increment Angles, d = 1.50 degrees 47 ...... 0.03 radians 48 d1= 43.42 minutes 4.90.72 degrees 30 0.01 radians ..... 51 61.58 minutes d2= 52 107 1.03 degrees 53 -----0.02 radians = a

44

5 7 8 9 10 CURVE LAYOUT DATA:(continued)

11 12 13 15

14

1	CURVE I	LAYOUT DAT	A: (cor	ntint	ied)						
$\gtrsim$		لوني کردو کردو کونو کردو کردو کردو کردو کردو کردو کردو 								1 - E	
Э											
<b>4</b> 1.				Defl	ecti	on An	glo	e			
5					from	PC					· · · ·
ć.			Τu	rnir	1g	Т	ur i	ning	•	Chord D	istance
7			F	light	•		l.e	ft		from PC	from PT
		Station	(deg	min	sec)	(de	g i	min .	sec)	(in	feet)
9	***************************************	nd dia 1940 ing dia dia dia dia 1940 ind 1940.	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~		ue ene ene ene ene ene :	** ** ** ** *** ***		*****		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	** ** ** ** ** ** ** *** ***
10	P.C.	95.5176	0	0	0	36	Q.	0	0	0.00	1748.95
11	· · ·	96.0000	0	43	25	35	9	16	35	48.24	1705.92
12		97.0000	2	13	25	35	7	46	35	148.20	1615.88
13		98.0000	3	43	25	35	6	16	35	248.07	1524.72
3.4		99.0000	5	13	25	30	4	46	35	347.76	1432.52
15		100,0000	6	43	25	35	3	16	35	447.21	1339.34
16		101.0000	8	13	20	30		46	30	346.36	1245.24
17		102.0000		43	20	30	<u>io</u>	16	30	645.13	1150.29
18		103.0000	11	13	25	34	8	46	30	/43.4/	1004.00
19		104.0000	12	43	20	34	-/	16	30	841.27	738.08 9/6 0/
20		105.0000	14	1	20	34		46	30	938.53 	860.96
21		106.0000	10	43	25	34	4	16	35	1035.13	/63.20
22		107.0000	1/	13	20	34	- A.	40	30 95	1131.03	660.02
11-13 (2)-13-13		108.0000	16	4.5	20			10		1220.14	390.33 Alto oc
2. 4. <del>3</del>	*	109.0000	20	15	. 20	33		40	30 05	1320.42	407.20
20		110.0000	21	43	25	55 A	185 . 	16	30 0E	1413.77	367.80
~~		112.0000	23	1.5	20	3a 07	C	4/5	30 ne	1006.20	140 07
21 		112.0000	24	43	20			10	30 95	1377.37	100.07
- <u></u>	EX 77	113.0000	20	15	20			40	30 0	1007.04	00.42
200 200	[" • 1 •	113.0042	4. / ()	10	0	- C - C	<u>~</u>		ŏ	1/40.20	0.00
200 121		0.0000	o o	0	ő		ă.		ő	0.00	0.00
30		0.0000	· 0	- ŏ	ŏ		ň	ă	- ñ	0.00	0.00
22		0.0000	ő	ŏ	ŏ		ă.	ă	ŏ	0.00	0.00
34		0.0000	ŏ	ŏ	ŏ		ă.	ŏ	ŏ	0.00	0.00
		0.0000	ŏ	ŏ	ŏ		õ.	· õ	ŏ	0.00	0.00
36		0.0000	ŏ	õ	ŏ		ŏ	ŏ	ŏ	0.00	0.00
37		0.0000	ŏ	õ	õ		õ	ō.	ŏ	0.00	0.00
Be		0.0000	· õ	õ	ŏ		õ	õ	õ	0.00	0.00
39		0.0000	õ	ō	ō		ō	.0	õ	0.00	0.00
40		0.0000	ö	ō	ō		ō:	ō.	ō	0.00	0.00
41		0.0000	Ö	Ō	ŏ		ō	Ô.	Ö	0.00	0.00
42		0.0000	ō	Ö	Ó.		ō	ō	0	0.00	0.00
43		0.0000	. O	0	Ó		ō -	Ó	Ó.	0.00	0.00
44	1	0.0000	0	0	0		ò	0	0	0.00	0.00
45		0.0000	0	0	Ó		0	0	0	0.00	0.00
46		0.0000	0	0	Ö		<b>0</b> '	0	0	0.00	0.00
47		0.0000	0	Õ	0		Ŏ.	0	0	0.00	0.00
48		0.0000	0	0	0		Ö	0	0	0.00	0.00
49		0.0000	0	Ô	0		0	0	Ò	0.00	0.00
SO		0.0000	0	0	Ó		Ŏ	0	0	0.00	0.00
51		0,0000	0	Ó	0		Q	Ó	Ö	Ŏ <b>,</b> 00	0.00
52		0,0000	O	0	0		Q	0	0	0.00	0.00
50		0,0000	· 0	0	0		$\odot$	ò	0	0.00	0.00
<u></u> 4		0.0000	. O	Q.	Ö	1.1	Q .	Q	0	. 0. 00	0.00

1 CURVE LAYOUT DATA: (continued)		н Н
S MEAGURET FROM	•	
The second		•
երով։ Գենելու հետում է Դենելու հետում է Դենելի հետում		
4 Curve to Tangent Tangent to	Curve	
6 Offset Ut	rset	<b>G</b>
7 Curve Distance langent langent Dis	rance	Curve
8 Station (in feet) Station Station (in	I TGGTJ Managana	STRULUN Manageren
	6 00	OF 5174
10 P.U. 95.5176 0.00 95.5176 7 95.3176	0.00	94 0001
	5 74	97 0015
12 97.0000 3.73 97.0007 7 97.0000	16 20	98 0070
	22 62	99 0194
14 97:0000 St.77 97:0077 1 100 0000	52.55 EQ 95	100 0422
$\frac{15}{1010000} = 1000000000000000000000000000000000000$	80.38	101.0782
$\frac{16}{17} \qquad 102.0000 \qquad 110.55 \qquad 101.0000 \qquad 101.0000 \qquad 102.0000 \qquad 102.000000 \qquad 102.00000 \qquad 102.0000 \qquad 102.000$	113.38	102.1314
$\frac{1}{10} \qquad 102.0000 \qquad 110.00 \qquad 102.0000 \qquad 102.000000 \qquad 102.00000 \qquad 102.0000 \qquad 102.0000$	152.48	103. 2060
	102.00	104 3070
$\frac{19}{105,000} = \frac{107,000}{107,1422} = \frac{107,000}{105,000}$	252.03	105.4404
	225 47	104 0961
21   103.000   133.00   107.4000   1   100.0000   107.4000   1   107.0000   107.4000   1   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.0000   107.00000   107.00000   107.00000   107.0000   107.0000   107	194 54	105 2194
	140 53	104. 3121
20 100.000 57 59 110 0924 1 109 0000	102 11	107 3800
	71 99	108 4277
22 110.0000 20.07 112.4777 1 110.0000 = 24 117 5017 1 111.0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5017 1 111 0000 = 24 117 5000 = 24 117 5000 = 24 117 5000 = 24 117 5000 = 24 117 50000 = 24 117 50000 = 24 117 50000 = 24 117 50000 = 24 117 50000000000000000000000000000000000	AA 54	109 4595
20   112.000   10.00   112.0017   111.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007   112.0007	76.04 76.04	110 4788
	12 40	111 <u>4890</u>
$20 \qquad 113.000 \qquad 1.10 \qquad 117.000 \qquad 110.000 \qquad 100.000 \qquad 10$	3.71	112,4931
	0 09	112 4938
	0.00	113.4842
91 0.0000 0.00 0.0000 1 110.100, 92 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
	0.00	0.0000
34 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
35 0.0000 0.00 0.0000 0.0000	0.00	0,0000
36 0.0000 0.00 0.0000 0.0000	0.00	0.0000
37 0.0000 0.00 0.0000 0.0000	0.00	0.0000
-32 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
39 0.0000 0.00 0.0000 0.0000	0.00	0.0000
40 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
41 0.0000 0.00 0.0000 1.00.0000	0.00	0.0000
42 0.0000 0.00 0.0000 1 0.0000	0.00	0,0000
43 0.0000 0.00 0.0000 0.0000	0.00	0.0000
44 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
45 0.0000 0.00 0.0000 0.0000	0.00	0.0000
46 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
47 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
48 0,0000 0.00 0.0000 ! 0.0000	0.00	0,0000
49 0.0000 0.00 0.0000 1 0.0000	0.00	0,0000
50 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
51 0.0000 0.00 0.0000 ( 0.0000	0.00	0.0000
52 0.0000 0.00 0.0000 0.0000	0.00	0.0000
53 0.0000 0.00 0.0000 1 0.0000	0.00	0.0000
54 0.0000 0.000 0.0000 0.0000 0	0.00	0,0000

	24	· · · · · · · · · · · · · · · · · · ·	26	27	28	29	30
1	· · ·	CURVE LAYOU	JT DATA: (contin	rued)			
2		eo para sa sa eo eo eo eo para e	ארא לא לא לא איז איז איז איז איז איז איז איז איז אי		. •		
Э							
4							
			Area of	Area of		1. S. 1.	
6			Favement	Shoulder			
7		Curve	ner Station	ner Station			
ŝ		Station	(in sa. ft.)	(in sn. ft.)			
Ş	والمالية وأواداون والوادر والادر	ין איז איני אור ער אורי איז אייר. איז ער ערי פוזי צווין ערי ערי ערי איז איז ערי ביו באי אוי					
10	P.C.	95 5174	0 - 00	0.00			
4 4		96 0000	1157 81	94 <b>4</b> 84			nija nija nija
4.79		97 0000	2400 00	2000 00	+ Pav	wampat Char	-+-
40		99 0000	2400.00	2000.00		na na Celha na na Celha na cui	• •
1 A		99.0000 99.0000	2400.00	2000.00	т. Да н. 1	- 0 - 1 - 11	
1 55			2400.00	2000.00		- 1001 04	
•⊷ دا. م ا		100.0000	2400.00	2000.00	т 	- 1721.00	т 
477		101.0000	2400.00	2000.00		- C 11.	
3.7 9 Ci		102.0000	2400.00	2000.00	+ r∡	= N - L.W.	+
10		103,0000	2400.00	2000.00	+•-	= 1897.86	+
17	· ·	104.0000	2400.00	2000.00	+		-+-
20		105.0000	2400.00	2000.00	+ Sho	ulder Char	• •
21		106.0000	2400.00	2000.00	+	*****	~ +
22		107.0000	2400.00	2000,00	+ Fir	st set:	+
23		108.0000	2400.00	2000,00	+ r1	=R +LW +Sh	₩ +
24		109.0000	2400.00	2000,00	+ .	= 1931.86	+
25		110,0000	2400.00	2000.00	+	· ·	+
26		111.0000	2400.00	2000.00	+ r2	= R + LW	+
$\mathbb{Z}7$		112.0000	2400.00	2000.00	+.	= 1921.86	+
28		113.0000	2400.00	2000.00	+	· ·	+
29	P.T.	. 113.6842	1642.19	1368.49	+ 11	+ r2	+-
30		0.0000	0.00	0.00	+	= 3853.72	. +
31		0.0000	0.00	0.00	+ r-1	- r2	+
32		0.0000	0.00	0.00	+	= 10.00	÷+-
33		0.0000	0.00	0.00	+		
34		0.0000	0.00	0.00	+ Ser	and set:	
35		0.0000	0.00	0.00	+ r1	= R - I.W	-+-
36		0.0000	0.00	0.00	+	= 1897.86	-4-
37		0.0000	0.00	0.00	+		
38		0.0000	0,00	0.00	+ 57		ial +
୍ଦ୍ରତ		0.0000	0.00	0.00	-	= 1887.84	
40		0.0000	0.00	0.00		- 1002.00	ملت
41		0.0000	0.00	0.00		+	
ለማ		0.0000	0.00	0.00	T I T	- 9705 79	т.
74		0.0000	0.00	0.00		- 3/00./Z	т 1.
-+		0.0000	0.00	0.00	- T T T	- 14	. <del>.</del>
AL 40		0.0000	0.00	0.00	*	= 10.00	
40		0.0000	0.00	0.00	*****	****	- <b>†</b> - <b>†</b> - <b>†</b> -
40		0.0000	0.00	0.00		· · ·	
41		0.0000	0.00	0.00		4 - A	
48		0.0000	0.00	0.00		1	
27.41		0.0000	0.00	0,00			
50		0.0000	0.00	0.00		1	
51		0,0000	0.00	0.00			
52		0.0000	0.00	0,00			
53							
雪点	- エロエム1 - ムのにと	Selen the im	42400 00	<u> 26022</u> 20			

## TANGENT TO CURVE COMPUTATIONS

		Arc
t/R	Theta	Length
~~~~~~	~~~~~	
0.00	0.00	0.00
0.03	1.45	48.25
0.08	4.45	148.39
0.13	/.4/	248.95
0.18	10.51	350.20
0.23	13.57	452.40
0.29	16.68	556.07
0.34	19.84	661.30
0.39	23.07	768.84
0.44	20.37	0/0.94
0.50	29.11	992.29
0.48	20.70	930.01
0.43	23.39	727 21
0.30	10 01	620 42
0.32	10.71	525 45
0.27	12 67	122.00
0.17	9.62	320 54
0.11	5.02	210 53
0.11	3 57	119.12
0.00	0.57	10 04
0.01	0.07	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00
0.00	0.00	0.00

48

2.1.3. MAXTANG

MAXTANG

2.1.3.1. Introduction

MAXTANG is a spreadsheet to calculate the elements of a horizontal curve for alignment purposes for which the field location has a restriction on the length of tangent that is permitted between the point of intersection and either the point of curvature or the point of tangency. The spreadsheet operates in the same form and manner as HORIZCRV. Thus, it is suggested that the user become familiar with HORIZCRV first. Then review Figures 9 through 12 on the following pages and proceed to use the spreadsheet in a manner similar to HORIZCRV.

2.1.3.2. Example Problem

The following is an example application of the spreadsheet MAXTANG.

A rural county highway in Iowa is to be paved. At one point in the route the existing aggregate surfaced roadway has a sharp curve that has several farmstead driveways near it. The engineer desires to keep these driveways on the tangent alignment rather than be located in the curved portion of the new paved highway. The engineer does, however, wish to use the longest and most

gentle curve possible at this location. Field survey measurements indicate that the longest permissible tangent length from the point of intersection to keep the closest farmstead driveway in the tangent is 650.00 feet. The total deflection angle, delta, was found to be 54 degrees and 30 minutes. The station of the point of intersection is 105 + 35.40. The stationing increment around the curve will be 100.00 feet. The paved roadway cross section will have 12.00 feet wide lanes and 10.00 feet wide shoulders.

The data may be entered on an input form. This example is shown in such a form in Figure 11. From this form the spreadsheet is then completed.

The completed spreadsheet for this example is shown in Figure 12. As before with HORIZCRV, the total output is contained in several pages but for layout of the curve in the field or on plans, only the first few pages are needed.

Figure 9. Input Template for MAXTANG

3 HORIZONTAL CIRCULAR CURVE COMPUTATIONS Given MAXIMUM TANGENT LENGTHS 2 а, 6 + Multiplan Microcomputer Spreadsheets for County 1. 7 4. Hydraulic and Highway Engineering Computations + Copyright by Kent L. Ahrenholtz \subseteq · . 9 All Rights Reserved, 1986 -fe Version 1.0 i O 11 12 13 Project Number: 14 Project Name : 15 Prepared By Date: 5 16 Checked By Date: e. 17 --- $1 \odot$ 19 CURVE INPUT DATA: Deflection angle, Delta = 0.00 degrees 0.00 radians **....** 21Tangent distance, T = - 0.00 feet 22 Point of Intersection, PI= 0.0000 stations 23 Station increment = 100 feet 24 Lane width, L:W. === 0,00 feet 20 Shoulder width, Sh.W. = 0.00 feet 26 27 28 CURVE OUTPUT DATA: 30 CURVE DATA: 31 Radius of curve, R 0.00 feet 32 Degree of curvature, D = #DIV/0! degrees 33 #VALUE! radians 34 Length of curve, L = #DIV/0! feet 0.00 feet 3.5 External distance, E 1.100 36 0.00 feet Long chord, C 25 37 Middle ordinate, M 0.00 feet ≡ 38 39 STATIONING INFORMATION: 4() Point of Curvature, PC = 0.0000 Foint of Tangency, PT 41 = #VALUE! 42 4.3 44 CURVE LAYOUT DATA: 45 Chord length, c = #VALUE! feet 46 Increment Angles, d = #VALUE! degrees 47 = #VALUE ! radians 자문 d1= #DIV/01 minutes 49 ≕ #VALUE! degrees 50 = #VALUE! radians ²²] d2= #VALUE! minutes 52 ≕. #VALUE! decrees 53 = #VALUE!radians 54



Figure 11. Input form for Example Problem

Project Number: 87-2			
Project Name: Story Co. E5	7		
Prepared By: Abrenholty		Date: 0	6-11-87
Checked By: Brewer		Date: O	6-11-87
		ستد ملک کناہ _{کری} _{ہیں، بیش بنان سند ملک <u>کی</u>}	
CURVE INPUT DATA:			
	· .		$\mu = -\frac{1}{2} \sum_{i=1}^{n} \frac{1}{2} \sum_{i=1}^{n}$
Deflection Angle, Delta	= 54	.5	degrees
Tangent Distance, T	- 65	0-00	feet
Point of Intersection, PI	= 105	.3540	stations
Station Increment	= /0	D .	feet
Lane Width	= 12		feet
Shoulder Width	=10	2	feet

Figure 12. Example Problem Template

1 1 2 HORIZONTAL CIRCULAR CURVE COMPUTATIONS Given MAXIMUM TANGENT LENGTHS 2 4 65 + Multiplan Microcomputer Spreadsheets for County 4 6 7 Hydraulic and Highway Engineering Computations ++- \odot Copyright by Kent L. Ahrenholtz + + \mathcal{D} + All Rights Reserved, 1986 + 10Version 1.0 11 12 13 Project Number: 87-2 14 Project Name : Story Co. E57 15 Prepared By Ahrenholtz Date: 06-11-87 Date: 06-11-87 16 Checked By **∶Br**ewer 17 ------18 19 CURVE INPUT DATA: Deflection angle, Delta = 54.50 degrees 0.95 radians Tangent distance, T 650.00 feet 21 -Point of Intersection, PI= 105.3540 stations 22 23 Station increment = 100 feet 24 12.00 feet Lane width, L.W. = Shoulder width, Sh.W. = 10.00 feet 25 26 27 28 CURVE OUTPUT DATA: 29 SO CURVE DATA: 31 Radius of curve, R = 1262.05 feet 32 Degree of curvature, D 227 4.54 degrees 23 0.08 radians 34 Length of curve, L = 1200.47 feet External distance, E Long chord, C 35 157.55 feet Ħ 36 = 1155.72 feet 37 Middle ordinate, M = 140.07 feet 38 39 STATIONING INFORMATION: 40 Point of Curvature, PC = 98.8540 41 Point of Tangency, PT = 110.8587 42 43 44 CURVE LAYOUT DATA: 4.55 Chord length, c 99.97 feet -46 Increment Angles, 2.27 degrees d = 47 0.04 radians 19.88 minutes 48 d1= 490.33 degrees -500.01 radians -----51 d2= 116.95 minutes 52 Ξ 1.95 degrees 53 0.03 radians 54

6 (*140038*		8): (r	9 4-4	10		12	13	14	15
ULIPOVE: Paratearanaa	Land Land Contraction and Cont	α	14, 11114	9.80 J.H. A					
			· ·	1				· .	
			Deti	ecti:	on Angl er	e			
		"Tu	enit		· v Tur	nina		Chord D:	istance
		E C	liaht		Le	eft.		from PC	from F
	Station	(deg	តារំរា	sec)	(deg	mіr	sec)	(in	feet)
	ه دید دید برم برم برم برم برم در در مرم در بالا به میتونش این بیدارس	••• ••• ••• ••• ••• ••• •••	, es es es es es	, , , , , , , , , , , , , , , , , , ,		,		00000000000000000000000000000000000000	1155 7
· • • 1.	. 98.8040	0	10	0 80	360 989	40	7	1/1 4.0	1142 7
		0 0	13		057		55	114 54	1052.4
	100.0000	ж Л.	-30 	17	00/ 055		42	214 24	940 9
:	102,0000	~* 7	ستدان. چې		000 050		73	212 79	867.9
	102.0000	, 0		40	332 750	 	20	A10 74	773
	103,0000 . 101 0000	4 4	40	50	040	10	20 Q	511 04	677.6
	105 0000	4 •	==-7	-01 -	240	2	=/	608.54	580.4
	104 0000	1.4	13	14	343	46	44	705.09	482.9
	107 0000	12	20	27	341	30	33	800.53	384.3
	108 0000	20	45	39	339	14	21	894.72	285.2
	109-0000	23	1	51	336	58	-9	987.50	185.7
	110.0000	25	19	ŝ	334	41	57	1078.73	85.8
e T	-110 8587		15	õ	337	45	Ö	1155.72	0.0
		Ő	.0	ŏ	Ö.	Ō	ŏ	0.00	0.0
	0.0000	ŏ	ŏ	õ	· Õ	ō	ō	0.00	0. 0
	0.0000	õ	ŏ	ŏ	õ	Ō	- õ	0.00	0.0
	0.0000	ŏ	õ	ō	ō	ō	õ	0.00	0.0
	0.0000	ō	Ō.	ō	ō	ò	· ō	0.00	0.0
	0.0000	Ö	ō	ō	ō	o	Ô	0.00	0.0
	0.0000	õ	õ	ō	ō	ō	Ō	0.00	0.0
	0.0000	Ô	ō	0	. 0	0	0	0.00	0.0
	0.0000	Ó.	Q	0	Ø	0	0	0,00	0.0
	0.0000	0	0	Ó	0	0	Ó	0.00	် O. (
·	0.0000	0	0	0	0	Ó	0	0.00	· • •
	0.0000	0	O	0	0	0	⇒ O	0.00	0.0
	0,0000	0	0	0	0	0	0	0,00	Ö. (
	0,0000	Õ	0	0	0	0	0	0.00	Ö.(
	0.0000	Ŏ	Q	0	0	С ()	0	0.00	0.0
	0.0000	Ō	0	0	O	. O	0	Ö.00	0.0
	0.0000	. O	. O	Ó	ö	Q .	• O	0.00	0.0
	0.0000	0	0	Ō	0	Ö	O	0.00	0.0
	0.0000	O_	0	Ð.	0	0	· 0	0.00	0. (
	0.0000	Ó	0	0	Q.	O .	0	0.00	0.0
	0,0000	<u>o</u>	0	Q	Ŏ	0	0	0.00	O .,(
	0.0000	Ó	, Õ	Ō	0	0	Ö	0.00	Q., (
	o, 0000	0	0	0	· 0	0	0	0.00	0.0
	0,0000	Q	0	<u>o</u>	0	ò	Ö	0.00	0.0
	0.0000	0	Q	<u>o</u>	- O	Ö	0	0.00	0.0
	0,0000	O	0	0	0	Ö	0	0.00	0.0
	0.0000	ò	0	Q	0	Q Q	0	0.00	0.(
	0.0000	Ŏ	Q	0	0	0	0	0.00	0.0
	0.0000	0	<u>o</u>	0	0	0	0 O	0.00	0. 0
	· 0,0000	Q.	Q _	0	0	0	0	0.00	Q.0
	0.0000	()	0	Q.	Ō	0	0	0.00	0.C

	16 17	18	19 20	21	22	23
ţ.	CURVE LAYOUT D	ATA: (conti	nued)			
2	ਆਫ਼ ਸਾਡ ਸਾਡ ਸਾਡ ਸਾਡ ਦਾ ਹਾ ਸੋਡੀ ਦੇ ਦੇ ਦੱਸਾਂ ਦੇ ਦੇ ਦੇ ਸਿੱਖ ਦਿੱਤਾ ਹੈ। ਸ	ropara.	10 - C	5.1.4	and the second second	
З			MEASURED	FROM	, , , , , , , , , , , , , , , , , , ,	
4		Curve to	Tangent	Tangent	to Curve	
5		لي ي ي ي ي ي ي ي ي ي ي ي ي ي ي ي ي ي ي	กล ที่ไร กละคน สี่ได้ กมะกลี่ ค่อง	و وہ دے وہ وہ دے وہ دہ ہ		an a
6		Offset			Offset	
7	Curve	Distance	Tangent	Tangent	Distance	Curve
\otimes	Station	(in feet)	Station	Station	(in feet)	Station
\sim	en pa pa pa pa pa pa pa pa ca ta ta ta ta ta ta ta ca pa	er na na na na na na na na na ha na.	en pa pa pal na pa pa pa pa pa pa pa pa pa T	و حال حال خراد حال خالو واس حال حال	يه ينة دوندويه بي ده وه ينه ده د	****
10	F.C. 98.8540	0.00	98.8540 !	98.8540	0.00	98.8540
11	99.0000	0.08	92,5836	99.0000	0.08	A 99.0000
12	100,0000	5.20	93.8172 :	100.0000	5,21	100.0016
13	101.0000	18.27	95.0068 !	101.0000	18.38	101.0105
14	102,0000	39.31	96.1581 F	102.0000	39.84	102.0335
15	103.0000	68.41	97.2765	103.0000	70.04	103.0784
16	104.0000	105.66	98.3667 l	104.0000	109.68	104.1545
17	105,0000	151.18	99.4332 ⁻ 1	105.0000	159.76	105.2732
18	106.0000	94.11	100.4798	106.0000	143.98	104.7714
19	107,0000	59.22	101.5104	107.0000	97.08	105.8763
20	108.0000	32.45	102.5284	108.0000	60.29	106.9421
21	109.0000	13.70	103.5373 (109.0000	32.69	107.9798
22	110.0000	2,92	104.5404	110.0000	13.69	108.9980
23	P.T. 110.8587	0.00	105.3994	111.0000	2.89	110,0041
24	0.0000	0.00	0,0000	111.8540	0.00	110,8587
25	0.0000	0,00	0.0000 !	0.0000	0.00	0.0000
26	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
27	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
28	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
22	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
30	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
31	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
32	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
33	0.0000	0.00	0.0000 !	0.0000	0.00	0.0000
34	0,0000	0.00	0.0000 !	0.0000	0.00	0.0000
35	0,0000	0.00	0.0000 1	0.0000	0.00	0.0000
36	0.0000	0.00	0.0000	0.0000	0.00	0.0000
37	0.0000	0.00	0.0000	0.0000	0.00	0.0000
38	0.0000	0.00	0.0000	0.0000	0.00	0.0000
39	0.0000	0.00	0.0000	0.0000	0.00	0.0000
40	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
41	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
42	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
43	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
44	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
45	0.000	0.00	0.0000 !	0.0000	0.00	0.0000
46	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
47	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
48	0.0000	0.00	0.0000 1	0.0000	0.00	0,0000
4 🤉	0.0000	0.00	0.0000 1	0.0000	0.00	0.0000
50	0.0000	0.00	0.0000 ;	0.0000	0.00	0.0000
51	0,0000	0.00	0.0000	0.0000	0.00	0.0000
52	0.0000	0.00	0.0000	0,0000	0.00	0.0000
53	0.0000	0,00	0.0000 1	0.0000	0.00	0.0000
54	0.0000	0.00	0.0000 }	0.0000	0.00	0.0000

	24	25	26	27	28 29 30	Э
1		CHRVE LAYD	UT BATA: (conti	nued)		
Ő		~~~~~	re ra ra ra ra ra			
. <i>Q</i>						
84). 637		in the second second		A.m		
਼			mrea or	Mrea ur		
0			Favement	Snoulder	· · · · ·	
/		Curve	per station	per Station		
8	and the second	Station	(in sq. ft.)	(in sq. ft.)	A second s	
Σ	*****	\$	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~			
10	P.C.	98.8540	0.00	0.00		
11	· · · · ·	99,0000	350.40	292.00	·┿·╈·╈·╈·╈·╈·╈·╈·╋·╋·╋·╋·╊·╋·╋·╋·╋·	÷
12	· · · · ·	100.0000	2400.00	2000.00	+ Pavement Char.	÷
13		101.0000	2400.00	2000.00	+ management	ł
14		102.0000	2400.00	2000.00	$+r_1 = R + L.W.$	۲
15		103.0000	2400.00	2000.00	+ = 1274.05	۲
16	•	104.0000	2400.00	2000.00	+	+
17		105.0000	2400-00	2000-00	$+ r^2 = R - L_2 W_2$	+
4 👄	· · · ·	104 0000	2400.00	2000.00	+ = 1250.05	
10		107 0000	2400.00	2000.00		
17		107.0000	2400.00	2000.00	- Chauldon Phan	
20 03			2400.00	2000.00	T STORIGE STAR	
-43. 		109.0000	2400.00	2000.00	· · · · · · · · · · · · · · · · · · ·	
		110.0000	2400.00	2000.00	T PIPST Set	7
23	P.T.	110.8587	2060.89	1717.41	+ r1 = R + Lw + 3nw	÷
24		0.0000	0.00	0.00	+ = 1284.05	÷.
25		0.0000	0.00	0.00	***	t
26	· · · · · · · · · · · · · · · · · · ·	0.0000	0.00	0.00	+ r2 = R + LW	÷
27		0.0000	0.00	0.00	+ = 1274.05	÷
23		0.0000	0.00	0.00	t 🕂 sa	۴
29		0.0000	0.00	0.00	+ r1 + r2	+
30	· · · ·	0.0000	0.00	0.00	+ = 2558.11	÷
31		0,0000	0.00	0.00	+ r1 - r2 .	÷
32		0.0000	0.00	0.00	+ = 10.00	÷
33	· · · · · · · · · · · · · · · · · · ·	0.0000	0.00	0.00		+.
34.		0.0000	0.00	0.00	+ Second set:	+
<u>_</u>		0.0000	0.00	0.00	+ r1 = R - 1M	+
-24		0.0000	0.00	0.00	+ = 1250.05	4
	1999 - Sec A	o oooo	0.00	0.00		
-07		0.0000	0.00	0.00		
		0.0000	0.00	0.00	+ 12 - 6 - 1240 0 =	T
್		0,0000	0.00	0.00	= 1240.05	
40	Martin and Article	0.0000	0.00	0.00		+
41	Maria di Anglia	0.0000	0.00	0.00	+ r1 + r2	÷
42		0.0000	0.00	0.00	+ = 2490.11	÷
43		0.0000	0.00	0.00	+ n1 - r2	t
44	e e la companya de la	0.0000	0.00	0.00	+ = 10.00	+
45	•	0.000	0.00	0.00	· · · · · · · · · · · · · · · · · · ·	÷.
46	and a second	0.0000	0.00	0,00		
47		0.0000	0.00	0.00		-
48		0.0000	0.00	0.00		
49		0.0000	0.00	0.00		
50		0.0000	0.00	0.00		
5 () 5 ()		0,0000	0.00	0.00		
55		0.0000	ο ο ο ο ο ο ο ο ο ο ο ο ο ο ο ο ο ο ο	. <u>6.66</u>		
53		میں میں میں اور میں -	بنایا سب ساید اینده است. بایی ایند اینده اینده بایی بایی سب سب بید. بایار رایز ۱۹۹ بایار	۵۰٫۴ ۲۰۰۰ ۲۰۰۰ ۲۰۰۲ سالت منبع تصبر (۱۹۹۵ ۱۹۹۵ ۱۹۹۵ ۱۹۹۵ ۱۹۹۵ ۱۹۹۹ ۱۹۹۵ ۱۹۹۵		
<u>с</u> л		Verea at Sm	00011 00	TAINO AA		
···	in a cum that the	alon a consider a constituent	الأحيموك فالبلي الأسرا فسياستك المرا	· · · · · · · · · · · · · · · · · · ·	1	

					1.1
1.1	34	a ser para	32		33

DEFLECTION	
ANGLES	

TANGENT TO CURVE COMPUTATIONS

1¹²5

6	Turni	ng i	Turning	e george		2	· _
~		C 7	Lett		4 2 100		Arc
10 -	(uegrees)	(racians)	(degrees)		t/R	Theta	Length
9							n nn
10	0,00	0,000	360.00		0.00	0.00	
i 1	0,33	0.006	359.67		0,01	0.66	447 77
1.2	2.60	0.045	357.40		0.02	5.21	114,70
13	4.87	0.085	355,13	and and an and a second se	0.17	19 - 19 - 19 - 19 - 19 - 19 - 19 - 19 -	210.60
14	7.14	0,125	352.86	5 d	0.25	14.43	317.90
15	9.41	0.164	350,59		0,33	19.18	42.44
1.6	11.68	0.204	348.32		0.41	24.06	530.05
17	13.25	0.243	346.05		0.49	22.14	641.92
18	16.22	0.283	343.78	1	0.46	27.64	608.73
1.9	18.49	0.323	341.51		0.38	22.62	498.24
20	20.76	0.362	332,24		0.31	17.78	371.66
21	23.03	0.402	336.97		0,23	13.07	287.89
22	25.30	0.442	334.70		0.15	8.45	186.07
23	27.25	0.476	332.75		0.07	3.88	85,47
24	°,00 €	0.000	0.00		0.00	0.00	0.00
25	0.00	0.000	0.00		0.00	0.00	0,00
26	0.00	, 0 . 000	0,00		0.00	0.00	0.00
27	· .0, 00	0.000	0.00	1	0.00	0,00	0.00
2.2	0.00	0.000	0.00	· · · · ·	0.00	0.00	0.00
29	0,00	0.000	0.00	•	0.00		0.00
30	0.00	0.000	0.00		0,00	0.00	0.00
31	0.00	0.000	0.00	an di san sa	0.00	0.00	0.00
	0.00	0.000	0.00	·. · · ·	0.00	0.00	0.00
33	0.00	0.000	0,00	and the second second	0.00	0.00	0.00
34	0.00	0.000	0,00		0.00	0.00	0.00
35	0.00	0.000	0.00	and the state	0.00	0.00	0.00
36	0.00	0.000	0.00	and the second	0.00	0.00	0.00
37	0.00	0,000	Q., QQ		0.00	< 0.00	0.00
38	0.00	0:000	0.00	in the second	6.00 C	0.00	0.400
39	0.00	0.000	0.00		0.00	0.00	0.00
40	0.00	0.000	0.00		0.00	0.00	0,00
41	0.00	0.000	0.00		0.00	0,00	0.00
42	0.00	0.000	0.00		0.00	0,00	0.00
43	0.00	0,000	0.00	e tra di second	0.00	0,00	0.00
44	0.00	0.000	0.00		0.00	0.00	0.00
45	0,00	0.000	0.00		0.00	0.00	0.00
46	O.OO	0.000	0.00	ананан сайтар сайтар Сайтар сайтар	0.00	0,00	0.00
47	0.00	0,000	0.00	",	0.00	0.00	0.00
$Q \subseteq$	0, ÓO	0.000	0.00	· · ·	0.00	0,00	0.00
69	0.00	0.000	0.00		0.00	0.00	0.00
50	0.00	0.000	0.00		0.00	0.00	0.00
² 51	0,00	O"QQQ	0,00		0.00	0.00	0.00
52	0.00	0.000	0.00		0.00	0.00	0.00
53	0.00	0.000	0.00		0.00	0.00	0.00
5.4	0 00	0.000	0 00		0.00	0.00	0.00
2.1.4. EARTHWKS

k

EARTHWKS

2.1.4.1. Introduction

EARTHWKS is a spreadsheet developed to calculate the mass diagram ordinate using the cut and fill quantities obtained from roadway cross sections. The original objective was to create a spreadsheet that would provide a dot-matrix printer plot of the mass diagram from the results of this spreadsheet. Another design objective for this spreadsheet was to have one variation which permitted the entry of ground elevations of the cross section with the specified finished profile cross section, then the spreadsheet would compute the cuts and fills for each cross section. While both of these are possible, it proved unwieldy and cumbersome such that both these objectives were abandoned. It is anticipated that programs to do these tasks and that can also interface with this spreadsheet will be developed in the future.

The input data include: station, template cut and fill per station, additional cut and fill per station, cut and fill required to rebuild embankment, cut and fill related to removal of pavement, unsuitable cut, and percent shrinkage.

The output generated includes: adjusted cut and fill

per station, adjusted fill + shrinkage, and mass diagram ordinate.

2.1.4.2. Using the Spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred to the spreadsheet, and then input the data onto the spreadsheet. The data obtained from preliminary cross sections can be transferred to an input form. In this way this spreadsheet may be a useful tool in the early stages of design to determine what major vertical profile adjustments may be required to achieve earthworks balance before going to a computer generated set of cross sections for a final design. Once this input form record of the data is made, the user can proceed to use the spreadsheet.

The first step is to load the file from the disk to Multiplan. The master spreadsheet file is assumed to be stored on disk in a Normal Mode under the name EARTHWKS.MP. Once the master spreadsheet is loaded into the computer, turn the Recalculation option OFF (select Options command, then "tab key" to Recalc and highlight "off"). Then input the information in rows 13-14 (see Figure 13). These data include the project number, project name, preparer, checker, and dates the project was prepared and checked. Once the informative data are

62 :

input, the user then should input the station, template cut and fill per station, additional cut and fill per station, cut and fill required to rebuild embankment, cut. and fill related to pavement removal, unsuitable cut, and percent shrinkage. All input data except the percent shrinkage can be obtained from the preliminary cross The percent shrinkage (row 13 column 19, see sections. Figure 13) is chosen according to the policy used in the engineer's office for the anticipated soil conditions and construction practices. All of these data are input for each station. Before viewing the output data generated by the spreadsheet, REMEMBER TO TURN THE RECALCULATION MODE OF SPREADSHEET OPERATION BACK TO "ON". After viewing the output data, the spreadsheet should be saved with a file name solely characteristic of the project for the purpose of reuse and later editing.

 $\frac{\partial f}{\partial t} = \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} + \frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right) + \frac{\partial f}{\partial t} \left(\frac{\partial f}{\partial t} \right)$

If the project has more stations than are provided by the spreadsheet, the user should insert additional rows just above the "Totals" line in the spreadsheet. The equations for adjusted cut and fill, adjusted fill + shrinkage, station (column 21, see Figure 13), mass diagram ordinate, and the section dividers should also be copied dowm into the inserted additional rows of the expanded spreadsheet.

2.1.4.3. Example Problem

There is not a readily adaptable example that can be shown in the space of this manual. To begin use, and as a check, the user should calculate the mass diagram ordinates for a project both by hand and using the spreadsheet the first time he or she uses this spreadsheet. In this way, the user can verify that the spreadsheet is working properly.

++ +	·++++++++ M::1++-7	+++++++++	+++++	t+++++++++	++++++++	++++++++	⊦∔++	
	Hydrau	lic and l	líghwa;	y Engineeri	ng Compu	tations	+	
+		Copyrigh	nt by l Vere	Kent L. Ahr	enholtz		+	
+			1986				+ .	
· ++	·+++++++++++++++++++++++++++++++++++++	* *******	┝┿┿┿┿┿	╪╍╪╍╪╍╪╍╪╍╪╍╪╍╪╍╪╍╪╸ _╋ ╸	+++ +++++	╺╈╺╈ ╺ ╈╺╪╸ ╡ ╸┽╸┽╸┥	• • • • • • • • • • • • • • • • • • • •	
Project Project	Number: Name:		Prepai	red By: ed By:		De De	nte: nte:	
Descript	100	Station		Template	Addit. Quant.	Rebui Embar +C	ld nk	Pavement Remova
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	~~~~~~~			~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
		0.0000		U	0		U	
			1					
			i i	ية المراجع المراجع				
			1					
					-			
			}			н 1911 - 1911		
			1					
			i i					
				÷				
			2 8 8					
				,				
			1					
			1 1					
			•					
			1					

Figure 13. Input Template for EARTHWKS

Figure 13. (continued)

3	······································	TOTALS ==	>	66	0	0	0	0
7 3 9 1 2 3 4 5	•							
5 9 1 2 3 4 5 6								
8 9 0 1 2 3 4 5 6 7 8	 • •		***					
7 8 9 0 1 2 3 4 5 5 6 7	·							
~			1					



### Figure 13. (continued)

4.10





	16	17	18	19 2	0 21	22
1 2	******	ROADWAY EA	RTHWORK CO	MPUTATIONS	**********	******
3	********	******	****	*****	****	********
5						÷
6		:				
8					. '	
9				•		
10			,			
12		۵۰ مُنبو عند شده الله عبد عبد عند الله عبد عبد الله . ۱۰ -	مید بات جله فی بید بند باد مید می مد به م	يونية تركية تركية تركية منية منية منية تركية المرك المرك الم	ا مەرى بىرى بىرى بىرى بىرى بىرى بىرى بىرى ب	
13		Percent sh	nrinkage =	pe	rcent	
15						
16	Rebuild Embank	Removal	Adjusted	Adjusted Fill+		Mass Diagram
18	+F	+F	Fill	Shrinkage	Station	Ordinate
19	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	•~~~~~	·~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	***************************************		~~~~~~~~ ^
20	U Star	0	0	0	0.0000	õ
22	·		o de la <b>O</b>	0	0.0000	0
23		·	0	0		0
25	ан 1 — Дар		0	· Õ	0.0000	õ
26			0	0	0.0000	0
27	ан сарана 1996 г. – 1996 г. – 1 1996 г. – 1996 г. – 1		0	0	0.0000	0
29			Ō	0	0.0000	0
30		·	0	0	0.0000	0
31 32			0	0	0.0000	Ö
33			0	0	0.0000.	0
34	•		· 0	0		0
36			i Õ	õ	0.0000	ŏ
37			0	0	0.0000	0
38		•.	U 0	U - ()		0
40	• •		Ŭ,	Ŏ	0.0000	ŏ
41			0.1	0	0.0000	0
42 43			0	. U D		0
44			Ō	i O	0.0000	0
45 16			. 0	0	1 0.0000	0.
47			0	. 0	0.0000	0
48			0	· 0	0.0000	0
49 50			0	0 M	0.0000	0
51			ő	ŏ	0.0000	ŏ
52			0.	0	0.0000	0
53 54		9 A	0 0	U Q		· 0
					•	

# Figure 13. (continued)

69

)

Figure 13. (continued)

55678901234567890123456789012345888888888888888888888888888888888888	16	17	18			20	$\begin{array}{c} 21\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0000\\ 0.0$	
79 80 81 82 83 84 85 86							0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	0 0 0 0 0 0 0 0
87 88 89 90 91 92 93 94				0 0 0 0 0 0 0 0			0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	0 0 0 0 0 0 0
95 96 97 98 99 100 101 102 103			· . . ·	0 0 0 0 0 0 0 0 0			0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	0 0 0 0 0 0 0 0
104 105 106 107 108	0		ō	0 0 0	0 0 0		0.0000 0.0000 0.0000	0 0 0

. .

# 2.1.5. SUPERE

· · ·

·.

#### SUPERE

### 2.1.5.1. Introduction

SUPERE is a spreadsheet developed to establish superelevation for a horizontal curve. The spreadsheet will calculate the surveying data required to layout a superelevated horizontal curve in the field.

The input data include: design speed, lane width, rates of normal crown and superelevation, point of curvature, point of tangency, centerline grades at the P.C. and P.T., elevation of the P.C. and P.T., station increment, and desired length of runoff.

The output generated includes:

runoff data:

minimum length of runoff to establish

superelevation,

actual design slope,

distance X required to raise outside edge of pavement to centerline elevation,

distance Y required to raise outside edge of pavement to a constant slope equal to the normal crown rate,

70% of runoff distance; layout data:

centerline elevation,

difference in elevation from centerline, elevation, and cross slope for both outside and inside of curve pavement edges at beginning and end of curve; stationing details:

beginning of superelevation runoff, station at a distance X from the beginning of runoff,

station at a distance Y from the beginning of runoff, and

2.1.5.2. Using the Spreadsheet

end of runoff.

The best way to begin using a spreadsheet is to obtain all pertinent data, to record the data in a form that is easily transferred to the spreadsheet, and then input the data into the spreadsheet. The data obtained from preliminary roadway layouts and design manuals can be transferred to an input form. Once this is done, the user can proceed to use the spreadsheet.

The first step is to load the file from the disk to Multiplan. The master spreadsheet is assumed to be stored on disk as a file in Normal Mode under the name SUPERE.MP. Once the empty master spreadsheet is loaded, turn the Recalculation OFF by using the Options command. Then input the informative data in rows 12-15 (see Figure 14). These data include the project number, project

name, preparer, checker, and the dates the project was prepared and checked.

Once the informative data are input, the user should then input the design speed, pavement lane width, rates of normal crown and superelevation, centerline grades at the P.C. and P.T., point of curvature station, point of tangency station, P.C. and P.T. elevations, and station increment into rows 17-27 in column 4 (see Figure 14). The point of curvature, point of tangency, centerline grades at the P.C. and P.T., and P.C. and P.T. elevations can be obtained from the plan and profile sheets (see Figure 15). The design speed, lane width, rates of normal crown and superelevation, and station increment are determined by or under the supervision of a qualified engineer. The values for these data are all chosen according to the highway design policy in practice in the engineer's office. Before proceeding, the user should turn the Recalculation Mode of operation back to ON (reenter the Options command).

When the spreadsheet has been recalculated by the computer, the user should examine the output value for the "Minimum length of runoff to establish superelevation" (row 32 column 4, see Figure 14). The engineer should determine if this is the value the engineer wants to use for length of runoff. If Tables III-7 to III-11 from the AASHTO Green Book or comparable tables from the Iowa Department of Transportation Design

Procedures Manual are used to obtain a value for the length of runoff, the distance X (row 46, column 4, see Figure 14) needs to be added to the value for length of runoff taken from the book tables. This is necessary in order to compare the table values with those computed by the spreadsheet.

If the value the engineer chooses for length of runoff differs from that given by the program, the user needs to input the preferred value in space beside the question:

"If not, what length of runoff do you wish to use?" (row 39, column 4, see Figure 14). If the engineer wishes to use the length of runoff computed by the spreadsheet, he or she needs to be sure that the cell described above (row 39, column 4) is empty. This is done by moving the cell pointer (illuminated block) to the cell in question (R39C4) and selecting the Blank command in the Multiplan command menu. These are all the required input data. The Recalculation Mode of operation should be in the ON status (go to the Options command to check), therefore, the output data is ready for viewing. After viewing the output data, the spreadsheet should be saved with a filename solely characteristic of the superelevated horizontal curve and project for the purpose of reuse and later editing.

2.1.5.3. Example Problem

The following is an example application of the spreadsheet previously described.

A farm-to-market paved county highway is to be designed and constructed in rural Iowa. From the plan and profile sheets, the point of curvature and point of tnagency are found to be 100 + 00.00 and 110 + 00.00, respectively. The P.C. is 900.00 feet above sea level and the P.T. is 890.00 feet above sea level. The centerline grades are 1% and -2% at the P.C. and the P.T., respectively. The design speed is 60 miles per hour. The pavement lane width is 12 feet. The rates of normal crown and the superelevation rate are selected as 2% and 8%, respectively, and the station increment is 25 feet.

The data are first entered on an input form. An example of one such input form with the example information entered is shown in Figure 16. After these data were entered into the spreadsheet and the Recalculation turned ON, the minimum length of runoff required to establish superelevation was found to be 266.4 feet. Assume the engineer wanted to use a value which was a multiple of the station increment, so the desired length of runoff of 275 feet was entered into the appropriate spreadsheet cell.

The completed spreadsheet is shown in Figure 17. The total output of the spreadsheet requires seven pages, but for layout of the curve in the field, only pages 3

## through 6 are needed.

Figure 14. Input Template for SUPERE

4 2 3 1 SUPERELEVATION COMPUTATIONS for HORIZONTAL CURVES 2 Э **** 4 Multiplan Microcomputer Spreadsheets for County 5 + Hydraulic and Highway Engineering Computations + 4 6 Copyright by Kent L. Ahrenholtz 1 + Version 1.0 8 4. 1986 C, *********************** i 0 11 12 Project Number: 13 Project Name: 14 Prepared By: Date: 15 Checked By: Date: 16 _____ Design speed, V 17 INPUT DATA: 0 miles/hour ----18 Lane width = 0.0 feet 19 Rate of normal crown 0.0 percent Rate of superelevation, e = 20 0.0 percent Centerline grade, g (at P.C.)= 21 0.00 percent 22 g (at P.T.)= 0.00 percent Point of curvature, PC = 0.0000 stations 23 24 P.C. elevation 0.00 feet -25 Point of Tangency, PT 0.0000 stations = P.T. elevation 0.00 feet 26 = Station increment 25 feet 27 = 28 29 RUNOFF DATA: Maximum relative design 30 slope for given design speed = 1:#N/A Minimum length of runoff to 31 establish superelevation = #N/A 32 feet ***** 33 34 + Do you wish to use this value for runoff, YES or NO ? YES 35 36 If not, what length of 37 runoff do you wish to use ? feet + 38 ************** 34 40 #N/A 41 OUTPUT DATA: Runoff distance, S feet -42 Actual design slope = 1: #N/A43 #N/A percent 44 Distance 'X' required to 1. raise outside edge to 40 centerline elevation #N/A feet 47 Distance 'Y' required to 48 49 raise outside edge to -50 a constant slope equal 51 to the normal crown rate = #N/A feet 52  $\cdot$  ,  $\dot{\epsilon}$ 70% of superelevation runoff = #N/A feet 5.4

78





Cross Sections:

Project Numb	per: 87-2		
Project Name	Story Co. E57		
Prepared By:	Abrenholtz	Date: 06-17-87	
Checked By:	Brewer	Date: 06-18-87	
INPUT DATA:	Design Speed, V	60	miles/hr
~~~~~	Lane Width	=12	_ feet
	Rate of Normal Crown	=2	_ percent
	Rate of Superelevation, e	=8	_ percent
	Centerline Grade (at PC)	=	_ percent
	(at PT)	= -2	_ percent
	Point of Curvature, PC	= /00.0000	_ stations
. •	P.C. Elevation	= 900.00	_ feet
	Point of Tangency, PT	= /10.0000	_ stations
	P.T. Elevation	=	_ feet
	Station Increment	<u>= 25</u>	feet

Figure 16. Input Form for Example Problem

* Be sure to check the length of the runoff after you have input the values above so it is the length you wish to use.

}

Figure 17. Example Problem Template

SUPERELEVATION COMPUTATIONS for HORIZONTAL CURVES *********** Multiplan Microcomputer Spreadsheets for County + Hydraulic and Highway Engineering Computations Copyright by Kent L. Ahrenholtz Version 1.0 1986 ************* Project Number: Project Name: Date: Prepared By: Date: Checked By: INPUT DATA: Design speed, V 60 miles/hour Lane width -= 12.0 feet Rate of normal crown 2.0 percent == Rate of superelevation, e 8.0 percent **a**2 Centerline grade, g (at P.C.)= 1.00 percent -2.00 percent g (at P.T.)= Point of curvature, PC = 100.0000 stations P.C. elevation = 900.00 feet Point of Tangency, PT = 110.0000 stations P.T. elevation 890.00 feet = Station increment 25 feet RUNOFF DATA: Maximum relative design slope for given design speed 1:222 = Minimum length of runoff to establish superelevation = 266.4 feet ***** + Do you wish to use this value for runoff, YES or NO ? YES If not, what length of runoff do you wish to use ? feet + ********** OUTPUT DATA: Runoff distance, S 266.4 feet Actual design slope = 1:222 0.45 percent ----Distance 'X' required to raise outside edge to centerline elevation 53.28 feet Distance 'Y' required to raise outside edge to a constant slope equal to the normal crown rate = 106.56 feet 70% of superelevation runoff = 186.48 feet

Figure 17. (continued)

TABLE III-13 from the AASHTO Green Book	DESIGN SPEED V (mph)	MAXIMUM PROFILE TWO-	M RELATIVE SLOPES FOR ES BETWEEN THE EDGE OF -LANE PAVEMENT AND THE CENTERLINE		
	20		1:133		
	30	t (1941) Alexandria Alexandria	1:150		
	40		1:175		
8	50		1:200		
	60		1:222		
	65		1:244		
	70	an a	1:250		

n an taona a Taona an taon Taona an tao

Figure 17. (continued)

LAYOUT DATA:

				OUTSIDE EDGE	
			Difference in elevation from centerline		Cross Slope
		Station	(IN feet) ~~~~~~~~~~~~~~	LIEVATION	(in percent)
	BEGINNING OF CHOVE				
	Section from ->	98 1352	-0.240	897.90	-2.00
	beginging to	98 2500	-0.188	898.06	-1.57
	the station at	98.5000	-0.100	898.42	-0.63
		98.3000 98.7500	0.070	898.79	0.31
	a distance i	000,196	0.007	899.15	1.25
		99.0000	0.150	899.44	2.00
		99.2000	0.240	0 00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
	Section from =>	99.2008	0.240	899.44	2.00
	the station at	99.2500	0.262	899.51	2.18
	a distance 'Y'	99.5000	0.375	899.87	3.12
	to the P.C.	99.7500	0.487	900.24	4.06
		100.0000	0.600	900.60	5.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		100 0000	0.000	000 60	
	Section from =>	100.0000	0.600	900.60	5.00
	the P.C. to	100.2500	0.713	900.96	
	the end of	100.5000	0.825	901.33	5.80 7.02
Ì	the runoff la	100.7500	0.938	901.69	7.82
		100.7992	0.960	901.76	8.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
	4	0.0000	0.000	0.00	0.00
	· •	~~~~~~~~	~~~~~	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	
	END OF CURVE:				
	Section from =>	109.2008	0.960	892.56	8.00
	the beginning	109.2500	0.938	892.44	7.82
	of the runoff	109.5000	0.825	891.83	6,88
	ro the P.T.	109.7500	0.713	891.21	5.94
		110.0000	0.600	890.60	5.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	.0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00
		0.0000	0.000	0.00	0.00

Figure 17. (continued)

LAYOUT DATA: (continued)

OUTSIDE EDGE

	Station	Difference in elevation from centerline (in feet)	Elevation	Cross Slope (in percent)
Section from => the P.T. to the station at a distance `Y'	110.0000 110.2500 110.5000 110.7500 110.7992 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	0.600 0.487 0.375 0.262 0.240 0.000 0.000 0.000 0.000 0.000 0.000 0.000	890.60 889.99 889.37 888.76 888.64 0.00 0.00 0.00 0.00 0.00 0.00 0.00	5.00 4.06 3.12 2.18 2.00 0.00 0.00 0.00 0.00 0.00 0.00 0.0
Section from => the station at a distance `Y' to the end	110.7992 111.0000 111.2500 111.5000 111.7500 111.8648 0.0000 0.0000 0.0000	$\begin{array}{c} 0.240\\ 0.150\\ 0.037\\ -0.076\\ -0.188\\ -0.240\\ 0.000\\ 0.000\\ 0.000\\ 0.000\end{array}$	888.64 888.15 887.54 886.92 886.31 886.03 0.00 0.00 0.00	2.00 1.25 0.31 -0.63 -1.57 -2.00 0.00 0.00 0.00

LAYOUT DATA: (continued)

		INSIDE EDGE		
Station	Difference in elevation from centerline (in feet)	Elevation	Cross Slope (in percent)	CENTERLINE
و این		~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	
98.1352 98.2500 98.5000 98.7500 99.0000 99.2008 0.0000 0.0000	$ \begin{array}{r} -0.240 \\ -0.240 \\ -0.240 \\ -0.240 \\ -0.240 \\ -0.240 \\ 0.000 \\ 0.000 \\ 0.000 \\ \end{array} $	897.90 898.01 898.26 898.51 898.76 898.96 0.00 0.00	-2.00 -2.00 -2.00 -2.00 -2.00 -2.00 0.00 0	898.14 898.25 898.50 898.75 899.00 899.20 0.00 0.00
99.2008 99.2500 99.5000 99.7500 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000	$ \begin{array}{r} -0.240 \\ -0.262 \\ -0.375 \\ -0.487 \\ -0.600 \\ 0.000 \\ 0$	898.96 898.99 899.13 899.26 899.40 0.00 0.00 0.00 0.00 0.00	-2.00 -2.18 -3.12 -4.06 -5.00 0.00 0.00 0.00 0.00 0.00	899.20 899.25 899.50 899.75 900.00 0.00 0.00 0.00 0.00 0.00
100.0000 100.2500 100.5000 100.7500 100.7992 0.0000 0.0000 0.0000 0.0000	-0.600 -0.713 -0.825 -0.938 -0.960 0.000 0.000 0.000 0.000 0.000	899.40 899.54 899.67 899.81 899.84 0.00 0.00 0.00 0.00 0.00	-5.00 -5.94 -6.88 -7.82 -8.00 0.00 0.00 0.00 0.00 0.00	900.00 900.25 900.50 900.75 900.80 0.00 0.00 0.00 0.00 0.00
109.2008 109.2500 109.5000 109.7500 110.0000 0.0000	-0.960 -0.938 -0.825 -0.713 -0.600 0.000 0.000 0.000 0.000 0.000	890.64 890.56 890.17 889.79 889.40 0.00 0.00 0.00 0.00 0.00 0.00 0.00	-8.00 -7.82 -6.88 -5.94 -5.00 0.00 0.00 0.00 0.00 0.00 0.00	891.60 891.50 891.00 890.50 890.00 0.00 0.00 0.00 0.00 0.00

Figure 17. (continued)

LAYOUT DATA: (continued)

INSIDE EDGE

centerline Cross Slope CENTER Station (in feet) Elevation (in percent) ELEVAT	LINE 10N .00 .50
Station (in feet) Elevation (in percent) ELEVAT 1 110.0000 -0.600 889.40 -5.00 890	10N .00
+ 110.0000 -0.600 889.40 -5.00 890	.00
+ 110.0000 -0.600 889.40 -5.00 890	.00
	.50
-0.487 889.01 -4.06 889	
110.5000 -0.375 888.63 -3.12 889	.00
110.7500 -0.262 888.24 -2.18 888	.50
110.7992 -0.240 888.16 -2.00 888	.40
0.000 0.000 0.00	.00
0.000 0.000 0.00 0.00 0.00 0.00	.00
0.000 0.000 0.00 0.00 0.00 0.00	.00
0.000 0.000 0.00 0.00 0.00 0.00	.00
0.000 0.000 0.00 0.00 0.00	.00
1. 0.000 0.000 0.00 0.00 1 0	.00
-0.240 888.16 -2.00 888	.40
-0.240 887.76 -2.00 888	.00
-0.240 887.26 -2.00 1 887	.50
-0.240 886.76 -2.00 887	.00
111.7500 -0.240 886.26 -2.00 886	.50
111.8648 -0.240 886.03 -2.00 886	.27
0.000 0.000 0.00 0.00 0.00 0.00 0.00	.00
0.0000 0.000 0.00 0.00 0.00 0.00	.00
0.000 0.000 0.00 0.00 0.00 0.00	.00

Figure 17. (continued)

STATIONING DETAILS:

At the Beginning of the Curve: * Beginning of superelevation runoff, P.C.- 70% of runoff = 98.1352* Station at a distance 'X' from beginning of superelevation runoff = 98.6680 * Station at a distance 'Y' from beginning of superelevation runoff = 99.2008 * Point of Curvature, P.C. = 100.0000* End of superelevation runoff, P.C.+ 30% of runoff = 100.7992 First even incremental station after beginning of superelevation runoff = 98.2500 First even incremental station after a distance 'Y' from the beginning = 99.2500 First even incremental station after the point of curvature, P.C. = 100.2500 At the End of the Curve: * Beginning of superelevation runoff, P.T.- 30% of runoff = 109.2008 * Point of Tangency, P.T. = 110.0000* Station at a distance 'Y' from end of superelevation runoff = 110.7992 * Station at a distance 'X' from end of superelevation runoff = 111.3320 * End of superelevation runoff, P.T.+ 70% of runoff = 111.8648 First even incremental station after beginning of superelevation runoff = 109.2500 First even incremental station after the point of tangency, P.T. = 110.2500 First even incremental station after a distance 'Y' from the beginning = 111.0000

a a series de la companya de la comp A series de la companya de la company A series de la companya de la company

2.1.6. SIGNINV and MAINTREC

and a second second

SIGNINV and MAINTREC

2.1.6.1. Introduction to SIGNINV

SIGNINV is a spreadsheet illustrating one (of many) approach to creating a traffic control device inventory using a spreadsheet program. A microcomputer data base program will permit creation of a traffic control device inventory system with more flexibility in manipulating the information contained in the file. However, if the need is for a systematic record from which reports may be generated periodically, then it is possible to create a workable and effective inventory system with a spreadsheet program. This spreadsheet is organized with the various traffic control device parameters entered in columns across the table and each control device occupies Thus, as many traffic control devices can be a row. entered as there are rows in a spreadsheet. For the smallest versions of Multiplan that operate on an Apple Ile computer, the spreadsheet contains 254 rows. For the largest versions for MS-DOS computers the spreadsheet contains over 4000 rows. In a practical sense, the number of rows that may be filled is dependent upon the computer memory size installed and the efficiency of the computer in allocating memory. Therefore, in this and similar applications, the user should prepare a SIGNINV1,

SIGNINV2, etc., to handle any massive data base.

The user should change the column headings to suit his or her needs in identifying traffic control devices. This illustrative design resulted from several consultations with county offices, the Iowa Division of the Federal Highway Administration and the Iowa Department of Transportation Office of Local Systems. It is intended, however, to be a guide to assist the user in generating application concepts to move beyond the scope of this report in using Multiplan (or any spreadsheet).

2.1.6.2. Introduction to MAINTREC

MAINTREC is a spreadsheet designed to work with SIGNINV to establish a record of the maintenance history for a traffic control device. It is designed to have a particular traffic control device occupy an entire row in the table. Note that the column headings contain identification information in the first few columns which is to correspond to the sign identification in SIGNINV. Subsequent columns in the table are a repeating pattern of recording a notice of need for maintenance and action taken. This permits establishing a record base of the maintenance history of the traffic control device. There are sufficient columns in the spreadsheet to permit retaining what is expected to be about 10 years activity on a traffic control device.

There is an advantage to having something such as a maintenance record in a separate file from an inventory. The maintenance record in the case of traffic control devices may be considered a sensitive record. In this manner, it is possible to keep different security levels for the inventory and the maintenance record. Someone looking at the inventory will not immediately find the maintenance history. In fact, it may be desirable to have files such as these on two completely different disks. Access to data and file security is always a concern in computer systems. Planning for it should be considered at the time records are established.

2.1.6.3. General Introduction

SIGNINV and MAINTREC are two spreadsheets developed to be used as a traffic control device inventory. SIGNINV can be used to store the location, type, and condition of the traffic control devices within an engineer's jurisdiction. MAINTREC can be used to store a record of the maintenance performed on each traffic control device.

The input data for SIGNINV include: sign number, sign location (township number, range number, section number, township name, and the engineer's choice for the exact location of the sign), sign legend, MUTCD number, sign position (direction sign is facing, lateral position such

as distance from roadway and side of road), number in assembly, sign characteristics (shape, color, size in horizontal and vertical dimensions, height, sign condition, sign reflectivity, and sign visibility), post characteristics (post type and post condition), inventory direction, inventory date, last date checked, maintenance record sheet, and remarks.

The input data for MAINTREC include: sign number (same as in SIGNINV), date reported, sign condition, recommended improvements, and date installed/serviced for each time a sign is repaired.

These spreadsheets were developed using the <u>Traffic</u> <u>Sign Inventory System</u> developed for the Iowa Department of Transportation by Johnson, Brickell, Mulcahy and Associates as a reference and a guide. The spreadsheets are similar to the sign inventory and maintenance record forms included in this document.

2.1.6.4. Using the Spreadsheets

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred onto the spreadsheet, and then input the data into the spreadsheet. The data obtained in the field should be collected on an input form. The form can be made up by the engineer or it can be similar to the examples in the <u>Traffic Sign Inventory System</u> document.

Once the data have been collected, the user can proceed to use the spreadsheet.

The first step is to load either file from the disk into the computer operating in Multiplan. The files are assumed to be stored on disk in Normal Mode as SIGNINV.MP and MAINTREC.MP, respectively. Once the spreadsheet to be used is loaded into the computer, the data can be input from the appropriate field input form (examples shown in Figure 18).

2.1.6.5. <u>SIGNINY</u>

Before entering data, the engineer should decide upon a method to be used for the exact location of the sign to put into columns 7 and 8 (see Figure 18). Some suggestions for this include references to section corners and quarter-section corners, reference to the Iowa Department of Transportation's road number system, the ALAS link-node indentification system used for accident location, or by route number and referenced to section lines. These are only a few of the possible methods. The engineer may have another one he or she prefers. The most important thing to remember is the system must be inderstood and applied by all personnel who are involved in the sign inventory.

Once the user is prepared to begin, he or she should then input the data into the spreadsheet. These data for

SIGNINV include the sign number, sign location, sign legend, MUTCD number, direction facing, lateral position, number in assembly, sign characteristics, post characteristics, inventory direction, inventory date, last date checked, maintenance record sheet number, and any remarks (see Figure 18). All of these data can be obtained in a field inspection of traffic control devices, except for the MUTCD number which can be obtained from the <u>Manual on Uniform Traffic Control</u> <u>Devices</u>. Once the data have been entered, the spreadsheet should be saved with a filename characteristic of the position of the spreadsheet within the inventory (i.e., SIGNINV!, SIGNINV2, etc.).

One problem in using a spreadsheet to develop this inventory system is not being able to easily obtain a list of all signs of a specific type of a specific location unless the data is input in that fashion. This means, if the engineer wanted a list of all the STOP signs within his or her jurisdiction, it would be cumbersome to accomplish.

2.1.6.6. MAINTREC

When the user is prepared to begin using MAINTREC, the engineer should then input the data into the spreadsheet. These data include the sign number, date sign condition reported, condition, recommended improvements, and date

installed or repaired (see Figure 19). All of these data can be obtained from either a field inspection or a citizen callling in a problem with a sign. The sign number should be the same number as that used in SIGNINV for the sign in question. Once the data have been entered, the spreadsheet should be saved with a filename characteristic of the position of the spreadsheet within the inventory (i.e., MAINTREC1, MAINTREC2, etc.). The spreadsheet should also be labeled with a letter (i.e., A, B, C, etc.) in row 13 column 2 at the top of the sheet corresponding to its position in the inventory.

2.1.6.7. Example Problem

No example problem was developed for this spreadsheet due to the wide range of opinion on exactly how it should be applied.
Figure 18. Form of SIGNINV

+ + + + + + + + + + +	++++++ Multi Hydr ++++++	++++++ plan 1 aulic Cop	and H	+++++++++ omputer Spr ighway Engi t by Kent L Version 1 1986 +++++++++++	+++++++ readshea ineering Ahren 1.0 +++++++	++++++ ts for Comput holtz +++++++	+++++++ County ations +++++++	*** * * * * *
SIGN !				SIGN LOCAT	FION			
NO.	Twns	Range	Sect	Township	Name	?		?
2 3 4 5 6 7 8 9 10 11 12 13 4 15 16 7 8 9 10 11 12 13 4 15 16 7 8 9 10 11 20			· ·					



Figure 18. (continued)

Figure 18. (continued)

	·		· .	
		SIGN	CHARACTERIST	ICS
ASSEMBLY	Shape		Color	Horiz Vert Height
1 1 1	199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199 - 199	** ** ** ** ** *	1999 - 1996 - 1987 - 1997 - 1997 - 1997 - 1997 - 1998 - 2004 - 2004 - 2004 - 2004 - 2004 - 2004 - 2004 - 2004 -	ten ven min nan min ann ann ann ann ann ann ann ann ann a
2 2 2				
3 8 8 1				
4 8 4 3				
2 			н	
, , , , , , , , , , , , , , , , , , ,				
			•	
1 1 1				
			. •	
3 				
			· ·	
i T I				
1 2 7				



Figure 18. (continued)



Figure 18. (continued)

· ·				н. 1.1	
	·	50 50			
	MAINTENANCE				
CHECKED	SHEET		REMAR	RKS	
	. The first and the first first the second			904 9000 9900 990 990 990 990 990 9	
		•			
·				•	
				۰.	
	· .				
				· · ·	
·					

. .

Figure 19. Form of MAINTREC

123456789011	** * * * * * * * * * * * * * + + + + + +	**** **** ! !	TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC TRAFFIC	C CONT	ROL DE ****** poputer ghway t by K Vers 1	<pre>****** VICE M ****** Sprea Engine ent L. ion 1. 986</pre>	AINTENANO ********** dsheets 1 ering Cor Ahrenho 0	CE RECORD	* * * * * * * * * * * * * * * * * * *
12 13 14	SHEET	٨						·····	
15	SIGN NO.	 	DATE REPORTED		CONDI	TION	·	RECO IMPR	MMENDED OVEMENTS
19012222222222233333333333444444444555555	1 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 6 7 8 9 10 11 2 3 4 5 10 1 1 2 1 5 1 1 2 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 2 1 1 2 1 1 1 2 1 1 2 1 1 2 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 1 2 1 2 1 1 1 1 2 1 1 1 1 2 1 1 1 1 1 2 1 1 1 1 2 1 1 1 1 1 1 1 1 2 1	17							

Figure 19. (continued)

****	*******	*****	***
	,	1. Sec. 1. Sec. 1.	
			•
•			
•		•	
0.070	1 (C) A 77 (FT		
INSTALLED		CONDITION	
	·		
		,	
	↓ ↓		
• •			
	* * *		
•	1		
	1 1		
	1 3 4		
		· .	
		•	
· ·	1		
•			
	5		
	\$ \$ 1		
		· .	
1997 - A.	•		
· .			



' Figure 19. (continued)

2.2. Hydraulic Engineering Spreadsheets

1

غه رهار

2.2.1. DITCHFL

DITCHFL

MANNING'S EQUATION - OPEN CHANNEL GEOMETRICAL SECTIONS

2.2.1.1. Introduction

The "Manning's Equation - Open Channel Geometrical Section" spreadsheet was developed to find the normal depth of water given various hydraulic conditions. The program uses the Iteration Mode of operation available in Multiplan to compare an entered initial specified design flow and one calculated by the spreadsheet.

The input data consists of the ditch bottom, foreslope, backslope, Manning's n, ditch slope, design flow, and initial trial depth. Once the initial data are entered, the Iteration option is invoked and depth of flow for a given design will be calculated. The output consist only of the calculated flow depth.

2.2.1.2. Using the Spreadsheet

The best way to begin using this or any spreadsheet template is to collect all the pertinent data, record the data in a form that is easily transferred into the spreadsheet, and then enter the data into the spreadsheet. The first step is, thus, to collect the data and record it onto an input form. Once this is accomplished, a person can begin to use the spreadsheet template.

The first step after completing the input form is to load the spreadsheet into the computer. The master template is assumed to be stored on a disk in the Normal Mode under the filename DITCHFL.MP. Once the master template is loaded into the computer, use the Options command from the Multiplan menu to turn OFF both the Recalculation option and the Iteration option for initial data entry. At this time the user can enter the data for project number, project name, preparer, checker and dates prepared and checked. These entry lines are found in rows 14 through 17 (see Figure 20).

After items have been entered in rows 14 through 17, enter the design parameters located in column 6 in rows 23 through 29 (see Figure 20). These items include: the ditch bottom width, foreslope, backslope, Manning's n, ditch slope, design flow to be accommodated, and the initial trial depth.

The ditch bottom width is entered in feet. For triangular cross-sections, the ditch bottom width should be 0.0 feet. The foreslope is the slope from the ditch bottom to the edge of the roadway shoulder. The backslope is that from the ditch bottom to the interception of natural ground surface at the outer right of way edge. The backslope and the foreslope are entered in the form Z:1 where Z is a horizontal distance in feet

(see Figure 21). The ditch slope is the average slope at the location for which the data apply and is entered in feet per feet. Manning's n should be the one that is best suited at the channel location where the flow depth is to be calculated. The design flow is the flow for which the normal depth is to be calculated. Design flow is entered in cubic feet per second (cfs). The final input parameter is the initial trial depth. The spreadsheet will work for any initial trial depth that is less than or nearly equal to the final depth. A value of 0.10 feet is recommended as a starting value for most conditions.

Once all the data are entered, the Recalculation option and the Iteration option are turned ON. At this time the spreadsheet will begin the recalculation and iteration to converge on a flow depth. When the iteration is complete the results are found in row 33 (see Figure 20).

Before making changes to more than one cell in the spreadsheet, turn the Iteration and the Recalculation options OFF. After making the changes in design parameters, then turn Iteration and Recalculation back ON. IF ANY RESULTS OF AN ITERATION ARE NEEDED FOR LATER USE, BE CERTAIN TO SAVE THE SPREADSHEET ON DISK AT THAT POINT BEFORE MAKING FURTHER CHANGES.

2.2.1.3. Example Problem

A ditch located along a county road has deteriorated to the point where it needs to be regraded to adequately drain the water. The final ditch design is one which requires the road to be located five feet above the bottom of the ditch. Three alternative designs have been proposed. These are shown in Figure 22. Table 1 shows the design parameters for each cross-section. Which ditch design should be used so that the water depth remains below the elevation of the roadway for the 100-year storm?

The data are taken from Table 1 and recorded onto input forms. These completed forms are shown in Figure 23. From the input forms, the data are input into the spreadsheet template. The results of each of the three examples are shown in Figures 24, 25 and 26.

One can now look at and compare the results. From this example it appears that the only ditch that will give a water depth below the roadway surface is cross-section 1 which has a water depth of 4.8 feet. The water depths for cross-sections 2 and 3 are 5.4 feet and 6.8 feet respectively which exceeds the design specification of 5.0 feet maximum depth of flow.

Design parmeter	Cross - section				
	1	2			
Ditch bottom (ft)	30	20	0		
Foreslope (ft:1)	1:1	2:1	4:1		
Backslope (ft:1)	1:1	2:1	4:1		
Manning's N	0.02	0.02	0.02		
Ditch slope (ft/ft)	0.01	0.01	0.01		
100-year design flow (cfs)	3000	3000	3000		
Initial trial depth (ft)	.0.1	0.1	0.1		

Table 1. Input data for example problem

Figure 20. Input Template for Manning's Equation - Open Channel Geometric Section 1 5 4 6 1 MANNING'S EQUATION - OPEN CHANNEL GEOMETRIC SECTIO 2 3 4 5 *************** + Multiplan Applications in Civil Engineering 6 7 November 21, 1984 + 8 Copyright by Kenneth A. Brewer ÷ 9 All Rights Reserved, 1984 + 10 Version 1.4 + 11 Revised March 27, 1987 + 12 *************** 13 14 Project Number 1 15 Project Name 1 16 Prepared By Date: 1 17 Checked By Date: . 18 19 20 21 INPUT - Design Parameters 22 ~~~ 23 Ditch bottom (FT) -----> 24 Foreslope (FT:1) ----> 25 Backslope (FT:1) ----> Manning's N -----> 26 Ditch slope (FT/FT) -----> 27 Design flow (cfs) -----> 28 29 Initial trial depth (FT) ----> 30 31 ----32 OUTPUT 33 ~~~~~ Calculated Flow Depth (FT) = #VALUE! 34 35 ---36 **37 CALCULATIONS** 38 39 1.486/Mannning's N = #DIV/01 Calculated Flow Depth (FT) = 40 #VALUE! 41 Flow Area (SQ FT) == #VALUE! 42 Wetted Perimeter (FT) = #VALUE! 43 Hydraulic Radius (FT) ----#VALUE! 44 Calculated Velocity (FPS) = **#VALUE!** 45 Test to Design Flow (cfs) = **#VALUE!** 46 Delta Flow (cfs) ----#VALUE! 47 Initial Delta *** 48 Delta Change = #VALUE! Delta Check to Stop 49 TRUE = 50 Test for end: #VALUE! 51 52 53 54 55 * COPYRIGHT 1984, 1985, BY K. A. BREWER * 56



Figure 21. . Description of input varibles for channel cross-section





Figure 23. Input Form for DITCHFL

INPUT FORM - Page 1

MANNING'S EQUATION - OPEN CHANNEL GEOMETR	RICAL SECTION
Project Number:	
Project Name :	
Prepared By : Dat	te:
Checked By : Dat	te:
***********	****
INPUT - Design Parameters - Option 1	
Ditch bottom	> <u>30</u> feet
Foreslope	> <u>/</u> ft:1
Backslope	>ft:1
Manning's roughness coefficient (n)	-> 0.02
Ditch Slope	> 0.01 ft/ft
Design flow	> <u>3000</u> cfs
Initial trial depth	> <u>0.1</u> feet
*****	****
INPUT - Design Parameters - Option 2	
Ditch bottom	> feet
Foreslope	-> ft:1
Backslope	-> ft:1
Manning's roughness coefficient (n)	->
Ditch Slope	-> ft/ft
Design flow	-> cfs
Initial trial depth	-> feet

Figure 23. (continued)

INPUT FORM - (continued) - Page of	
MANNING'S EQUATION - OPEN CHANNEL GEOMETRICAL SECT	ION
Input Design Parameters - Option	
Ditch bottom>	feet
Foreslope>>	£t:1
Backslope>	£t:1
Manning's roughness coefficient (n)>	
Ditch Slope>	£t/£t
Design flow>	cfs
Initial trial depth>	feet
***************************************	k
INPUT - Design Parameters - Option	
Ditch bottom>	feet
Foreslope>	£t:1
Backslope>	ft:1
Manning's roughness coefficient (n)>	
Ditch Slope>	ft/ft
Design flow>	cfs
Initial trial depth>	feet
*************	k -
INPUT - Design Parameters - Option	
Ditch bottom>	feet
Foreslope>	ft:1
Backslope>	£t:1
Manning's roughness coefficient (n)>	
Ditch Slope>	£t/£t
Design flow>	cfs
Initial trial depth>	feet

Figure 24. Example Problem 1 Template

MANNING'S EQUATION - OPEN CHANNEL TRAPEZOIDAL SECTION ***** + Multiplan Applications in Civil Engineering + November 21, 1984 Copywrite by Kenneth A. Brewer Version 1.2 Revised August 19, 1986 ******* Project Number 1 1 Project Name :Example problem 1 Prepared By :Rocky Keehn :Rocky Keehn Date: 9/9/86 Date: 9/9/86 Checked By INPUT - Design Parameters Ditch bottom (FT) ----> 30 Foreslope (FT:1) ----> 1 Backslope (FT:1) -----> Manning's N ----> 0.02 Ditch slope (FT/FT) -----> 0.01 Design flow (cfs) -----> Initial trial depth (FT) ----> 3000 0.10 CALCULATIONS 74.30 , " 1.486/Mannning's N Calculated Flow Depth (FT) = 4.76 Flow Area (SG FT) Wetted Perimeter (FT) Hydraulic Radius (FT) = 165.45 = 43.46 -3.81 Calculated Velocity (FPS) Test to Design Flow (cfs) # 18.12 = 2998.41 Delta Flow (cfs) -1.5896 Initial Delta ÷ Delta Change -0.00 Delta Check to Stop TRUE CONTINUE ITERATION Test for end: OUTPUT ~~~~~ 4.76 Calculated Flow Depth (FT) KIT: 34 COPYRIGHT 1984, 1985, BY K. A. BREWER * ****************

Figure 25. Example Problem 2 Template

MANNING'S EQUATION - OPEN CHANNEL TRAPEZOIDAL SECTION ************** Multiplan Applications in Civil Engineering November 21, 1984 Copywrite by Kenneth A. Brewer Version 1.2 Revised August 19, 1986 ***** Project Number : 1 Project Name :Example problem 2 Date: 9/9/86 :Rocky Keehn Prepared By Date: 9/9/86 Checked By Rocky Keehn INPUT - Design Parameters Ditch bottom (FT) ----> 20 Foreslope (FT:1) -----> 2 Backslope (FT:1) -----> 2 Manning's N ----> 0.02 Ditch slope (FT/FT) ----> 0.01 Design flow (cfs) ----> 3000 Initial trial depth (FT) ----> 0.10 ____ CALCULATIONS -1.486/Mannning's N 74.30 5.40 Calculated Flow Depth (FT) = 166.52 122 44.17 Hydraulic Radius (FT) 3.77 Calculated Velocity (FPS) = 18.01 = 2998.26 Test to Design Flow (cfs) Delta Flow (cfs) **R**2 1.7379 Initial Delta 33 0.00 Delta Change æ Delta Check to Stop TRUE -----CONTINUE ITERATION Test for end: OUTPUT ~~~~~~ Calculated Flow Depth (FT) 100 5.40 * COPYRIGHT 1984, 1985, BY K. A. BREWER * ***************

Figure 26. Example Problem 3 Template

****	********	****
+ Mul	tiplan Applications in Civil Eng	ineering +
+	November 21, 1984	• • •
+	Copywrite by Kenneth A. Brew	er +
+	Version 1.2	+
+	Revised August 19, 1986	++++++++++
.,,.,		
Project Number	: 1	
Project Name	:Example problem 3	· · · · · · · · · · · · · · · · · · ·
Prepared By	Rocky Keehn Dat	e:9/9/86
Checked By	:Rocky Keehn Dat	e19/9/86
INPUT - Design P	ar ameters	
	Ditch bottom (FT)	-> 0
	Foreslope (FT:1)	-> 4
	Backslone (FT:1)	-> 4
	Nanning's N	-> 0.02
	Ditch slope (FT/FT)	-> 0.01
	Design flow (cfs)	-> 3000
	Initial trial depth (FT)	-> 0.10
CALCULATIONS	1.486/Manning's N	= 74.30
	Calculated Flow Depth (FT)	= 6.76
	Flow Area (SQ FT)	= 182.79
	Wetted Perimeter (FT)	= 55.74
	Hydraulic Radius (FT)	= 3.28
	Calculated Velocity (FPS)	= 16.41
	Test to Design Flow (cfs).	= 2998.74
	Delta Flow (cfs)	= 1.2565
	Initial Delta	#
	Delta Change	≖ 0.00
	Delta Check to Stop	= TRUE
	Test for end: CONTINUE	ITERATION
	Calculated Flow Broth (FT)	- 5.75
OUTPUT	Calculated Flow Depth (FT)	= 6.76

2.2.2. RUNOFF

RUNOFF

2.2.2.1. Introduction

RUNDFF is a spreadsheet developed to estimate the amount of runoff from most all watersheds in Iowa. The spreadsheet can be used to calculate runoff based on the "Iowa Runoff Chart" and the "Iowa Natural Resources Council Bulletin Number 11".

Input for the Iowa Runoff Chart consist of the drainage area and the land use factor (LF). For Bulletin 11, a person needs to input the drainage area, the Iowa hydrologic region in which the watershed is located, model number if the watershed is in Region I, and slope if the watershed is in Region I and Model 2 is used.

The output generated for both methods is the peak discharges for the 2-, 5-, 10-, 25-, 50-, 100-, and 500-year recurrence intervals for storms.

2.2.2.2. Using the Spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred into the spreadsheet, and then input the data into the spreadsheet. The data obtained in the field, from topographic maps, and engineering principles

can be transferred to an input form. Once this is done, a person can proceed to use the spreadsheet.

The first step in spreadsheet use is to load the master spreadsheet as a file from a disk drive to place it under the control of the Multiplan program. Assume the spreadsheet is stored on disk in the Normal Mode and is named RUNOFF.MP. Once the spreadsheet is loaded into the computer, enter the Multiplan command menu Options command and turn the Recalculation option OFF. Then enter the informative data in rows 13 through 16 (see Figure 27). This data includes the project number, project name, preparer, checker, and dates the project was prepared and checked.

Once the informative data are input, the user needs to enter the method to be used by the spreadsheet and the units of the drainage area as it is tabulated. The first choice the user must make is whether to use the Iowa Runoff Chart (input a number 1), Bulletin 11 (input a number 2), or both (input a number 3) to calculate the peak rate of runoff. The input for this choice is located in row 23, column 5 (see Figure 27). After the method(s) are chosen, the user must enter the units for the drainage area datum. If the area is to entered as square miles, put a number 1 in row 35, column 6 (see Figure 27). If the area is in acres, enter a number 2 in row 35, column 6. Once these two steps are complete, enter the Multiplan command for Options and turn

Recalculation ON. Wait until the computer has recalculated the spreadsheet, and then enter the drainage area in row 41, column 6 (see Figure 27).

2.2.2.3. Iowa Runoff Chart

If the user selects choice 1 or 3 in row 35, column 6 he or she can find the peak discharges using the Iowa Runoff Chart. The only datum the user needs to enter is the land use factor (LF) in row 67, column 2 (see Figure 27). The user can "unlock" cell R36C1 if he or she wishes to enter a description of the land use for later reference.

The values for LF can be found in one of three sources. These are: the original paper, Table 2, and by entering "IOWA" in the Goto Name command in the Multiplan command menu.

Table 2. Values for LF

· · · · · · · · · · · · · · · · · · ·	. * .	Lan	d Descrip	tion	$(\gamma_{i} \in \mathcal{X}^{1}) \rightarrow \dots$
Land Use	Very Hilly	Hilly	Rolling	Flat	Very Flat No Ponds
Mixed Cover Permanent Pasture Permanent Woods	1.00 0.60 0.30	0.80 0.50 0.25	0.60 0.40 0.20	0.40 0.20 0.10	0.20 0.10 0.05

Once the LF factor has been entered, the results for

several recurrence intervals are calculated. All the results are based on the equation for a direct calculation of a peak Q except the 2-year and the 500-year interval which are based on a linear regression equation developed from the other recurrence intervals.

If the user specifies using only the lowa Runoff Chart, the output data can be examined beginning in row 74, column 2. If Bulletin 11 output is also desired, then the user should now enter the data for this method of calculation. If only the Iowa Runoff Chart is to be used, the spreadsheet results should now be saved with a filename solely characteristic of the watershed, for later use and reference in design.

Since discharges are calculated by equations, there will always be results no matter what input is used. However, there are application limits to the variables. These limits are given in Table 3. If the drainage area or the LF factor does not fall within the specified limits, the output for the Iowa Runoff Chart will be suppressed. To warn users of problems with the input, special "flags" were included (see Figure 28).

2.2.2.4. Bulletin 11

If a value of 2 or 3 is entered in row 23, column 7, results from Bulletin 11 can be calculated. The data needed for Bulletin 11 may vary depending upon what part

of Iowa the drainage area is located, and whether the slope of the main channel can be calculated. The Bulletin 11 portion of the spreadsheet works better if the Recalculation option is ON at all times.

The segregation fo Iowa into regions for runoff analysis is depicted in Figure 27. The slashed area can be either in Region I or II. In the input box for "Region I(1) or II(2)" (in row 67, column 7), input either the number 1 for Region I or a number 2 for Region II (BE CERTAIN THAT THE RECALCULATION IS ON!). If Region II is used, the data inputs are complete. The results are then displayed beginning in row 74, columns 6 and 7.

If Region I contains the watershed, the spreadsheet will prompt the user for which model is to be used (row 68, column 7). Model 1 is to be used when a good determination of the main channel slope CANNOT be made, otherwise Model 2 is to be used. If Model 1 (input a number 1 when the spreadsheet prompts for selecting a model) is chosen, then the calculations will be complete at that point. The results may be reviewed beginning in row 74, column 6. If Model 2 is utilized, then one more item of information must be entered.

Once a number 2 is entered in response to "Model 1(1) or 2(2)" in row 68, column 7, the slope input will appear on the screen. The slope should be the 10/85 slope (refer to Bulletin 11, page 41, for the procedure to calculate the 10/85 slope) and it is input in feet per

mile. Once this item is entered, the computational results are again found in row 74, columns 6 and 7.

The output for this method includes an estimation for the 500-year storm. This value is based on a linear regression equation calculated from the other recurrence intervals. If the user is satisfied with the results, the spreadsheet should be saved on disk under a unique name for later reference.

As was the case with the Iowa Runoff Chart, limits are needed on the variables so that the equations are not misused. These limits are given in Table 3. If these limits are exceeded the spreadsheet will not display the output data for Bulletin 11 (except errors in the slope). If an error occurs, the user is warned and should then make the necessary adjustments (Figure 28 illustrates the error messages).

2.2.2.5. Rounding the Output

The output can be set to be rounded to a specified precision. The output data are broken into two sets. The first set consists of output values less than 1000. The second set consists of those values greater than or equal to 1000. The cells that contain the location for entering the rounding limits are located to the right of the final peak discharge output beginning in cell R74C11 and ending in cell R80C17.

The user specifies the range for rounding by entering a specific value in row 78, column 12 for number less than 1000 and row 79, column 12 for values greater than or equal to 1000. The following values can be entered:

O for integer result,

-1 for rounding to tens,

-2 for rounding to hundreds, etc.

For example, if the calculated runoff was 4215.6 cfs, then a value of 0 would cause the output to report 4216 cfs, a value of -1 would result in an output of 4220 cfs, a value of -2 would yield an output of 4200 cfs, and a value of -3 would produce an output of 4000 cfs. It is recommended that a value of -1 be used for output of less than 1000 cfs and a value of -2 be entered for output greater than or equal to 1000 cfs.

Table 3. Limits on variables for RUNOFF

Var	i	a	b	1	e
-----	---	---	---	---	---

Range of values

Iowa Runoff Chart
 Recurrence intervals (years) 2*, 5, 10, 25, 50, 100, or 500*
 Area (acres)
 LF (unitless) 2*, 5, 10, 25, 50, 100, or 500*
 1 <= area <= 70,000
 0.05 <= LF <= 1.00
Bulletin 11
 Recurrence intervals (years)
 Area (square miles)
 10/85 Slope (ft/mi) 2, 5, 10, 25, 50, 100, or 500*
 2 <= area <= 14,038
 1 <= slope <= 100</pre>

* Estimated by linear regression

127

1.13

2.2.2.6. Example Problem

One item that may concern or confuse the user is the numbers remaining in the spreadsheet from previous calculations. The best way to demonstrate this problem is by the following application example.

A culvert is to be constructed under a county highway in central Iowa. The drainage area is totally permanent pasture and is located in Story County (therefore, it is Region I or Region II) and has topography that can be described as rollling. The design storm is 50 years; the major storm is 100 years; the area is 10,000 acres (15.625 square miles); and the slope of the main channel is 9 feet per mile. Check the runoff for both Bulletin 11 and for the Iowa Runoff Chart.

Since the location of the watershed is in Region I and the slope of the main stream is known, Region I Model 2 is used for Bulletin 11. The data are first entered on an input form. An example of the input form is shown in Figure 30.

The completed spreadsheet is shown in Figure 31. After this computation, the user desired to check Region II results against those already calculated. Since the values for the Iowa Runoff Chart were already calculated, only Bulletin 11 data were input.

The number 2 is input in the cell to change the spreadsheet to output only data for Bulletin 11. Once this task is complete, the recalculation takes place. When the recalculation is complete, the number 2 is entered into the cell that contains the "region option". The results of this computation are shown in Figure 32.

The user can now see the extra values in the cells below where the region option is entered for Bulletin 11, and to the left of these cells, input leftover from applying the Iowa Runoff Chart. These data are from the previous computation using Bulletin 11 and the Iowa Runoff Chart. The numbers have no effect on the computational results (compare the results shown in Figures 32 and 33), but are a bit confusing as a person views the spreadsheet. To correct this confusion, a user needs to move the cell pointer to the cells in the spreadsheet containing the "extra or unnecessary" values and blank them out with the Blank command from the Multiplan menu. Figure 33 illustrates the spreadsheet after the "leftover" data are blanked out.

The results from the spreadsheet indicate that if the lowa Runoff Chart is used to calculate the runoff, the design discharge is 1100 cfs and the major discharge is 1300 cfs. For Bulletin 11, Region II Model 2, the values are 3700 cfs for the design runoff and 4700 cfs for the major storm. And finally, for Bulletin 11, Region II the results are 1000 cfs for the design storm and 1200 cfs

for the major storm.

. . Figure 27. Location of Input Data for RUNOFF

5 2 Э 4 7 8 6 RUNDEE 11 3、日本家父亲和客意来我的事务就的需要我的事实在非常的事实是要我就要我的事实是要我来来我不能是不要要要我在我们都是要要要我有不能要这些事实是不能不能 4 5 4. ć, + Nultiplan Microcomputer Spreadsheets for County Hydraulic and Highway Engineering Computations •7 . - 🍋 ខ Copyright by Rocky J. Keehn 4. + 9 Version 3.0 + 1986 1.0 ŀ 11 111 13 Project Number:1 14 Project Name :Example Problem 15 Prepared By :Rocky J. Keehn 16 Checked Dy :Rocky J. Keehn Date:11-15-86 Date:11-15-86 16 Checked Dy 17 18 -----19 INFUT En vorme **************** METHOD USED TO CALCULATE RUNOFF 21 + 32 + 23 Choose one from below (1-3) ---> + 3 + <u>2</u>:4 -1 - Iowa Runoff Chart 25 2 - Bulletin No. 11 3 - both methods 26 + 27 + + 28 TO GET HELP ~~~~~~~~~ 1202 4 For both methods 30 Goto IOWA OR BULL11 21 зiг UNITS USED WHEN INPUTTING THE AREA эЭ :34 Choose 1 or 2 ----> 35 2 1 - square miles 36 2 - acres 37 38 39 INPUT THE AREA ~~~~~~~~~~~~~~~~ 40 41 4.10 43 41 45 46 47 --- Helpful Output ----Area ----->109.375 sq mi 48 49 SO ******************** 51 57 ------53 RESULTS 54 ****** 56 Project Number:1 57 Project Name :Example Problem 58 Prepared By :Rocky J. Keehn 59 Checked By :Rocky J. Keehn Date:11-15-86 Date:11-15-86 60 6 Please input ---5 Ð 7 - 6 es és ---- Please input ----1 67 LF -----1 Region I(1) OR II(2) -> Model 1(1) OR 2(2) ---> 2 10/85 slope (ft/mi) --> 100 69 2 09 Goto LF FOR HELP *70 21 72 74
38 INPUT THE AREA 39 40 41 Area ----> 15001 sg mi 42 43 + NOTE: AREA TOO LARGE TO USE IOWA RUNOFF CHART 44 45 NOTE: AREA TOO LARGE TO USE BULLETIN 11 46 47 --- Helpful Output ---Area ----> 15001 sg mi 48 49 50 ***** 7 1 2 3 5 6 8 19 INPUT 20 *************** METHOD USED TO CALCULATE RUNOFF 21 22 Choose one from below (1-3) ---> 23 24 1 - Iowa Runoff Chart 2 - Bulletin No. 11 25 26 3 - both methods 27 28 TO GET HELP 29 30 ERROR - method used number incorrect+ 31 or area out-of-range ÷ 32 UNITS USED WHEN INPUTTING THE AREA 33 \mathbb{C}^{n} 34 Choose 1 or 2 ----> 35 2 36 1 - square miles 2 - acres 37 38 INPUT THE AREA 39 40 Area 41 1 acres 42 43 + NOTE: AREA TOO SMALL TO USE IOWA RUNOFF CHART 44 45 + NOTE: AREA TOO SMALL TO USE BULLETIN 11 46 47 --- Helpful Output ---48 Area ----->0.00156 sg mi 49 50 **************** 61 65 66 --- Please input ------ Please input ---67 LF ----> 0.04 Region I(1) OR II(2) -> 1 68 Model 1(1) OR 2(2) ---> 2 69 *** ERROR *** 10/85 slope (ft/mi) --> 101 *** POSSIBLE ERROR *** 70 LF incorrect-Help at Goto LF Check your Region number, Model number, or slope value 71 72 73 *** PEAK DISCHARGES *** 74 75 IOWA RUNOFF CHART BULLETIN 11 76 77 NOT USED ----> 2100 cfs 02 78 Q5 · -----> 3900 cfs Q10 ----> Q25 ----> Q50 ----> 79 5200 cfs 7000 cfs 80 81 8400 cfs 82 Q100 ----> 9900 cfs



Figure 29. Hydrologic Regions of Iowa

Figure 30. Input Form for RUNOFF

INPUT FORM -	For RUNOFF
Project Numb)er:
Project Name	· · · · · · · · · · · · · · · · · · ·
Prepared By	: Date:
Checked By	: Date:
******	*******************************
METHOD: 1 =	Iowa Runoff Chart, 2 = Bulletin 11, or 3 = Both
	(Circle) 1, 2 or 3
****	*****************************
AREA: Uni	ts 1 = square miles, 2 = acres; (Circle) 1 or 2
	Area
*****	*******************************
METHOD 1:	1 - Iowa Runoff Chart
INPUT DATA:	Land use (optional)
	Topography (optional)
	LF> unitless
****	****************************
METHOD 2:	2 - Bulletin 11 (Circle one)
INPUT DATA:	Region I (1) or II (2)> 1 or 2
	Model 1 or 2 (if Region is I)> 1 or 2
	Slope (if Model is 2)> ft/mi

Figure 31. RUNOFF Completed

2 3 1 5 6 7 8 19 INPUT 20 ************** 21 METHOD USED TO CALCULATE RUNOFF 22 Chocse one from below (1-3) ---> 1 - Iowa Runoff Chart 23 3 24 2 - Bulletin No. 11 25 26 3 - both methods 27 + TO GET HELP 28 4 29 30 For both methods Goto IOWA OR BULL11 31 32 UNITS USED WHEN INPUTTING THE AREA 33 34 Choose 1 or 2 -----> 35 2 1 - square miles 2 - acres 36 37 38 INPUT THE AREA 39 40 41 Area ----> 10000 acres 42 43 44 45 46 47 --- Helpful Output ---Area -----> 15,625 sg mi 48 49 50 51 52 -53 RESULTS 54 55 · · · · · · · 56 Project Number:1 57 Project Name :Example Problem 58 Prepared By :Rocky J. Keehn 59 Checked By :Rocky J. Keehn Date:11-15-86 Date:11-15-86 60 61 62 *** IOWA RUNOFF CHART *** *** BULLETIN 11 *** 63 --- Helpful Output ---64 Area (acres) > 10000 --- Helpful Output ---Area (sq m1) -----> 15.625 65 66 --- Please input ------ Please input ----67 LF ----> 0.2 Region I(1) OR II(2) -> 1 68 Rolling pasture land 69 Goto LF FOR HELP Model 1(1) OR 2(2) ---> 2 10/85 slope (ft/mi) --> 9 70 71 72 *** PEAK DISCHARGES *** 73 IOWA RUNOFF CHART BULLETIN 11 74 360 cfs* 75 02 --> 02 ----> 630 cfs 76 Q5 --> 560 cfs 05 ----> 1300 cfs 77 010 --> 780 cfs Q10 ----> 1900 cfs 890 cfs 78 Q25 Q25 --> ----> 2900 cfs 79 Q50 --> ----> 1100 cfs Q50 3700 cfs 80 Q100 --> 1300 cfs Q100 ----> 4700 cfs 81 2500 --> 1800 cfs* Q500 ----> 7800 cfs* 82 * estimated by linear regression - 1

Figure 32. Leftover Input in RUNOFF

83 ----7 2 3 1 5 6 19 INPUT 20 ************** METHOD USED TO CALCULATE RUNOFF 21 22 23 Choose one from below (1-3) ---> 2 24 1 - Iowa Runoff Chart 25 2 - Bulletin No. 11 26 3 - both methods 27 * * * * * * * * * * * * * * * * 28 TO GET HELP 29 30 For Bulletin No. 11 31 32 33 34 35 Choose 1 or 2 -----> 2 1 - square miles 36 37 2 - acres 38 INPUT THE AREA 39 40 41 Area ----> 10000 acres 42 43 44 45 46 --- Helpful Output ---47 48 Area ----> 15.625 sq mi 49 50 51 52 53 RESULTS 54 55 * * * * * * * * * * * * * * * * * + * * * * * * * 56 Project Number:1 57 Project Name :Example Problem 58 Prepared By :Rocky J. Keehn 59 Checked By :Rocky J. Keehn Date:11-15-86 59 Checked By Date:11-15-86 60 61 * * * * * * * * * * * * * * * 62 *** BULLETIN 11 *** --- Helpful Output ---63 64 Area (sg mi) ----> 15.625 65 66 --- Please input ---67 Region I(1) OR II(2) \rightarrow 0.2 2 68 Rolling pasture land 2 69 9 70 71 72 73 *** PEAK DISCHARGES *** IOWA RUNOFF CHART BULLETIN 11 74 75 NOT USED Q2 ----> 270 cfs 76 Q5 ----> 480 cfs 77 ----> Q10 650 cfs 78 ----> Q25 870 cfs 79 Q50 ----> 1000 cfs 80 0100 ----> 1200 cfs 81 Q500 ----> 1800 cfs* 82 * estimated by linear regression

Figure 33. RUNOFF Example - Bulletin 11, Region II

2 5 6 7 8 1 3 4 19 INPUT 20 ******************* 21 METHOD USED TO CALCULATE RUNOFF 22 Choose one from below (1-3) ---> 1 - Iowa Runoff Chart 23 + 2 24 ٠ 2 - Bulletin No. 11 25 26 3 - both methods 27 * * * * * * * * * * * * * * * TO GET HELP 28 ٠ 29 30 For Bulletin No. 11 4 31 Goto BULL11 UNITS USED WHEN INPUTTING THE AREA 32 - + 33 ٠ 34 35 Choose 1 or 2 -----> 2 36 1 - square miles 37 2 - acres38 39 INPUT THE AREA 40 41 Area -----> 10000 acres 42 43 44 45 46 47 --- Helpful Output ---48 Area ----> 15.625 sq mi 49 50 ************** 51 52 53 RESULTS 54 + + + + + + + + 57 Project Name :Example Problem 58 Prepared By :Rocky J. Keehn Date:11-15-86 Rocky J. Keehn Date:11-15-86 59 Checked By 60 61 * * * * * * * * * * * * * * * 62 *** BULLETIN 11 *** 63 --- Helpful Output ---Area (sq mi) ----> 15.625 64 65 --- Please input ---Region I(1) OR II(2) -> 66 67 2 68 69 70 71 72 *** PEAK DISCHARGES *** 73 IOWA RUNOFF CHART BULLETIN 11 74 75 NOT USED Q2 ----> 270 cfs 76 Q5 ----> 480 cfs 77 Q10 ---> 650 cfs 78 025 ----> 870 cfs 79 050 1000 cfs ----> 80 0100 ----> 1200 cfs 81 Q500 ----> 1800 cfs* 82 * estimated by linear regression

2.2.3. WSGEOM

WSGEOM

WATER SURFACE PROFILE OPEN CHANNEL TRAPEZOIDAL SECTION

2.2.3.1. Introduction

The "Water Surface Frofile - Open Channel Trapezoidal Section" spreadsheet was developed to calculate the water depth along a section of a trapezoidal channel. This type of channel is typically located along a section of highway to drain water from the roadway and adjacent land.

This spreadsheet is very useful in answering "What if?" questions in regard to modifying the channel located next to the road. Various bottom widths, channel slopes, foreslopes and backslopes can be tried to obtain the optimal design.

The input consists of the water elevation at the last downstream cross-section (usually the design headwater depth at a culvert), design flow, channel bottom elevation at the last downstream cross-section, the energy coefficient, and cross-section data for up to 20 cross-sections. For each cross-section, a person needs to input the distance from the starting station, the width of the ditch bottom, foreslope, backslope, ditch or

channel slope, and Manning's roughness coefficient.

Once the data are input, the user must then iterate the water surface elevation at each cross-section. This is done by entering a trial depth, checking whether or not it is an acceptable value, if not, input a new elevation and recalculate at that station. If the trial depth is acceptable, then proceed to the next station for further calculation. The program contains a cell that informs the user whether to increase or decrease the elevation. A check value is also output for each iteration. This check value should approach 0,001 as the iterations are performed (seeking convergence).

Once all the cross-sections' water elevations have been interated by the user, the final output can be printed. Included in the output data are the channel bottom elevation, water surface elevation, energy line elevation, water depth, and friction loss. From this data, a water surface profile can be drawn and the water depths caused by the headwater can be observed. If the user has Microsoft Chart which is a companion software package to Microsoft Multiplan, this spreadsheet can be used as an input file to Chart and plot the water surface profile directly to the computer monitor screen or dump it out to a dot-matrix printer.

2.2.3.2. Using the Spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred into the spreadsheet, and then input the data into the spreadsheet. The data obtained in the field, from topographic maps, and engineering principles can be transferred to an input form. Once this is finished, a user can begin to apply the spreadsheet.

The first step is to load the master spreadsheet file from the disk. It is assumed for discussion purposes here that the file is stored on disk in Normal Mode and is named WSGEOM.MP. Once the file has been loaded into the computer memory operating under the control of the Multiplan program, select the Options command from the Multiplan menu and turn the Recalculation OFF. Next enter the project number, project name, preparer, checker, and dates prepared and checked. These are located in rows 12-15 (see Figure 34). Once these entrie have been made, the constant variables in column 8, rows 21-24 (see Figure 34) are entered. These constant values should pertain to cross-section number 1 (the last downstream cross-section where the initial water depth is known). Typically, this initial water depth will be the headwater depth calculated during the analysis of a culvert or bridge located at this cross-section. Values for the energy coefficient, entered in row 22, column 8 (see Figure 34), are given in Table 4.

141

2

5.

 $\mathcal{Y}^{(2)}$

Table 4. Various values for the energy coefficient

(according to finding of Chow, 1959)

Value o Channels	Value of the energy coeefi									
	Minimum	Average	Maximum							
Regular channels, flumes, spillways	1.10	1.15	1.20							
Natural streams, and torrents	1.15	1.30	1.50							
Rivers under ice cover	1.20	1.50	2.00							
River valleys, overflooded	1.50	1.75	2.00							

The next step is to enter the data for each cross-section. The maximum number of cross-sections is 20. The station distance from the starting cross-section should be entered in feet, not in stations. The ditch bottom width, foreslope, backslope, and Manning's roughness coefficient should be values that are associated with the cross-section under calculation consideration at the moment. The foreslope is the slope from the ditch bottom to the edge of the roadway shoulder. The backslope is the slope from the ditch bottom to the intercepted natural ground surface near the outer right of way boundary. The backslope and foreslope are entered as Z, where Z is the horizontal distance in the slope ration Z:1 (see Figure 35). The ditch slope is the average slope of the channel from the previous station cross-section to the current station

cross-section in feet per feet. For the initial station, enter the average slope at that station between an upstream and downstream location.

The six variables for each cross-section are entered in rows 31 through 36, beginning in column 8 for cross-section 1 and ending in column 31 for cross-section 20 (excluding columns 9, 11, 13, and 15). (Refer to Figure 36 which shows the template for cross-sections 1, 2, 3, and 4.) A person does not need to enter all 20 cross-sections for the spreadsheet to work. Once the cross-section data are entered, the user may begin iterating the water surface elevations. BEFORE BEGINNING THE ITERATIONS, ENTER THE MULTIPLAN COMMAND Options TO TURN Recalculation ON.

The water surface elevation for the first cross-section is automatically transferred from the constant variable previously entered in row 24, column 8 (see Figure 34). The user then begins the iteration process at cross-section 2. A person enters a trial depth in row 42, column 10 (see Figure 34). This depth should be slightly greater than the initial water surface elevation in column 8. Once a depth is entered, a "(+)" or a "(-)" will appear in row 46 below the water surface elevation number just entered. If it is a "(+)", then the water surface elevation should be INCREASED; if the spreadsheet displays a "(-)", then the water surface elevation should be decreased.

The method for finding the water surface is based on the standard step method presented by Chow (1959). This method utilizes the fact that the total head at the current cross-section is equal to the total head at the previous cross-section plus the friction head plus the eddy losses. For convenience of computation, the eddy losses can be considered part of the friction losses (Chow, 1959). The check value in row 47 is the difference between the total head at the current s cross-section and the total head plus the friction loss at the previous cross-section. As the check value becomes smaller, the precision of the method increases. For this spreadsheet, the recommended precision is such that the value in row 47 became 0.000.

Once the water surface depth is at a desirable precision, the user is to continue to cross-section 2 (row 42, column 12) and repeat the process. The user continues until all the cross-sections have been completed. USERS ARE TO REMEMBER THAT DATA CANNOT BE ENTERED IN COLUMNS 9, 11, 13, AND 15 IN ROW 42.

Once all the cross-sections have been entered, the output data can be reviewed in rows 69 through 96. The user can "jump" to this location within the spreadsheet by selecting the Goto command from the Multiplan command menu. The procedure is to select "Goto", then select the "Name" subcommand, then enter the word OUTPUT, and press the <return> key or the <enter> key. This will jump the

spreadsheet control directly to the output area.

At this time the spreadsheet should be saved for later revision and editing.

2.2.3.3. Example Problem

Figure 37 show a road section with a culvert located at station 0 + 00. The calculated headwater depth for the 50-year storm is five feet. The discharge in the ditch for this recurrence interval was 400 cfs. The road elevation at the culvert is 605.4 feet. The road elevation dips to 605.2 feet at station 6^{+} 79, which is located upstream from the culvert. In addition to stations 0 + 00 and 6 + 79, data were collected for stations 1 + 55, 3 + 18, and 4 + 19. It was concluded that the channel is constructed such that the Z value for foreslope and backslope is 2; the ditch bottom is 20 feet; the channel slope is a constant 0.0016 feet per feet; and Manning's n is 0.025. These values pertain to all stations. The question is: Will the water flow over the road at station 6 + 79?

From the data given above, the input forms for the spreadsheet were completed using forms like those shown in Figure 38 and 39. Iteration and Recalculation were switched OFF by using the Multiplan command menu choice of Options. From an input form, the spreadsheet was filled in starting with lines 12 through 15; then lines

21 through 24 were completed (the energy coefficient was assumed to be 1.1). Finally, the cross-section data were entered in lines 31 through 36 starting in column 8. Figure 40 depicts the input template for this example problem.

Dnce the initial input was recorded, the Iteration and Recalculation functions were turned back ON. Following the closure of recalculation, an input is needed for row 42, column 10. This is the iteration cell to get the get the water surface elevation at cross-section 2. The iteration continued at this cross-section until the check value reached 0.000. Once this cross-section was complete, cross-section 3 was iterated; then cross-section 4; and finally, cross-section 5.

The output (see Figure 41) shows that the water surface elevation at cross-section 5 is 605.29 feet which is 0.09 feet above the road surface. To correct the problem, the engineer may decide to change the Z value in the foreslope and backslope to 1.0, and to change the ditch bottom to 30 feet. If these changes are made in the spreadsheet, the computational results would be those shown in Figure 42. The new water surface elevation at cross-section 5 would be 605.18 feet, which is 0.02 feet below the elevation of the road.

2.2.3.4. References

Chow, Ven Te, <u>Open-Channel Hydraulics</u>, McGraw-Hill, Inc., New York, 1959, pp. 27-28, 249-289.

147 *

1.4

Figure 34. Input Template for WSGEOM (Part 1)

10 2 З 5 8 9 1 4 6 7 WATER SURFACE PROFILE - OPEN CHANNEL TRAPEZOIDAL SECTION 2 ************************************** 4 5 Multiplan Microcomputer Spreadsheets for County + Hydraulic and Highway Engineering Computations 6 + 7 Copyright by Rocky J. Keehn 4 8 Version 1.0 9 July, 1986 10 **** 11 12 Project Number 2 13 Project Name 2 Date: 14 Prepared By Date: 15 Checked By 16 17 18 INPUT - constant varibles ,**ຎຎຎຎຎຎຎຎຎຎຎຎຎຎຎຎ**ຎ 19 20 Elevation at 21 initial ditch bottom feet 22 Energy coefficient 23 Design Flow cfs 24 Starting water depth elevation= feet 25



21 The section data 28 CROSS-SECTIONS> 1 2 3 4 29 Station distance from = 3 5 4 30 Station distance from = 3 5 5 5 31 starting point (feet) = - - - - - 31 starting point (feet) = -	75	1	2	3	4	5	6	7	8	9	10	11	12	13	14
28 CROSS-SECTIONS> 1 2 3 4 29 30 Station distance from 31 starting point (feet) = 32 3 5 31 starting point (feet) = 33 Foreslope (ft:1) = 3 3 5 7 32 Ditch bottom (ft) = 1 2 3 4 33 Foreslope (ft:1) = 1 2 3 4 34 Dackslope (ft:ft) = 1 2 3 4 35 Ditch Stotke (ft) = 1 2 3 4 36 Hanning's n = = 3 - 4 37	25 26	INPUT - Cr	055-5 2 C	tion da	ta										
27 30 Station distance from 31 starting point (feek) = 32 Ditch bottom (ft) = 33 Foreslope (ft:1) = 34 Backslope (ft:1) = 35 Ditch Slope (ft:1) = 36 Maning's n = 37	28			CROS5-	SECT	lons	>)	a 1			2	:	3	4
31 Stating point (feet) = 32 Ditch bottom (ft) = 33 Foreslope (ft:1) = 34 Backslope (ft:1) = 35 Ditch Slope (ft/ft) = 36 Manning's n = 37	29		******	dict											÷
Starting point (term - 32 Ditch bottem (ft) = 33 Foreslope (ft:1) = 34 Backslope (ft:1) = 35 Ditch Slope (ft/ft) = 36 Manning's n = 37	21		ets station	ulaidu rtina a	168 11 Aist	(fee	F1								
22 Ditch Dotes (ft:1) = 33 Foreslope (ft:1) = 34 Backslope (ft:1) = 35 Ditch Slope (ft:1) = 36 Manning's n = 37	22	1	368 Aitch h	otton (443	1144	•/		2						
36 Dotslope (ft:1) = 37 Ditch Slope (ft:1) = 35 Ditch Slope (ft:1) = 36 Maning's n = 37	22	5	Toracla	na (ft:	11				1						
35 Ditch Stope (ft/ft) = 36 Manning's n 37	24		Rackelo	na (ft:	ñ			2	1	•					
35 Manning's n = 37	37 75		litch C	long (1	** */{t1			3							
30 31 38 INPUT - Self-interation 39 41 41 +> Input yourself ++ 42 Water surface elevation (FT) = 0 43 ++ 44 ++ 45 Increase (+) or decrease (-) 46 Water surface elevation (FT) = 0 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! #VALUE! 49	36		lanning	te n	•• ••	r		#							
33 INPUT - Self-interation 39 CROSS-SECTIONS> 1 2 3 4 41 ++ Input yourself ++ 42 Water surface elevation (FT) = 0 43 ++ Helpful Dutput ++ 5 Increase (+) or decrease (-) 45 Water surface elev. = start at #VALUE! #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! 48	37	*				5 0w (39 4 1 0 4 1 0			****						**
39 40 CRDSS-SECTIONS> 1 2 3 4 41 ++ Input yourself ++ 4 4 4 ++ Helpful Output ++ 4 42 Water surface elevation (FT) = 0 6 6 6 44 ++ Helpful Output ++ 4 5 Increase (+) or decrease (-) 46 46 Water surface elev. = start at \$VALUE! \$VALUE! \$VALUE! \$VALUE! 47 Check value (ok if (= +/001)= X-section 2 \$VALUE! \$VALUE! \$VALUE! 49	38	INPUT - Sel	f-inte	ration											
40 CRDSS-SECTIONS> 1 2 3 4 41 ++ input yourself ++ 42 Water surface elevation (FT) = 0 0 43 ++ Helpful Output ++ 0 0 0 45 increase (+) or decrease (->) 46 Water surface elev. = start at \$VALUE! \$VALUE! \$VALUE! \$VALUE! 47 Check value (ok if (= +/001)= X-section 2 \$VALUE! \$VALUE! \$VALUE! 49	39	******	*****	****			. '								
<pre>41 ++ Input yourself ++ 42 Water surface elevation (FT) = 0 43 44 ++ Helpful Output ++ 45 Increase (+) or decrease (-) 46 Water surface elev. = start at @VALUE! @VALUE! @VALUE! 47 Check value (ok if (= +/001)= X-section 2 @VALUE! @VALUE! @VALUE! 48 49</pre>	40			CROSS-	SECTI	IONS		>	1			2	2	3	4
42 Water surface elevation (FT) = 0 43 ++ Helpful Output ++ 45 Increase (+) or decrease (-) 46 Water surface elev. = start at #VALUE! #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! #VALUE! 49	41	44 Inc	at vou	rself +	+				•			-		-	•
43 44 ++ Helpful Dutput ++ 45 Increase (+) or decrease (-) 46 Water surface elev. = start at #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! 49	42		later s	urface	eleva	tion	(FT)	. =	0						
44 ++ Helpful Dutput ++ 45 Increase (+) or decrease (-) 46 Water surface elev. = start at #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= I-section 2 #VALUE! #VALUE! #VALUE! 48 49 50 CALCULATIONS 51 ************************************	43	-													
45 Increase (+) or decrease (-) 46 Water surface elev. = start at #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! 48 49 50 CALCULATIONS 51 52 52 Delta X (FT) = 0.000 0.000 0.000 53 Length \$ Slope (FT) = 0.000 0.000 0.000 54 Accumitative channel rise = 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha \$ V^2 / 2g #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 61 <t< td=""><td>44</td><td>++ He)</td><td>oful D</td><td>utout +</td><td>+</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	44	++ He)	oful D	utout +	+										
46 Water surface elev. = start at #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! #VALUE! #VALUE! 48	45	1	ncreas	e (+) o	r dec	7025	e (~)	i							
47 Check value (ok if (= +/001)= X-section 2 #VALUE! #VALUE! <t< td=""><td>46</td><td></td><td>Wa</td><td>ter sur</td><td>face</td><td>elev</td><td>•</td><td>#</td><td>start a</td><td>t</td><td>#VALUE!</td><td></td><td>#VALUE!</td><td></td><td>#VALUE!</td></t<>	46		Wa	ter sur	face	elev	•	#	start a	t	#VALUE!		#VALUE!		#VALUE!
48 50 CALCULATIONS 51 51 52 Delta X (FT) = 0.000 0.000 0.000 53 Length X Slope (FT) = 0.000 0.000 0.000 54 Accumlative channel rise = 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (S0 FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha # V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 = #VALUE! #VALUE! #VAL	47	Ċ	heck v	alue (o	k if	(= +	/00	1)=	X-section	n 2	AVALUE!		#VALUE!		VALUE!
49 50 CALCULATIONS 51 ************************************	48										·				
50 CALCULATIONS 51 52 Delta X (FT) 53 Length \$ Slope (FT) 54 Accumative channel rise 55 Calculated Flow Depth (FT) 55 Calculated Flow Depth (FT) 56 Flow Area (S0 FT) 57 Wetted Perimeter (FT) 59 Calculated Velocity (FPS) 59 Calculated Velocity (FPS) 51 Hi elevation (FT) 52 Hydraulic Radius ^ 4/3 53 Friction Slope, Sf 54 Average Sf 55 Friction head loss, hf (FT) 56 Friction fer) 57 Wetted Perimeter (FT) 58 Hydraulic Radius (FT) 59 Calculated Velocity (FPS) 50 alpha \$ V^2 / 2g 51 Hi elevation (FT) 52 Hydraulic Radius ^ 4/3 53 Friction Slope, Sf 54 Average Sf 55 Friction head loss, hf (FT) 56 H2 elevation (FT) 57 WALUE! 58 Friction head loss, hf (FT) <td>49</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>****</td> <td></td> <td>****</td> <td></td> <td></td> <td></td> <td>دور خون خان الله الله الله الله الله الله الله ال</td> <td></td> <td></td>	49						****		****				دور خون خان الله الله الله الله الله الله الله ال		
51 Delta X (FT) = 0.000 0.000 0.000 0.000 53 Length X Slope (FT) = 0.000 0.000 0.000 0.000 54 Accumative channel rise = 0 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 0.000 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 0.000 56 Flow Area (SD FT) = 0.000 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha X V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 <t< td=""><td>50</td><td>CALCULATION</td><td>IS</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	50	CALCULATION	IS												
52- Delta X (FT) = 0.000 0.000 0.000 0.000 53 Length X Slope (FT) = 0.000 0.000 0.000 0.000 54 Accumlative channel rise = 0 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 0.000 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha 1 V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! #VALUE!	51	******	1 %												
53 Length # Slope (FT) = 0.000 0.000 0.000 54 Accumiative channel rise = 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha # V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 63 Friction Slope, Sf =	52-	D	elta X	(F1)				3	0.000		0.00	0	0.000)	0.000
54 Accumiative channel rise = 0 0 0 0 55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha \$ V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 = #VALUE! #VALUE! #VALUE! #VALUE! 63 Friction Slope, Sf = #VALUE! #VALUE! #VALUE! #VALUE! 64 Average Sf = 0.000000 #VALUE! #VALUE! #VALUE! 65 Friction head loss, hf (FT) =<	53	1	ength \$	\$ Slope	(FT)			Ħ	0.000		0.00	0	0.000)	0.000
55 Calculated Flow Depth (FT) = 0.000 0.000 0.000 0.000 56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha \$ V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 = #VALUE! #VALUE! #VALUE! #VALUE! 63 Friction Slope, Sf = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 64 Average Sf = 0.000000 #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 65 Friction head loss, hf (FT) = 0.000000 #VALUE! #VALUE! #VALUE!<	54	A	ccublat	tive ch	annel	ris	ŧ	=	0		I	0	0)	0
56 Flow Area (SQ FT) = 0.000 0.000 0.000 0.000 57 Wetted Perimeter (FT) = 0.000 0.000 0.000 0.000 58 Hydraulic Radius (FT) = 0.000 0.000 0.000 0.000 59 Calculated Velocity (FPS) = #DIV/0! #DIV/0! #DIV/0! #DIV/0! 60 alpha \$ V^2 / 2g = #VALUE! #VALUE! #VALUE! #VALUE! 61 H1 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! 62 Hydraulic Radius ^ 4/3 = #VALUE! #VALUE! #VALUE! #VALUE! 63 Friction Slope, Sf = #O.000000 #VALUE! #VALUE! #VALUE! 64 Average Sf = 0.000000 #VALUE! #VALUE! #VALUE! 65 Friction head loss, hf (FT) = 0.000000 #VALUE! #VALUE! #VALUE! 66 H2 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! #VALUE! 67	55	Ċ	alcula	ted Flo	v Dep	th (FT)		0.000		0.00	0	0.000)	0.000
57Wetted Perimeter (FT)=0.0000.0000.0000.00058Hydraulic Radius (FT)=#DIV/0!#DIV/0!#DIV/0!#DIV/0!#DIV/0!59Calculated Velocity (FPS)=#DIV/0!#DIV/0!#DIV/0!#DIV/0!#DIV/0!60alpha $\ddagger V^2 / 2g$ =#VALUE!#VALUE!#VALUE!#VALUE!#VALUE!51H1 elevation (FT)=#VALUE!#VALUE!#VALUE!#VALUE!62Hydraulic Radius ^ 4/3=#VALUE!#VALUE!#VALUE!#VALUE!63Friction Slope, Sf=#VALUE!#VALUE!#VALUE!#VALUE!64Average Sf=0.000000#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)=0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)=#VALUE!#VALUE!#VALUE!#VALUE!67	56	F	lov Ar	ea (SQ	FT)			15	0.000		0.00	0	0.000)	0.000
58Hydraulic Radius (FT)= #DIV/0!#DIV/0!#DIV/0!#DIV/0!59Calculated Velocity (FPS)= #DIV/0!#DIV/0!#DIV/0!#DIV/0!#DIV/0!60alpha # V^2 / 2g= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!51H1 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!62Hydraulic Radius ^ 4/3= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!63Friction Slope, Sf= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!64Average Sf= 0.000000#VALUE!#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)= 0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!67	57	l l	etted f	Perimet	er (F	T)		2	0.000		0.00	0	0.000)	0.000
59Calculated Velocity (FPS)= #DIV/0!#DIV/0!#DIV/0!#DIV/0!60alpha \$ V^2 / 2g= #VALUE!#VALUE!#VALUE!#VALUE!61H1 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!62Hydraulic Radius ^ 4/3= #VALUE!#VALUE!#VALUE!#VALUE!63Friction Slope, Sf= #VALUE!#VALUE!#VALUE!#VALUE!64Average Sf= 0.000000#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)= 0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!67	58	H	lydraul i	ic Radi	us (F	T)		æ	#DIV/0!	e.	#DIV/0!		#DIV/01		#DIV/0!
60alpha # V^2 / 2g= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!51H1 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!62Hydraulic Radius ^ 4/3= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!63Friction Slope, Sf= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!64Average Sf= 0.000000#VALUE!#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)= 0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!67	59	C	alcula	ted Vel	ocity	(FP	S)	2	#DIV/0!		#DIV/0!		#DIV/0!		#DIV/0!
51H1 elevation (FT)=#VALUE! <th< td=""><td>60</td><td>2</td><td>lpha 🔱</td><td>V^2 /</td><td>2g</td><td></td><td></td><td>=</td><td>#VALUE!</td><td></td><td>#VALUE!</td><td></td><td>#VALUE!</td><td></td><td>#VALUE!</td></th<>	60	2	lpha 🔱	V^2 /	2g			=	#VALUE!		#VALUE!		#VALUE!		#VALUE!
62Hydraulic Radius ^ 4/3= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!63Friction Slope, Sf= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!64Average Sf= 0.000000#VALUE!#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)= 0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!67	61	н	1 eleva	ation (FT)			3	#VALUE!		#VALUE!		AVALUE!		#VALUE!
53Friction Slope, Sf= #VALUE!#VALUE!#VALUE!#VALUE!#VALUE!54Average Sf= 0.000000#VALUE!#VALUE!#VALUE!#VALUE!65Friction head loss, hf (FT)= 0.000000#VALUE!#VALUE!#VALUE!66H2 elevation (FT)= #VALUE!#VALUE!#VALUE!#VALUE!57	62	H	lydrauli	ic Radi	us ^	4/3		#	#VALUE!		#VALUE?		#VALUE ?		#VALUE ?
64 Average Sf = 0.000000 #VALUE! <	6 3	F	riction	s Slope	, Sf			2	VALUE!		#VALUE!		EVALUE!		#VALUE!
55 Friction head loss, hf (FT) = 0.000000 #VALUE! #VALUE! #VALUE! 66 H2 elevation (FT) = #VALUE! #VALUE! #VALUE! #VALUE! 67	54	٨	verage	\$f				Ħ	0.000000		#VALUE !		#VALUE!		#VALUE!
66 H2 elevation (FT) = \$VALUE! \$VALUE! \$VALUE! \$VALUE! 67	65	F	riction	n head	loss,	hf	(FT)	=	0.00000		#VALUE!		WALUE!		#VALUE!
67	66	H	2 eleva	ation (FT)			2	#VALUE!		#VALUE!		#VALUE!		#VALUE!
	67														

Figure 36. Input Template for WSGEOM



Figure 37. Plane view for example problem.

Figure 38. Input Form for WSGEOM

INPUT FORM - For WATER SURFACE PROFILE - OPEN CHANNEL TRAPEZOIDAL SECTION	
Project Number:	
Project Name :	
Prepared By : Date:	
Checked By : Date:	
*****************	***
INPUT - constant varibles	× 1 .
Elevation at initial ditch bottom>	feet
Energy coefficient>	
Design Flow>	cfs
Starting water depth elevation>	feet
***************************************	***
INPUT - Cross-section data for cross section number	1
Station distance from startin point>	feet
Ditch bottom>	feet
Foreslope>	ft:1
Backslope>	ft:1
Ditch Slope>>	ft/ft
Manning's roughness coefficient (n)>	
***************************************	* * *
INPUT - Cross-section data for cross section number	2
Station distance from startin point>	feet
Ditch bottom>	feet
Foreslope>	ft:1
Backslope>	£t:1
Ditch Slope>	£t/£t
Manning's roughness coefficient (n)>	

Figure 39. Input Form Continuation for WSGEOM

INPUT FORM - For WATER SURFACE PROFILE - OPEN CHANNEL TRAPEZOIDAL SECTION

Project no.	Page 🔬 of
INPUT - Cross-section data for cross sec	ction number
Station distance from startin po	>int> feet
Ditch bottom	> feet
Foreslope	> ft:1
Backslope	> ft:1
Ditch Slope	> ft/ft
Manning's roughness coefficient	(n)>
*********	****
INPUT - Cross-section data for cross sec	tion number
Station distance from startin po	oint> feet
Ditch bottom	feet
Foreslope	> ft:1
Backslope	> ft:1
Ditch Slope	> ft/ft
Manning's roughness coefficient	(n)>
*************************************	*****
INPUT - Cross-section data for cross sec	tion number
Station distance from startin po	int> feet
Ditch bottom	> feet
Foreslope	> ft:1
Backslope	> ft:1
Ditch Slope	=== ft/ft
Manning's roughness coefficient	(n)>

Figure 40. Example Problem Template for First Cross Section

	1 2 3 4 5 6	7	8 9	10 1	1 12	13	14	15
i	***************************************	***	************	********				
2	WATER SURFACE PROFILE - OPEN CHANNE	LI	RAPEZOIDAL SECT	ION				
3	***************************************	***	***********	********				
4	******************	++1	***********	+++				
5	+ Multiplan Microcomputer Spread	she	ets for County	+	t.			
6	+ Hydraulic and Highway Enginee	rie	o Computations					
7	+ Convright by Rocky J	. 1	eehn	+				
8	+ Version 1.0	•••		÷				
9	+ July, 1986			+				
10		+++		+++				
- 11								
12	Project Number : 1		•					
13	Project Name :Francle problem					,		
14	Prenared Ry Pocky Keeha		Date: 9/9/86					
- 15	Sharkad By Porty Kasha		Date: 9/9/86					
12	checked by inocky weam		WQ1C0 41 21 UU					
10	※ 또 내 … 는 내 는 는 는 은 은 은 은 은 은 은 은 의 의 는 소 은 바 관계 의 는 는 것 같은 것 같은 가 드 드 느 느 느 느 느 느							
10	INDIT - constant variables		· · · ·					
10	INFUI ~ LURSKARK VAFIUIES							
12	Claumbian ab		•					
20	Elevation at		CAA' 2					
21	INIVIAL DIVCO DOVVOH	-	buu teet					
22	Energy Coefficient							
23	Design flow	=	400 CT5					
24	Starting water depth elevation	¶∓	bva tees					
20				*****				
20	1870) - 67033-3766108 Gaid				ar an			
27				,	2			
20	CKUSS-SECTIONS>		A	<u> </u>			. *	
17	Philip distance from							$(x_{i})_{i\in \mathbb{N}}$
30	Station distance from	_	A	166	210		401	
31	Starting point (Teel)	-	. V	100	310		471	
32	Sitch Dottom (It)	-	20	20	20		20	
33	Forestope (TTTI)	#	2	2	2		2	
59	Backstope (ITII)		2	Z	Z		2	
35	Ditch Slope (It/It)	=	0.0015	0.0015	0.0016		0.0016	
35	nanning's n	22	0.023	0.025	0.025		0.025	
3/		•	┮┍┍┍╈┱╖╧┲╬╛╪╪┲┾╛ ╵		. In the star of the star of the star of the star	- 10 - 10 - 10 - 10 - 10		40 ke 40 ke
30 20	IRFUI - JEII-INTERAGION 4444444444444444444444		· .				. •	
32	CORCE OFOTIONE		•	•	•			
40 44	LKUSD-SEULIUND>		1	Z	3		4	
41	TT INDUT YOUTSELT IT	-	t af	7.00 A40	CAE 444		PAR 100	
74	water surface elevation (FI)	#	649	040.040	PA3*1AA		0V2-182	
43	11 Batalan Batanah Se							
44	++ Heiptul Uutput ++							
43	increase (+) or decrease (-)	_						
46 4 1	Nater surface elev.	₩	STATT AT	(+) A AAA	(-) • • • • •		(+)	
4/	Ungek value (ok 11 <= +/001)	1 #	A-Section Z	v.000	0.000		V.000	
48								
47	***************************************		***	*********				* ** ** **

*****	\$\$ Res	ults	##	· ·	i	Channel	Í	Water	1	Energy	1	Water	1	Friction
	Cross- section number	Cross- section Station number			3 4 5 8 8 F E	Bottom Elevation (feet)		Surface Elevation (feet)		Line Elevation (feet)		Depth (feet)		Loss (feet)
	1	0 +		+ 0		600.00		605.00		605.12	· +	5.00		0.000
	. 2	1	+	55	1	600.25	1	605.05	1	605.18	1	4.80	1	0.052
	3	3	+	18	ŧ	600.51	5	605.11	1	605.26	1	4.60	ł	0.077
	4	4	+	91	1	600.79	ŧ	605.18	:	605.36	ł	4.40	ł	0,095
	5	6	+	79	1	601.09	ł	605.29	ł	605.48	1	4.20	1	0.123

Figure 41. Output for Example Problem (for First Cross Section)

Figure 42. Output for Example Problem (for Second Cross Section)

	و المار الذي الذي الذي الذي والم الذي الذي الذي الذي الذي الذي الذي الذي				-	*****			-					
OUTPUT														
*****	tt Res	ults.	**		1	Channel	1	Water	-	Energy	1	Water	i.	Friction
	Cross-				ţ	Bottom	1	Sur face	1	Line	1	Depth	;	Loss
	section	Sta	tion	1	ł	Elevation	ł	Elevation	1	Elevation	1	(feet)	1	(feet)
	number				ł	(feet)	ł	(feet)	ł	(feet)	ł		ł	
		-			ł		1	****	1		ł		i	وي ورد هند ونه ونه ونه حله علم حله علم تام
	1	0	+	0	ł	600.00	1	605.00	ł	605.09	ţ	5.00	:	0.000
di se	2	1	+	55	ł	600.25	ł	605.03	1	605.13	1	4.78	ł	0.040
	3	3	+	18	ł	600.51	ł	605.07	ł	605.18	;	4.56	1	0.048
	4	- 4	+	91	ł	600.79	1	605.11	1	605.24	1	4.33	1	0.051
	5	6	+	79	ł	601.09	1	605.18	ł	605.32	1	4.09	;	0.079

2.2.4. CULVERT

CULVERT

2.2.4.1. Introduction

CULVERT is a spreadsheet developed to estimate the necessary size of a culvert used to convey a given amount of water. The spreadsheet has a menu of several box and pipe culverts from which the user can make a selection. The calculations are based on the Federal Highway Administration (FHWA) methodology.

Inputs for the spreadsheet consist of the site data, structure data, tailwater depth, and design flow rates. The site data include the roadway elevation or allowable headwater elevation for larger storm events, the allowable headwater for the design storm, pipe invert elevation at the inlet, elevation of the streambed at the pipe inlet, station distance at inlet, elevation of the pipe at the outlet invert, and station of the outlet invert.

The structure data needed are the structure type (selected from the menu of possible alternatives), diameter (or height) if it is a circular conduit, width and height if it is a rectangular box, number of barrels, whether or not the culvert has a mitered end, Manning's roughness coefficient, and the inlet loss coefficient (Ke). The tailwater depth is also entered. The final

items of information needed are the peak discharges for the design and major storms.

There are two sections of output in the culvert spreadsheet. The first section contains the culvert data inputs and outputs that are necessary to make initial checks of the headwater depths. In some cases, the pipe is in inlet control. When this occurs, the normal depth of water in the pipe needs to be found (if the pipe is not flowing full) so that an estimation of the outlet velocity can be calculated.

The normal depth is found by an interative process in which the user inputs an estimation of the water depth in the culvert. Based on this depth, the flow in the pipe is calculated. The design (or major) storm discharge is then compared against this calculated discharge. Once the two discharges are nearly equal, the outlet velocity due to normal depth can be estimated.

The second section of output comes from saving the data calculated in the first output section. The user can save up to six different culvert options in the second output section. The second output section of the spreadsheet includes all the information that is given on the FHWA input form for culvert analysis.

2.2.4.2. Using the Spreadsheet

The best way to begin using the spreadsheet is to

obtain all pertinent data, record the data in a form that is easily transferred into the spreadsheet, and then enter the data into the spreadsheet. The data obtained in the field, from topographic maps, and engineering principles can be transferred to an input form. Once this is done, a person can proceed to use the spreadsheet.

The first step is to load the file from the disk to the computer memory so that the spreadsheet will be operating under the control of Multiplan. For purposes of discussion here, assume the master spreadsheet is stored as a file on disk under the filename CULVERT.MP in Normal Mode. Once the program is loaded, turn the Recalculation and Iteration functions OFF by selecting the Options command from the Multiplan command menu, and then enter the informative data in rows 13 through 16 (see Figure 43). These data include the project number, project name, preparer, checker, and dates the project was prepared and checked.

Once all the informative data are input, the user needs to enter the site data. The site data begins in row 73, column 6, and continues to row 79, column 6 (see Figure 44). The roadway elevation is the minimum elevation of the roadway before overtopping occurs or is the maximum allowable headwater elevation for the major storm event. This elevation may be located at the point of the structure, or due to the geometrics of the

roadway, may be located a distance up the road (or down the road) from the structure. The allowable headwater is the maximum elevation the headwater can reach for the design storm. The rest of the entry information should be self-explanatory. Figure 45 in the report text or Figure 1 displayed in the spreadsheet may be helpful since both figures illustrate a culvert site and have labels for the location fo the various inputs.

The total number of barrels goes in cell R82C6. The methodology for this spreadsheet is such that the total flow is divided by the number of barrels. The design is then based on one culvert and this partial flow. In the final construction, a project designed with a 42 inch diameter pipe and two barrels would need two 42 inch pipes placed at the site

The user should now go to the structure data (which starts at row 88, column 18) and input the type of culvert that will be used in the initial calculation (see Figure 44 for the location of the inputs described hereafter). The cell for the culvert type is located in row 88, column 6. The user chooses one of the values (from 1 to 8 or from 20 to 37) as shown in Table 5 and enters it in the appropriate spreadsheet cell. Table 5 is also found in the spreadsheet starting in row 19 and ending in row 52. Once this selection is made, reenter the Options command in the Multiplan command menu and turn the Recalculation Mode back ON to let the program

recalculate all the spreadsheet cells. The user may hear a "BEEP!" and the message "Circular reference unresolved" may appear as a warning. Ignore this message; enter the Options command once more to turn OFF the Recalculation Mode; and continue entering your data.

If a circular pipe has been selected as the culvert structure, enter the height of the culvert in INCHES. This input goes into cell R91C6 (row 91, column 6). Cell R90C6 (above the cell where the culvert height was entered) can have any value since it is not used for circular pipes. If a box culvert has been selected, the user enters the width of the box in cell R90C6 and the height in cell R91C6. Both the width and the height of a box culvert are entered in FEET.

The tailwater elevation is entered in cell R100C6. If the pipe is mitered, enter a number 1 in cell R93C6, and if it is not mitered enter a number 2.

Manning's roughness coefficient and the entrance loss coefficient may or may not need to be entered. For both these variables default values have been established. If the user wishes to utilize the default values displayed in cells R95C8 and R96C8, enter a number 1 in the column 6 or each respective row (R95C6 and R96C6). If the user wants to enter his or her own value, enter the required value in place of the number 1 (i.e., in R95C6 and R96C6).

Once all pipe data have been entered, the user needs

to enter the design storm discharge and the major storm discharge. The design storm discharge is the one for which the structure is initially constructed. Depending upon the local design policy, this storm may be the 10-, 25-, or 50-year storm. The headwater for a major storm. recurrence interval should also be examined to check for problems that may occur as a consequence of a large rainfall event. For example, a requirement may be that the design storm headwater be three feet below the centerline pavement elevation of the highway at the culvert station. However, for the major storm the required headwater must be such that overtopping of the highway does not occur. In this case, both discharges need to be checked. The CULVERT spreadsheet is designed to do both tasks.

Enter the design storm in cell R104C6 and enter the major storm in cell R105C6.

The final two entries are the storage location of the computed results and a cell to enter the description of the type of culvert being considered. The user needs to enter in cell R109C6 the location (designate the portion of the spreadsheet) where the ouptput is to be stored in the completed output form. A number from 2 to 6 can be used to specify which of five locations within the spreadsheet is to be used for storage of results. The engineer or analyst should be careful when using this cell, since whenever a number is entered, with the

Recalculation turned DN, all previous results (output data) stored in the block of spreadsheet cells designated by the selection of a number to be entered are lost and are replaced by the values of the most recent computation.

There is one way in which a spreadsheet user can store computational output from up to six different culvert analysis scenarios. If any number except 2, 3, 4, 5, or 6 is entered cell in R109C6, then the spreadsheet will place the current computation results in the first row of the final output data block and retain all previous results stored in the output data block. Thus, this retains up to six completed computations at once.

To aid in descriptive output, the type of culvert can be identified on the final output sheet. To reproduce any of the descriptions of culverts listed in Table 5, the user can type =CT? in cell R110C6. The ? is replaced by the structure type already entered in cell R90C2. For example, if a person used a CMP pipe with a headwall (option 4 from Table 5), the user could type =CT4 in cell R110C6 and "CMP pipe with a headwall" will appear in the output block of the spreadsheet. If the user types =CT6, the output would contain the message "CMP pipe projecting". If the user wishes to output his or her own description, it can be typed in cell R110C6 using the Alpha command from the Multiplan command menu. However, only part of it may be displayed due to the width of the

screen. It will all be printed out in the final spreadsheet display as long as it does not exceed 61 characters.

The input is now complete. The user should turn the Recalculation Mode back on by entering the Options command from the Multiplan command menu again. As was the case earlier, ignore the alerting "BEEP!" sounds and the error message "Circular references unresolved" which will be displayed at the bottom of the screen. Once the recalculation is complete, check the headwater elevations in cells R117CB and R117C12. If the values are not acceptable and the data does not need to be sayed, make the necessary changes to seek a better solution and check the results again. ***HELPFUL HINT: If only one cell needs to be changed (like the pipe diameter) it works fine to leave the Recalculation Mode ON. However, if several changes are to be made, the user should probably turn the Recalculation Mode OFF, make the changes, and then turn the Recalculation Mode back ON.*** If the results are acceptable and the culvert is in outlet control, turn the Iteration Mode of computation ON by entering the Options command from the Multiplan command menu. The operation of the spreadsheet is now complete and the user can try another alternative, save the spreadsheet for future reference, or print the results out on a printer for a paper record. If the culvert is under inlet control and the headwaters are acceptable,

the normal depth needs to be determined if the pipe is not running full. If the pipe is running full a message will appear in cell R135C8 for the design storm and in cell R135C12 for the major storm that displays "FULL%".

The normal depth is found by changing the water depths in cells R130C8 and R130C12 until the Design Discharge and the Calculated Discharge are close or match. It is recommended that depths be entered to the nearest one-tenth. This procedure calculates the outlet velocity for normal depth which is the maximum velocity possible in the pipe. Once the culvert inputs and the headwaters are acceptable, the user should enter the Options command in the Multiplan command menu to turn the Iteration Mode ON. When the iteration is completed the user can print out the spreadsheet results, save the spreadsheet as a data file on disk, or analyze another conduit.

If the user continues by analyzing another conduit, the user MUST reenter the Options command and turn OFF the Recalculation Mode and the Iteration Mode. After making these operational changes in the spreadsheet, move the cell pointer to the cells needing changed entries and enter the new values. MAKE CERTAIN THAT THE CELL THAT DETERMINES THE STORAGE LOCATION OF THE OUTPUT DATA IS CHANGED (i.e., cell R109C6). IF THIS CELL IS NOT CHANGED, THEN THE MOST RECENT OUTPUT DATA RESULTS WILL BE ERASED AND REPLACED BY THE RESULTS OF THE ANALYSIS UNDERWAY. Once the changes are completed, enter the

Options command once more and turn the Recalculation Mode back ON before checking the computational results.

When the user is ready to quit, the final results are tabulated starting in row 144, column 1, and continue to row 178, column 55. IT IS NOW A GOOD IDEA TO SAVE THE SPREADSHEET AS A DATA FILE IF NOT ALREADY DONE SD TO ENSURE THAT THE DATA ARE NOT ERASED AND LOST! Before printing, the user has the option of entering some informative data about the site beginning in cell R142C48 (see Figure 46). This includes such items as the drainage area, channel shape, routing, stream slope, and any other comments about the site. In addition to these information cells, comments about each scenario can be entered starting in cell R158C49 (see Figure 46).

Once all the information is entered, the Print command and its subcommands permit setting up the printed output to match the width and style of the printer available to produce printed records. The number of pages of output that are required is based on the printer capability and the style of print used. The user should utilize a set up with named grouping of cells to be printed out for minimum confusion during the printing process. (Consult the software manual for Microsoft Multiplan on how to Name cell blocks and on how to Print with the various options within the Print command.)

2.2.4.3. Example Problem

The highway plans are complete for a paved county road except for the design of a culvert which is to be placed under the road. The top of the roadway pavement elevation at the culvert location is 110.00 feet and the culvert inlet invert elevation is 100.00 feet. The pipe length needs to be approximately 100 feet long. The maximum allowable headwater elevation for the 25 year storm is 107 feet. For the 100-year storm the water cannot overtop the roadway. Due to the location of the structure, there is no tailwater.

The inlet invert will be put at 100 feet and the outlet invert at 94 feet elevations. The county has in it's maintenance and materials yard three 48 inch diameter CMP pipes, each 100 feet long. The county engineer has decided that, if possible, these pipes will be placed at the site with a headwall.

Two other options that are being considered are to place a square edged concrete pipe with a headwall and to construct a box culvert with no wingwall flares. In all cases the culverts will not be mitered, will be assumed to be 100 feet long, and cannot be over six feet high. An engineering sketch of the site conditions is shown in Figure 47.

The design and major storm discharges for this structure were found using the RUNOFF spreadsheet. The Iowa Runoff Chart was used with a drainage area of 2400
acres and an LF of 0.2. The discharge under these conditions was estimated at 350 cfs for the design storm (25-year) and 530 cfs for the major storm (100-year). The Iowa Runoff Chart results are shown in Figure 48.

Based on the site data and the calculated discharges, the input form was filled out. As was the case in the example problem and in almost all instances in culvert design, the heights and/or widths can only be estimated until the computations are performed. From the input form (see Figure 49) initial data was entered into the spreadsheet and the calculations completed.

The final results are shown in Figure 50. The portion of the output displayed in columns 1 through 22 contains a basic summary for comparing for adequate design flow while the output in columns 22 through 55 displays the computational details in the traditional format. It can be seen from this information that the 10 feet by 6 feet box culvert will work but that the other alternatives violate the minimum headwater depth requirement.

Table 5. Culvert Types Available

ID			:
Numb	er		Description
	Concrete pipe		Square edge with headwall
2	Concrete pipe		Groove end with headwall
. 2	Concrete pipe		Groove end projecting
4	CMP *	-	Headwall
5	CMP		Mitered to slope
6	CMP	-	Projecting
7	Circular		Beveled ring, 45 degree bevels
8	Circular		Beveled ring, 33.7 degree bevels
20	RCB **		30 to 75 degree wingwall flares
21	RCB		90 and 15 degree wingwall flares
22	RCB	-	0 degree wingwall flares
23	RCB		45 degree wingwall flare d=.043D
24	RCB	_	18 to 33.7 degree wingwall flare d=.083D
25	RCB	•••	90 degree headwall with 3/4" chamfers
26	RCB		90 degree headwall with 45 degree bevels
27	RCB		90 degree headwall with
			33.7 degree bevels
28	RCB		3/4" chamfers: 45 degree shewed headwall
-29	RCB	-	3/4" chamfers: 30 degree shewed headwall
30	RCB	-	3/4" chamfers: 15 degree shewed headwall
31	RCB		45 degree bevels:
		2	10 to 45 degree skewed headwall
32	RCB		
	3/4" chamfers	-	45 degree non-offset wingwall flares
33	RCB		
	3/4" chamfers		18.4 degree non-offset wingwall flares
34	RCB		
	3/4" chamfers		18.4 degree non-offset wingwall flares 30 degree skewed barrel
35	RCB		
36	Top Bevels		45 degree wingwall flares - offset

* CMP = Corrugated Metel Pipes ** RCB = Reinforced Concrete Box

Top Bevels

Top Bevels

37

RCB

169

- 45 degree wingwall flares - offset

- 45 degree wingwall flares - offset

	1	2	3	4	5	6	7	- 8		9	10	11	12	13	14
1	******	*****	* * * * *	*****	****	******	****	****	****	****	****	****	*****	*****	**
2					CULV	ERT AN	ALYSI	S						· ·	
3	******	*****	****	****	****	*****	*****	****	****	****	*****	****	****	*****	**
4															
5	++	++++++	+++++	+++++	++++	+++++	++++	++++	++++	+++-	++++4	++++	++		
6	÷	Multi	plan	Micro	comp	uter S	pread	lshee	ts 1	Eor	Cour	ity	+		
7	÷	Hydra	aulic	and	High	way En	ginee	ring	Cor	nput	tatic	ons	+	- 1	
8	· +	. ^		Copyw	rite	by Ro	cky J	I. Ke	ehn	-		1	+		
9	+				Ve	rsion 2	2.1						+		
10	· +					1986							+	1.	
11	++	++++++	+++++	+++++	++++	++++++	++++	++++	++++	+++	++++	++++	++		
12		•													
13	Project	Numbe	r :1											1. A.	
14	Project	Name	:E	xampl	e pr	oblem									
15	Prepare	d by	: R	ocky	Keeh	n .				. 1	Date:	11/	12/86		
16	Checked	Bv	: R	ocky	Keeh	n				1	Date	11/	12/86		
17		-1	÷ •		*******	₩ ₩				•			~ ~ / ~ /		
18					· ·			• • • •• ••		··					

Figure 43. Location of Descriptive Input Data in CULVERT Spreadsheet

• -

Figure 44. Location of the Culvert Input Data in the CULVERT Spreadsheet 1 2 3 4 5 6 7 8 9 10 11 12 13 63 -----14 64 RESULTS: 65 66 Project Number : 0 67 Project Name : 0 68 Prepared By : 59 Checked By : Date: 0 0 Date: 0 69 Checked By n 70 71 INPUT - SITE DATA (see Figure 1) 72 ~~~ Roadway Elevation --> 110 ft, or major storm headwater 107 ft, allowable headwater 73 74 EL (hd) ----> 75 76 100 ft, pipe invert elev. - inlet EL (1) ~~~~> 77 EL (1) station ----> 0 ft, pipe invert station - inlet 78 ELo -----> 94 ft, pipe invert elev. - outlet ELo station ----> 79 100 ft, pipe invert station - outlet 80 81 Number of barrels --> 82 1 83 El (sf) -----> 100 ft, elev. of stream bed the inlet 84 85 86 INPUT - STRUCTURE DATA 87 ~~ Type -----> 88 22 See Table 1 89 Width ----> 10 feet 90 Height ----> 91 6 feet 92 Mitered ? ----> 2 1 = yes, 2 = no 93 94 Roughness (n) \rightarrow 1 Entrance loss (Ke) \rightarrow 1 0.012 <- default value (if n=1) 95 0.7 <- default value (if Ke=1) 96 97 98 INPUT TAILWATER DEPTH: 99 ~~~ 1.00 Tailwater elevation > 0 ft 101 **102 INPUT FLOW RATES:** 103 25-year 100-year
 Design storm Q ---->
 350 cfs

 Major storm Q ---->
 530 cfs
 104 105 106 107 INPUT DATA STORAGE FOR SUMMARY TABLE: 108 ~~ Store at (2-6) ----> 3 109 110 Label structure ---->RCB no wingwall flares (extension of sides) 111 113 OUTPUT: 114 ~~ l Design I storm | Major | storm 115 116 Headwater elevation| 105.6 ft| 108.0 ftControl ?| Inlet| InletBelow allowable ?| Yes| YesMaximum outlet velocity| 35.0 ft/sec| 40.8 ft/sec 117 118 119 120 121 4 5 6 7 8 9 10 11 12 13 14 2 1 3 ** If pipe is in inlet control need to find normal depth 122 123 below to get outlet velocity ** 124 125 MANUAL INTERATION TO GET NORMAL DEPTH: 126 127 Design | storm | 1 Major storm . . 1 128 129 130 INPUT: Water depth 1 £t | 1.3 ft OUTPUT: Design dicharge | 350.0 cfs | 530.0 cfs Calculated discharge | 352.9 cfs | 520.8 cfs Difference | -2.9 cfs | 9.2 cfs 131 132 133 134 Difference | -2.9 cfs Error in percent | 0.8 % 9.2 cfs 135 136 ------

171

*** Needed to get outlet velocity when pipe is in inlet control ***



. 172

Figure 46. Display of Informative Record Portion of CULVERT Spreadsheet

** HYDROLOGICAL DATA (Optional input) ** Method: Drainage area: 2400 acres ł Channel shape: n/aRouting: n/a Stream slope: .01 ft/ft Other: ** SITE DATA OUTPUT ** Roadway Elev.: 10 ft EL (hd): 1 ft EL (i): 10 ft ELo: O ft/ft EL(i) station: 0 ft ELc sta: 0.ft EL (sf): No. barrels: ---- ** COMMENTS ** larger pipe needed but due to 6 foot limit cannot increase pipe diameter exceptable design . .. try two pipes try three pipes pipes on hand will not work



Figure 47. Example Problem Site Description

1 2 3 5 4 6 7 52 ---53 RESULTS 54 ~~~~~~ 55 + + + + + + + * * 56 Project Number:1 57 Project Name :Example area for culvert example 58 Prepared By :Rocky J. Keehn Date:11-15-86 59 Checked By :Rocky J. Keehn Date:11-15-86 60 + + 62 *** IOWA RUNOFF CHART *** --- Helpful Output ---63 Area (acres) > 64 2400 65 66 --- Please input --67 LF ----> 0.2 68 69 Goto LF FOR HELP 70 71 72 73 + + 74 *** PEAK DISCHARGES *** 75 IOWA RUNOFF CHART BULLETIN 11 76 ~~~~~~ 77 Q2 --> 140 cfs* NOT USED 05 78 --> 220 cfs 79 010 --> 310 cfs 80 Q25 350 cfs ~1 --> 81 050 440 cfs --> 82 0100 --> 530 cfs 83 0500 --> 720 cfs* 84 * estimated by linear regression 85

Figure 48. Results from the RUNOFF Spreadsheet Used in the CULVERT Spreadsheet Example

Figure 49. Input Data Form for use with CULVERT Spreadsheet

INPUT FORM - For CULVERT - Pa	ge 1
Project Number:	
Project Name :	
Prepared By :	Date:
Checked By :	Date:
**************	********
HYDROLOGICAL DATA (optional):	
Method>	
Drainage area ->	
Channel shape ->	
Routing>	
Stream slope>	
Other>	
******	******
SITE DATA:	
Roadway elevation ->	ft
EL (hd)>	ft - Allowable headwater
EL (1)>	ft - Pipe invert elev inlet
EL (sf)>	ft - Elev. stream bed at invert
So	ft/ft - Pine slope
*****	*****
DESTON FLOW RATES :	
Recurrence interval	Peak Flow rate (0)
Adacian usy	rean riom tace (¥)
Ancordin Addr	
ymajor year	
nonon more input data on	audicional page(s) *******

.

'n	1	2		3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	
1	RESUL	TS:															********		**			**	
2	*****	***																					
3	Proje	ct Numb	er	:1																			
4	Proje	ct Name		:Ex	ample	e prol	lea																
5	Prepa	red By		:Ro	cky I	Keehn					Date	:11/	12/86						· . ·				
6	Check	ed By		:Ro	cky I	Keehn	:				Date	:11/	12/86										
7					•								· .										
8	11 11	CULVERT OUTPUT:	DE	SCRI	PTIO	N	•	÷															
0	1	Structu	re	: Si	ze			- 1 Cu	lvert	des	criot	ion							1	Total	1	Flow	
1	1	type		l Wi	dth	: Hei	ight	(d	esign	sto	Th CO	11 0	nly)						ł	flov	1	per	
2	ł	from		1 (B)	: (D)	1											t		I	barrel	
3	1	Table 1		l fe	et	1 fe	et	1		•									:	Q (cfs)	6 2.	Q/N(1)	
4	1.	~ ~ ~ ~ ~ ~ ~ ~ ~	**	:		1		· :		****	*****	-					********		! -	*******	1	******	**
5	11	1	2	ł	10	1	: 6	1-RC	B no	ving	uall	flar	es (e	xtensi	on of	sides)		t	3	i0	35	0
5	# 1	2	2	ł	10	1	6	: RC	B no	ving	vall	flar	es (e	xtens	ion of	sides)		1	53	30 · 1	53	0
7	· 1	Choice	2	:		1		4											1		ł		
B	* 1		1	1		1	72	l Co	ncret	e pi	pe sq	uare	edge	with	headv	all			:	3	i0 t	35	0
9	#		1	1	<i></i>	1	72	: Co	ncret	e pi	pe sq	uare	edge	with	headv	all			. 1	5	30 1	53	0
0	. 1	Choice	3	1	•	I		1											1		- E		
1	11	. 1	2	•	10	1	6	I RC	Bino	ving	wall	flar	es (e	xtens	on of	sides)		:	- 3	50 I	35	0
2	4	7	2	! .	10	1	6	I RC	B no	ving	Vall	flar	es: (e	xtensi	ion of	sides).		1	53	30 1	53	0
3	1	Choice	4			1		1				_							:		1		
4			4	i		1	- 48		IP pip	e Vi	th he	adva	II.						1	: 3	50 1	35	0
5	H i	.	4	i		.i	48		P pip	e ¥1	th he	adva	11						1	5	30 1	53	Q
5	11 	Choice	5	i .		i	.	- i											1				
1	14		4	;		1	48	E CN	ip pip	e 91	th he	adva	ļI	•.					1	3	50 ł	17	5
8	T	AL	4 r	i		i	48	1 68	P pip	e vi	th he	adva	14							5	<u> 1</u>	26	3
2	Ц. • •	unoice	0- ▲	ī ,		i 1	40	i	mata		46. 6.		• •		·				i				-
₩. St			¥: 4	1 1		i t	90 - 40	i Un	r:pip 0 _:-	e at	58 86 AL L	:40V3	11 11				•		1 I I	3	N L	11	d T
1	44 i		4	ŧ .		¥	40	i UN	n. brb	4 VI	in ne	duva	11							Ĵ.	SV 1	17.	1

Figure 50. Total Output from the Example Problem for CULVERT Spreadsheet

																				44	4 0 (16	47	18 49	26 3	1	2	33	- J9 - JJ
144 145 146 147 148	22	23	24	25	26	27	28 29	3	0 31 3	32 33	34 35	35	37 3	3 6 33	9 40	,) 41 ,	42	43	141 142 ,143 144 145 146 147 148					1 11 HYDROLOG Method:Io Drainage area: 2 Channel shape: n Routing: n Stream slope: .	ICAL BAT wa Runof 400 acre /a /a 01 ft/ft	A (Option f Chart s	al input)	11	
149																			150	1		1		t Other:					1
151																			151	1 Con	trol	1	Outlet	1					1
152	1					*******						****	******	*****		*********		,	152	l Read	vater	1 1	elocity	1 11 1 12 12 12 12 12 12 12 12 12 12 12 12 12	SITE	TA OUTPU	111 26.232	107	
153	1	Inlet G	on\$ro.	i					: Outlet C	Datrol									153	- 1 EIEV - 1 - FF	ation ast)	1 (tt/sec)	i Koadway Elev.:	100 ft	ب	Elo:	- 34	fit i
155	i				;		ł		1	1	:	ł		:	;	i	1		155	4		ł		EL(i) station:	0 11	Elo s	ation:	100	ft
156	1	HWi/D	1	HWL	1	Fall	l EL-hi		TH TH	t dc	[(dc+D)/2	2 1	h0	i k		H	ł	EL-ho	156	1		ł		1 No. barrels:	1	E	. (sf):	100	
157	ļ		:		• ‡ -										}		- }	********	157						- 11 CB	HERIS II	*****		_~~~~
158	i	U.9	31	3.6		0.00	; 105.	57	: 0.00	3.37	1 4.65		4.7	1 0.1	70 1	4.69		99.68 101 FA	128	i I	03,3/	i i	33.00	i .					
109	1	1.4	• i •	8.V	1	4.00	i 108. 1	Q4	i 0.00	i 4.44	1 3.2		5.7	iVa. I	170) i	j.22	: i •	101.00	122	i 1 1	VG, V9	i	44.11	t 1					
161	÷	1.5	6 !	9.94	1	0.00	1 109.	94	2.00	1 5.11	1 5.5		5.55	1 0.1	50	5.55	i 1	103.70	161	1 1	09.94	i	35.09	l larger pipe neer	led but (lue to 6	laot lini	t can	not
162	ì	2.9	7 1	17.82	1	0.00	1 117.	82	: 0.00	1 5.75	5.8		5.88	1 0.1	50 1	S. 89		109.39	162	1	17.82	Ì	39.15	l increase pipe di	aneter				
163	1		ł		1		1		1	1	1	÷.		1	1		1		163	ł		1		1					
164	ł	0.9	31	5.57	1	0.00	1 105.	57	: 0.00	1 3.37	4.65	11	4.69	1 0.1	70	4.69	F F	99.68	164	1 1	05.57	;	35.00	l exceptable desig	jit.				
165	t	1.3	4 1	8.Q4	1	0.00	i 109.	04	0.00	1 4,44	5.2	2 1	5.22	Q.,	76 1	5.22	21	101.50	165	1 1	08.04	ł	40.77	1					
165	1	. .	1		1		1	-	1	1	1			1			1		166	!		1	a	i I Anno Anno - 3 Anno					
167	1	8.0		32.04	1	0.00	1 132.	04	i 0.00	3.97	3.9		3.99	1 0.1	50	3.99		136.21	16/	1 1	136.4I	;	27.68	i try two pipes					
168	i	11.5	11.	10.05	ì	0.00	; 1/Q.	96	: 0.00	2 4.00	4.0		4.00	1 Ø41	50 1	i 4⊾00	РТ.	183.64	100	i 1 	03.04	1	72.10	• •					
107	÷	2 5	A 1	9.99	4	0 00	1 109	60 ·	•	1 2 80	1 2 0/	4 1 4	2 00	1 01	50 5			107 45	170		09.99	ł	23.40	try three pines					
171	i	6.A	7 1	19.49	1	0.00	1 119.	49	1 0.00	1 3.96	1 3.95	2 1	3.99	1 6.5	50 1	3.99		119.89	171	1 1	19.89		21.13	1					
172	;		1		1		1	**	1	1	1		as 94	1	•• 1			******	172	1		1		1					
173	ŧ	1.4	8	5.91	ł	0.00	1 105.	91	0.00	3.34	3.67	r į	3.67	0.	50	3.67		101.92	173	1 1	105.91	;	15.60	f pipes on hand w	ill not /	ror k			
174	ł	2.5	3 1	10.13	ţ	0.00	1 110	13	0.00	: 3.80	1 3,9) [3.90	1 0.	50 8	3.90)	107.64	174	; 1	110.13	1	18.11	\$.					

Figure 50. (Continued)

2.2.5. XSECT

XSECT

HYDRAULICS - STREAM CROSS-SECTIONS

2.2.5.1. Introduction

The "Hydraulics - Stream Cross-sections" spreadsheet was developed to give the same results as the Iowa Department of Transportation VAL program. The spreadsheet uses the iteration mode to give a discharge in a natural cross-section for each incremental depth. The spreadsheet will handle overbank flooding on one or both banks.

The input consists of the cross-section shots across the channel. The distance from the starting point, the elevation of the shot, and the Manning's n between the previous shot and the current shot are all input parameters. The user also enters the starting depth and incremental depths for which the depths are to be calculated. The output consists of the depth elevation, discharge, velocity, and conveyance.

2.2.5.2. Using the Spreadsheet

The best way to begin using this or any spreadsheet program is to collect all pertinent data, record the data

in a form that is easily transferred into the spreadsheet, and then to enter the data into the spreadsheet. The first step is, thus, to collect the data and record it onto an input form. Once this is done, a user can begin to manipulate the spreadsheet template.

The first step after completing the input form is to load the spreadsheet into the computer to operate it under the control of Microsoft Multiplan. Assume that this spreadsheet is stored on disk as a data file under the filename XSECT.MP in the Normal Mode. Once the program is loaded into the computer, turn both the Recalculation Mode and the Iteration Mode of operation OFF by selecting the Options command from the Multiplan command menu. Then the user enters the data for project number, project name, preparer name, checker name, and dates prepared and checked. The entry lines for these data are found in rows 12 through 15 (see Figure 51).

The user now enters the "Starting elevation of depth computations (ft)" (in R2OC5), "Ending elevation of depth computations (ft)" (in R22C5), "Slope (ft/mi)" (in R23C5), and "Depth increment (ft)" (in R24C5). The spreadsheet can calculate up to 32 depth increments. The user can quickly check to see if all the points will be calculated by first subtracting the maximum depth from the minimum depth, and then, dividing by the depth increment.

The next step is to choose whether or not any bank overflow should be considered. If the option the user wants to choose is not already existing in cell R27C5, the value will need to be changed. Change the value in R27C5 (if needed) and turn the Recalculatin Mode ON by pressing the <shift> key and the <exclamation mark> key together (usually this is a SHIFT-1). After the recalculation begins, press the <ESC> key (escape key). This will cancel the recalculation so the user can continue to enter more data that is needed in order to complete the entire computation process.

If one or both bank overflows are desired, enter the shot distances and elevations for each overbank. The shot data for the left bank are entered in row 35, columns 5 and 6, and the data for the right bank is entered in row 36, columns 5 and 6 (see Figure 52). The banks are oriented as if the user is looking upstream for "left" and "right". An example of a stream cross-section is shown in Figure 53 with overbank shots labeled.

The next set of data to enter is the shot distances and elevations that describe the cross-section. Figure 52 shows a cross-section with these values.

The shot points are then entered beginning in R56C5 and R56C6. In R56C5 the first distance is entered (always should be 0.0). Cell R56C5 is the elevation of the first shot point. After the first shot is entered, the second shot is entered beginning with the Manning's

roughness coefficient between the first shot and the second shot in cell R57C4. The distance from the first shot to the second shot is entered in cell R57C5 and the corresponding elevation of the second shot entered in R57C6. The data for the third shot is then entered in row 58. Two things to remember for each shot are: (1) The distance is always that distance between the current shot and the first shot. (2) The Manning's n value describes the channel condition between the previous shot and the current one. A total of 24 shots can be input for each cross-section. The minimum number is 3 shots.

***** IMPORTANT NOTE: The spreadsheet has a problem when two successive shots have exactly the same elevation. To avoid this problem, enter one of the shots with a value slightly higher or lower than the other one. For example, if two successive shots have an elevation of 910.00, then one shot could be entered as 910.00 and the other could be entered as 910.001. This will have no effect on the accuracy of the results since the numbers are, for all practical purposes, equal. *****

Once this data is entered, a user can move down the spreadsheet to view the output beginning in row 84. Select the Options command from the Multiplan command menu and turn both the Recalculation Mode and the Iteration Mode ON for the results to be computed for

viewing.

2.2.5.3. Example Problem

To show how the program works, a sample problem given in an Iowa State University Short Course on the use of the VAL program at the Iowa Department of Transportation will be used. The input form is shown in Figure 54 that the Iowa Department of Transportation has a county engineer office submit when describing cross-sections. The data from this sheet is then entered into the spreadsheet and the results calculated. The input sheet is shown as Figure 51 and the output sheet is shown here as Figure 55. The output from the VAL program is also included as Figure 56.

Figure 51. Data Input for XSECT Example Problem

HYDRAULICS - STREAM CROSS-SECTIONS Multiplan Microcomputer Spreadsheets for County ÷ + Hydraulic and Highway Engineering Computations ŧ ŧ Copyright by Rocky J. Keehn 4 4 Version 1.1 + 1986 *********************** **Project Number:** Date: Date: **Project Name :** INPUT DATA ~~~~~ Starting elevation of depth computations (ft)= 987 Ending elevation of depth computations (ft)= 997 Slope (ft/mi) = 4.75 1 Depth increment (ft) = Input one of the following options: Input (0-3) ----> 0 0 - no overbank flow 1 - overbank flow both banks 2 - overbank flow left bank 3 - overbank flow right bank 1.12 OUTPUT: ~~~~~~ $= 0.0009 \, ft/ft$ Slope Number of iterations = 9 ITERATION: OUTPUT: ~~~~~ 17.5 feet Water depth # Water elevation **3**2 997 feet INPUT - Cross-section information: Distance Elev (feet) (feet) Data Manning's n 1 --> Ũ 997.00 2 --> 0.07 995.00 92 3 --> 0.07 145 993.00 4 --> 0.07 275 991.00 5 --> 0.07 430 990.00

б>	0.03	462	982.50
7>	0.03	472	979 50
8>	0.03	492	982.50
9>	0.03	510	990.00
10	0.07	562	990.00
11	0.07	705	993.00
12	0.07	745	995.00
13	0.07	807	1000.90
14	0.07	900	1003.00
15	0.0.	200	
16		.e.	and a grad
17			
18		•	- · ·
19			
20			
21			
22	· ·		
23			
24	· .		
<u>`</u> .			

1 5 7 2 3 4 б. HYDRAULICS - STREAM CROSS-SECTIONS 2 4 ************************ 5 Multiplan Microcomputer Spreadsheets for County 4 + 6 Hydraulic and Highway Engineering Computations + 7 Copyright by Rocky J. Keehn 8 Version 1.1 4 9 1986 10 11 12 Project Number: Date: 13 Project Name : Date: 14 Prepared By : 15 Checked By : 16 _____ **17 INPUT DATA** 18 19 Starting elevation of 20 depth computations (ft)= 987 21 Ending elevation of 22 depth computations (ft)= 997 23 Slope (ft/mi) 22 4.75 24 Depth increment (ft) 1 25 26 Input one of the following options: 27 Input (0-3) ----> 1 28 0 - no overbank flow 29 1 - overbank flow both banks 30 2 - overbank flow left bank 31 3 - overbank flow right bank 32 Input location of overflow bank: 33 dist. elev. 34 (ft) (ft)... 35 Overflow left bank = 220 994 Overflow right bank = 600 36 996 37 38 -39 OUTPUT: 40 41 Slope = 0.0009 ft/ft42 Number of iterations 22 9 44 ITERATION: 45 46 OUTPUT: 47 ~~~~~~~ 48 Water depth = 7.5 feet 987 feet 49 Water elevation = 50 51 INPUT - Cross-section information: 52 53 Distance Elev 54 Data (feet) (feet) 55 Manning's n 56 1 --> 0 997.00 57 2 --> 0.07 92 995.00 58 3 --> 0.07 145 993.00 59 4 --> 0.07 275 991.00





Figure 54. VAL Program Data Input Form

VALLEY CROSS SECTION DATA

The submittal of a bridge type structure will include a right angle valley section. This section should be taken downstream from the crossing. It shall be noted whether it is an average section or a control section. Enough ground shots will be taken to outline the valley to an elevation well above extreme highwater. Special care will be taken to accurately outline the main channel. Each shot should be identified; that is (FP) flood plain, (TB) top of bank, (ES) edge of stream, etc. Mannings equation roughness factors will be assigned each shot. Include site photos with this information.

REMARKS: Section taken 100' downstream from crossing. It is an average section.

* L						£	-	بمساهد الدمنيا	****		
(nere	are	- 0.0	contrat	Sections	COWNSINE	T T ()111	E D P	orioue	LIAL	PTTPCT	
	~ • • ~		Q Q Q .					0111-34			
								-			

the bridge hydraulics.

Distance	Elevation	(N) Roughness	Remarks		Distance	Elevation	(N) Roughness	Remarks
0	997.0	n=0.07	FP		807	1000.9	0.07	FP
92	995.0				900	1003.0	0.07	FP
145	993.0				-			
275	991.0							
430	990.0	n=0.07 n=0.03	ES		-			
462	982.5		ES					
472	979.5		çs					
487	982.5		ES	1				
510	990.0	n=0.03 n=0.07	тв					
562	990.0		FP					
705	993.0		FP					
745	995.0		FP					

PLAT OF DRAINAGE AREA

The drainage area is to be platted as completely and accurately as possible and to the largest practicable scale on a separate sheet. Use a definite scale, as 1" equals 4, 5, 1 or 2 miles, and indicate what scale has been used. In addition to the outlines of the watershed, indicate the positions of the streams and, roughly, the character of the soil and the relative locations of the steap and flat portions. Whenever practicable, the above information should be secured by going over the area either on foot or in a car. For most watersheds the information may be secured from the best existing data, soil maps, U.S.G.S. maps and Bulletin No. 7-1.H.R.B. No plat is necessary if the area is listed in Bulletin Number 7.

REMARKS:

Give additional information by reference to marginal number on reverse side of this sheet.

Marginal No,	
5	Mr. Doe has been living in this area all his life (62 years.)
, , . ,	
, <u></u>	

IMPORTANT NOTE

The information given on this form must in all cases be supplemented by complete plat and profile of the life, drawn to a convenient scale on a suparate sheet.

The information as shown on this form is essential and must be supplied in detail before the plans can be prepared or approved. It will be necessary to return this form for correction unless the data supplied is complete.

ganad diada kataw andat dibite using sama andar araw anda biana kirah i		وجو الداي جورا وروع وروي حوي حيني عنها منها منها المراجع أناج			
DUTPUT:		· · · · · · · · · · · · · · · · · · ·			. •
·	Water	r Water		• *	
Da	ta Elev	. Depth	Q	Velocity.	Conveyance
Poi	nt (feet)) (feet)	(cfs)	(ft/sec)	(sq. ft.)
	1 98	7 7.5	5 805	3.6	224
	2 98	8,5	5 1114	3.9	286
	3 98	9 9.5	i 1488	4.2	355
	4 99	0 10.5	5 1930	4.5	431
	5 99	1 11.5	5 2635	4.0	665
	6 993	2 12.5	5 3613	3.4	1055
	7 993	3 13.5	5 4890	3.1	1559
	8 99	4 14.5	6566	3.1	2142
	9 99	5 15.5	5 · 8557	3.1	2772
	10 99	6 16.5	10835	3.1	3453
	11 99	7 17.5	i 13442	3.2	4191

5.15

Figure 55. Output Table from XSECT Spreadsheet



	10	562 705	990.0 993.0	,			
	*** (g) 12 13	745 807 900	995.0 1000.9 1003.0				· · · · · · · · · · · · · · · · · · ·
	SLOPE SECTIO	IN FEET/ N DIST. 430	HILE 4 N VALUE 4 0.070	. 750		\backslash	If no printer is
	Š Stage High	DATA ELEV. L	0.079 Du elev. Incri	EHENT			data before you
	99 58978	7.00	987.00 1.0	90			[change screens. (+++ 3)
	VALUE STAGE ELEV.	987.00	SECTION	DISCHARGE	VELOCITY	CONVEYANCE	N
	••••@		i	0 CFS	0.0 FPS	0 SQ. FT.	
	0	8.0700	2	805 CFS	3.6 FPS	224 SQ. FT.	
	26832	0.0300	 -	9 675	0.0 FPS	9 SQ. FT.	a19.7
	Û	6.0700	TOTAL	865 CFS	3. A EPS	224 SQ. FT.	481-
	26832	000 00	ivine				·, ·
	31966 6LEV.	708.00	1	0 CFS	0.0 FP5 .	0 SQ. FT.	
	0	0.0700	2	1114 CFS	3.9 FP\$	286 SQ. FT.	
•	37146	9.9399	3	0 CFS	0.0 FP3	0 SQ. FT.	
	e	0.0700	TOTAL	1114 CFS	3.9 FPS	286 SQ. FT.	·
	37146 STAGE ELEV.	989.08				-	
	***E		1	0 CF3	0.0 FPS	. 0 SQ. FT.	
	0	0.0700	2	1468 CFS	4.2 FPS	355 <i>SQ.</i> FT.	
	49683	0.0300	3	0 CFS	0.0 FPS	0 SQ. FT.	
	6	0.0700	TOTAL	1488 CFS	4.2 FPS	355 SQ. FT.	• *
	49603	000 00					
	STAGE ELEV.	990.00	ì	0 CFS	0.0 FPS	0 SQ. FT.	· .
	•	0.0700	2	1930 CFS	4.3 FPS	431 SQ. FT.	
	64358	0.0300	. 3	0. CF <i>S</i>	0.0 FPS	0 SQ. FT.	
	9	0.0700	TOTAL	1930 CFS	4.5 FPS	431 SQ. FT.	▲ 14
	64358 STAGE ELEV.	991.00				a se se a companya da se	
	1039	0.0700	1	31 CFS	0.4 FP5	77 SQ. FT.	
	*** 🖻		2	2563 CFS	5.0 FP\$	511 SQ. FT.	
	85463	0.0300	3	40 CFS	0.5 FPS	76 SQ. FT.	
	1345	0.0700	TOTAL	2635 CFS	4.0 FPS	665 SQ. FT.	•
	97847	997 04					· .
	A184	A A700	\$	192 CF\$	0.7 FPS	265 SQ. FT.	
	4000	0.0100	2	3266 CF.S	5.5 FP S	591 SQ. FT.	•
	5400	0.0300 0.0300	3	156 CFS	0.8 FPS	199 SQ. FT.	
	170470	0.0/00	TOTAL	3613 CFS	3.4 FPS	1056 SQ. FT.	
	STAGE ELEV.	993.00					
•	16374	0.0700	1	492 CF3	1.0 PPS	317 SW1 F1.	
	••• E		2	4039 CFS	8.0 FPS	0/1 34. 71.	
	134544	0.0300	3	363 CFS	1.0 FPS	370 SQ. FT.	
	12097	9.0700	TOTAL	4890 CFS	3.1 FFS	1559 SQ. FT.	
	163034 Stage Elev.	994.00					
	32987	0.0700	1	989 CFS	1.2 FPS	816 SQ. FT.	
	162317	0.0100	2	4868 CFS	6.5 FPS	751 SQ. FT.	
	73247	4 0 700	3	708 CFS	1.2 FPS	575 SQ. FT.	
	23812	a.a.au	TOTAL	6366 CFS	3.1 F#S	2142 SQ. FT.	
	218410						

STAGE ELEV.	995.00				
		1	1638 CFS	1.4 FPS	1140 SQ. FT.
54608	0.0700	2	5763 CFS	6.9 FFS	831 SQ. FT.
192136	0.0300	-			
••• @	•	'n	1157 CFS	1.4 FPS	600 SQ. FT.
38566	0.0700	3			
		TOTAL	8558 CFS	3.1 FPS	2772 SQ. FT.
285310 Mare Flev.	996.08				
		1	2379 CFS	1.6 FPS	1501 SQ. FT.
79315	0.0700	2	, 4717 CFS	7.4 FPS	911 SQ. FT.
223934	0.0300	-			
50004	A 0780	3	1748 CFS	1.7 FP\$	1041 59. 21.
20002	0.0100	TOTAL	10835 CFS	3.1 FPS	3453 SQ. FT.
361235					
SIAGE ELEV.	997.00	1	3290 CFS	1.7 FP\$	1908 SQ. FT.
109701	0.0700	2	7770 555	7 8 595	994 50 FT
257649	0.0300	2	rizo ura	110 110	
A		3	2424 CFS	1.9 FPS	1292 SQ. FT.
···()	0 0700				
00011	•1•.••	TOTAL	13442 CFS	3.2 FPS	4191 SQ. FT.
448174					
IS DESIGN S	TAGE CONPL	TATION DESI	RED7 ENTER Y	URN : T (G/	
ANY CHANGE?	N C				
ESIGN DISC	HAGRE	200			
STAGE ELEV.	993.21	4	584 CFS		578 SQ. FT.
19481	0.0700				
440350	A A344	2	4207 CFS	6.1 FPS	048 24. 11.
140230	0.0300	3	427 CFS	1.0 FPS	412 SQ. FT.
14246	0.0700		5010 CCF	3 4 605	1479 CO. ET.
173977		TUTAL	3210 UF3	3.1 774	1017 541. 111
IS DESIGN S	TAGE CONPL	TATION DESI	RED? ENTER Y	OR N : Y 🔛	
NIER DESIG	N DISCHARG	6 (In Cra).	<u> </u>		
ESIGN DISC	HAGRE	200			
STAGE ELEV.	992.50		104 058	A 8 695	104 50 ET
10791	0.0700	•	344 654	V.U ///#	
		ຊ່	3645 CFS	5.8 FPS	631 SQ. FT.
121509	0.0300	3	247 CFS	6.9 FPS	279 SQ. FT.
8239	0.0700			1 7 656	1308 80 57
140539		TOTAL	4213 CFS	3.3 667	1,673 JH. P.L.
S DESIGN S	TAGE COMPL	TATION DESI	RED? ENTER Y	OR N : N. 08	
O YOU WANT	TO CHANGE	N VALUES?	ENTER Y OR N	· M @	
					•

ARE ADDITIONAL STAGES DESIRED? . N 400 Do you want to change the slope? (Y or N)

Logoff

C

N CONTRACT TO CHANGE ANY X-SECT. SHOTS? (Y OR N): N CO DO YOU WANT TO RERUN FROM THE BEGINNING? N CO END OF JOB SO ENTER B IF YOU WISH TO BROWSE THE PRINT DATASET SO ENTER P IF YOU WISH TO RESTART AT THE BEGINNING SO ENTER P IF YOU WISH TO PRINT THE LISTING SO ENTER P IF YOU WISH TO END THE PROGRAM AND NOT SO ENTER P IF YOU WISH TO END THE PROGRAM AND NOT

You could Browse By pushing B.

\$ 13



Fronk

	58978							
	27090	SECTION	21012					
	NO.	X	997.0	This is	a listing	•		
	2	92	995.0	1 11/5 13	a 115/119			
	4	275	991.0	If I is Ke	ived and a			
	5	430	982.5	printer is	queilable,			
	78	472 487	979.5 982.5					
	9 10	510 ·	990.0 990.0					
	11	705	993.0					
	13	807	1000.9					
	14	990	1003.0					
÷.,	SLOPE I	N FEET/M	ILE 4	.750	· .			
	SECTION	DIST. 430 0	N VALUE	•				
	2 3	-510 0	030	•				
	5766 D	700 U	••••					
	997	LEV. LO	W ELEV. INCR 987.00 1.	EMENT 00				
	58978							
,			SECTION	DISCHARGE	VELOCITY	CONVEYANCE	N VALUE	
STAGE	ELEV.	987.00						
			1 2	O CFS BOS CFS	0.0 FPS 3.6 FPS	0 SQ. FT. 224 SQ. FT.	0 26832	0.070
			3 TOTAL	0 CFS 805 CFS	0.0 FPS 3.4 FPS	0 SQ. FT. 224 SD. FT.	0	0.070
	•							
STAGE	ELEV.	988.00		A 654				
			2	1114 CFS	3.9 FPS	286 SQ. FT.	37146	0.07
			3 Total	0 CFS 1114 CFS	0.0 FPS 3.9 FPS	0 SQ. FT. 266 SQ. FT.	37146	0.07
STAGE	ELEV.	989.00		A C55	0 0 595	A 50 ET	•	0 07/
			2	1488 CFS	4.2 FFS	355 SQ. FT.	49603	0.030
			TOTAL	0 CFS 1488 CFS	4.2 FPS	© SQ. FT. 355 SQ. FT.	0 49603	0.070
STAGE	ELEV.	990.00	•	0 CFS	0.0 FPS	0 SD. FT.	0	0.07
			·	, -			U U	••••
			i.					
			2	1930 CFS	4.5 FPS	431 SQ. FT.	64358	0.030
			3 TOTAL	0 CFS 1930 CFS	0.0 FPS 4.5 FPS	0 SQ. FT. 431 SQ. FT.	0 64358	0.070
		-	,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			0,000	x
STAGE	ELEV.	991.00		74 055	A . 595	77 60 ET	1070	D 010
			. 1	2563 CFS	5.0 FPS	514 SQ. FT.	85463	0.030
			TOTAL	40 CFS 2635 CFS	0.5 FPS 4.0 FPS	76 SQ. FT. 665 SQ. FT.	1345 87847	0.070
							`	
STAGE	ELEV.	992.00	1	192 CFS	0.7 FPS	265 SQ. FT.	6386	0.070
			2	3266 CFS	5.5 FPS	591 SQ. FT.	108875	0.030
			TOTAL '	3613 CFS	3.4 FPS	1056 SQ. FT.	120470	V.070
		A 1 1 1					·	
STAGE	ELEV.	YY3.00	1	492 CFS .	1.0 FPS	517 SQ. FT.	16394	0.070
			2 3	4035 CFS 363 CFS	6.0 FPS 1.0 FPS	671 SQ. FT. 370 SQ. FT.	134544	0.030
			TOTAL	4890 CFS	3 1 FPS	1559 SQ. FT.	163034	*****

									10.00					
			407	055	•	• •	505		517	5 61	ET.		16394	0.0700
•		1 2	472	052	•	4 4	FPS			50	FT.		134544	0.0300
		4 7	1033	655		1 0	566		370	.02	ET.		12097	0.0700
		TOTAL	4004	050		7 4	600		4880	50	ET.		163034	
		TOTAL		QF G		9.1	er 4		1.2.27			·	100404	
									1.1997		:			
STACE FLEV	994.00													
		• 1	989	CES		1.2	FPS		814	SQ.	FT.		32987	0.0700
		2	4868	CFS		6.5	FPS		751	SQ.	FT.		162317	0.0300
		3	708	CES		1.2	FPS		575	SQ.	ET.	· ·	23612	0.0700
		TOTAL	6566	CFS		3.1	FPS		2142	SD.	FT.		218915	
											·. ·.			
STAGE ELEV.	995.00						· .							
		1	1438	CFS		1.4	FPS		1140	SQ.	FT.		54608	0.0700
		2	5763	CFS		6.9	FPS		831	SQ.	FT.	S. 1. 1. 1.	192136	0.0300
		3	1157	CFS		1.4	FPS		800	SQ.	FT.		38566	0.0700
		TOTAL	8558	CFS		3.1	FPS		2772	50.	FT.		285310	
STACE ELEV	994 00										,			
SINGE CLEV.	770.00	4	2770	CES		1.4	FPS		1501	50.	ET.		79315	0.0700
		2	4717	CES		7.4	FPS		911	so.	FT.		223934	0.0300
		3	1740	CFS		1.7	FPS		1041	so.	FT.		58006	0.0700
		TOTAL	10835	CFS		3.1	FPS		3453	SQ.	FT.		361255	
							••••							
		•												
STAGE ELEV.	997.00													
· · ·		1	3290	CFS		1.7	FPS		1908	SQ.	FT.		109701	0.0700
•		2	7728	CFS		7.8	FPS		991	sa.	FT.		257649	0.0300
		3	2424	CFS		1.9	FPS		1292	20.	FT.	· .	80824	0.0700
		TOTAL	13442	CFS		3.2	FPS		4191	so.	FT.		448174	
			·											
			1.894		112.1									
DESIGN DISCH	1AUKE 3	200			• •			;						
STAGE ELLY.	773.41	*	504	CES		1.0	FPS		578	50.	FT		19481	0.0700
			4207	CES		Å. 4	FPS		A88	sõ.	FT.		140250	0.0300
		ž	427	CES		1.0	FPS		412	SQ.	FT.		14246	0.0700
		TOTAL	5218	CFS		3.1	FPS		1679	sq.	FT.		173977	
						,							-	
					50 A.									
			1 A A		1.14									

DESIGN DISCHAGRE	4200	` .		``	
STAGE ELEV. 992.50		-	· .		
	1	324 CFS	0.8 FPS	384 SQ. FT.	10791 0.0700
	2	3645 CFS	5.8 FPS	631 SQ. FT.	121509 0.0300
	3	247 CFS	0.9 FPS	279 SQ. FT.	8239 0.0700
	TOTAL	4215 CFS	3.3 FPS	1295 SQ. FT.	140539
·					

2.2.6. WSNAT

WSNAT

WATER SURFACE PROFILES

NATURAL CHANNEL CROSS-SECTIONS

2.2.6.1. Introduction

The "Water Surface Profiles - Natural Channel Cross-section" spreadsheet was developed to calculate the water depth along a natural channel. This type of cross-section is normally associated with creeks, streams and rivers.

This spreadsheet allows the user to calculate the backwater effects of structures located along the channel reach. It permits the user to calculate the tailwater depths of upstream structures.

The initial input consists of the energy coefficient, design flow, and the starting water depth elevation. One also needs to input a description of the channel cross-section. This entry data includes: the station distance from the first station, minimum channel elevation, maximum channel elevation, whether or not there is overbanking (on the left bank, on the right bank or on both banks), distance and elevation of the overbanking from a datum (if overbanking exists), and values that outline the channel. The channel is described as starting at a point on the left bank, setting that distance equal to zero and recording the elevation at that point. There is no limit to the number of cross-sections permitted.

Once the data are entered, the user must then interate the water surface elevation at each cross-section. This is done by entering a trial depth and checking whether or not it is an acceptable value (if not acceptable then input a new elevation; if acceptable then go to next station). The spreadsheet contains a cell that tells the user whether to increase or decrease the elevation. A check value is also entered for each iteration. This check value should approach 0.001 as the iterations are performed.

After all the cross-sections' water elevations have been iterated by the user, the final output can be printed for a paper record. Included in the output data

are the channel bottom elevation, water surface elevation, energy line elevation, water depth, and friction loss. From these data a water surface profile can be drawn and the water depths caused by the headwater can be evaluated.

2.2.6.2. Using the Spreadsheet

The best way to begin using a spreadsheet is to obtain all pertinent data, record the data in a form that is easily transferred into the spreadsheet, and then input the data into the spreadsheet. The data obtained in the field, from topographic maps, and engineering principles can be transferred to an input form. Once this is done the user can begin to manipulate the spreadsheet.

The first step in using the spreadsheet is to load it into the computer memory so that it can be operated under the control of Microsoft Multiplan. Assume that this spreadsheet resides on disk as a data file under the filename of WSTRAP1.MP and has been saved to disk in the Normal Mode. Once the file has been loaded into the computer, select the Options command from the Multiplan command menu and turn the Recalculation Mode of operation OFF. Next enter the project number, project name, preparer's name, checker's name, and dates prepared and checked. These entry items are located in rows 13 through 16 (see Figure 57). Once these administrative

data have been entered, the constant values in column 8, rows 20 through 22 (see Figure 57) can be entered. Values for the energy coefficient, entered in row 20, column 7, (see Figure 57) are given in Table 6. The starting water depth is typically headwater depth of the structure located where the first cross-section is located.

Table 6. Various values for the energy coefficient (after Chow, 1959).

Channels Value of t	he energy	coefficient		
	Minimum	Average	Maximum	
Regular channels, flumes, spillways Natural streams, and torrents	1.10	1.15	1.20	
Rivers under ice cover River valleys overflooded	1.20 1.50	1.50 1.75	2.00 2.00	

The next step is to input the data for each cross-section. The number of cross-sections are limitless. This is accomplished by allowing a newly created spreadsheet to copy data from a previous spreadsheet which contains the data from the previous downstream cross-section. Once a series of spreadsheets

have been created, the output from each is copied onto a summary output spreadsheet. The data needed to begin entering the cross-section is the cross-section shots.

An example of cross-section shots is depicted in Figure 58. The information therein illustrates how a person finds the offset and elevation at each shot. In addition to the elevation at each shot, a person needs to determine what is the Manning's roughness coefficient for each shot. The roughness coefficient is the one in the reach from the previous shot to the current shot. Besides the shot data, the user has to input the distance from the starting station to the station for which the data is being input, the minimum elevation of the channel cross-section.

The input data for the station distance from the starting point, minimum elevation, maximum elevation for the first cross-section are input in column 6, rows 61, 62, 63 respectively (see Figure 59). The data for the cross-section shots begin in row 63, columns 11 and 12, and end at row 83, columns 10, 11, and 12. A Manning's roughness coefficient is not needed for the first shot.

If overbank flow is a problem, an additional item of information is needed. An example of what is meant by overbank flow is illustrated in Figure 58. Users need to specify whether the overbanking will not occur, will occur on the left bank only, will occur on the right

bank, or will occur on both banks. The overbanking condition is identified by entering a 0 for no overbanking, a 1 for overbank flow on both banks, a 2 for overbank flow on left bank only, or a 3 for overbank flow on right bank only. This "flag" is entered in row 68, column 6 (for cross-section 1 only). The orientation of left and right is based upon the user looking upstream of the flow.

The highest cross-section shot in the channel reach before overtopping can occur needs to be entered. This input data inloudes the offset distance and elevation at the point of overtopping. The data input for cross-section 1 is entered in columns 6 and 7, rows 76 and 77.

Once all the data listed above have been entered for cross-section 1, repeat the input process for cross-section 2 (see Figure 57). The basic input is entered in rows 70 through 92, column 6. For the cross-section, begin entering data in row 92, columns 11 and 12. The overbanking entry begins in column 6, row 97. Once this process is complete for cross-section 2, proceed to cross-section 3. The data input for the third cross-section is located between rows 115 and 143 in a similar fashion to cross-section 2. (Additional cross-sections are entered by creating more spreadsheets, such as WSNAT2.MP, which can contain three more cross-sections each and continuing on with an "external

copy" capability. Consult the Microsoft Multiplan Manual.)

When all the cross-sections have been entered, the spreadsheet is ready for computation and the iteration process can begin. The water surface elevation for the first cross-section is automatically transferred from the constant value previously entered in row 22, coumn 8 (see Figure 57). The user then begins the iteration process at cross-section 2. A person first enters a trial water elevation in column 8, row 28 (see Figure 60). Once a water elevation is entered a "(+)" or a "(-)" will appear in row 31 below the water surface number just entered. If it is a "(+)" then the water surface elevation should be increased to achieve closure in the iteration process. If the indicator is a "(-)" then the water surface elevation should be decreased.

The method for finding the water surface is based on the standard step method presented by Chow (1959). This method is based on the fact that the total head at the current cross-section is equal to the total head at the previous cross-section plus the friction head plus the eddy losses. For convenience of computation, the eddy losses can be considered part of the friction loss (Chow, 1959). The check value in row 32 is the difference between the total head at the current cross-section and the total head plus the friction loss at the previous cross-section. As the check value becomes smaller, the

precision of the method increases. For this spreadsheet, the recommended precision is such that the value in row 47 becomes 0.000 or a very small minimum value.

Once the water surface elevation is at a satisfactory precision level, proceed to cross-section 3 (row 28, column 9) and repeat the process. For a problem encompassing three cross-sections, this would complete the spreadsheet. To continue on to more cross-sections beyond three, the user will have to use a second spreadsheet file, such as WSNAT2.MP, and employ the Multiplan "extenal copy" capability to bring the intermediate results from WSNAT1.MP into WSNAT2.MP. In this fashion, the process can be extended indefinitely. If only three cross-sections are needed to satisfy the hyraulic analysis for this project, the user can review the output at this time.

The output data for cross-sections 1, 2, and 3 can be found in rows 143 through 153. To "jump" to this portion of the spreadsheet, select the Goto command from the Multiplan command menu, then select the Name subcommand within the Goto command, and finally enter the name OUTPUT (press <return> or <enter> key to complete the command). This will move the cell pointer directly to the output area of the spreadsheet.

The spreadsheet should now be saved as a data file for later use. If additional cross-sections are to be incorporated in this analysis, name the spreadsheet when
saving it in some fashion that identifies the spreadsheet as containing cross-sections 1-3.

For purpose of explaining how to continue on to cross-sections 4 through 6, the data for the first three cross-sections will be assumed to be saved as EXAMPLE. The first step in continuing to cross-section 4 is to load the spreadsheet W5NAT2.MP into memory to bring it under the operational control of the Multiplan program. Once this is done, enter the identification data in rows 13 through 16. Then move to the cell located in row 26, column 7. This cell (R26C7) is located just below where the spreadsheet displays the message "Transfered Cells".

The user can now copy the necessary data from the spreadsheet template created for cross-sections 1 through This is accomplished by using the XTERNAL/COPY 3. command sequence from the Multiplan command menu. While the Multiplan command menu is displayed on the screen, press X or move the command cursor over to XTERNAL and press <return>. Multiplan will then display the subcommands under the XTERNAL command. One of these subcommands indicated will be COPY. As before, either press C or move the command cursor to COPY and press <return>. Multiplan will then bring up the prompts to identify from where the "external copying" is to be done. The user must enter the name of the spreadsheet from which the data is to be pulled and the name of the block of cells (or the row:column range) in which the data

resides.

It was assumed for this discussion that the first three cross-sections were saved as a data file named EXAMPLE. Thus, for naming the spreadsheet from which data is to be copied, the user would enter EXAMPLE if the file is stored in the default drive, enter B:EXAMPLE if the file is stored on a disk in Drive B, or enter pathname\EXAMPLE is the file is located in a hard disk directory. The name of the cells where the data to be copied is located has already been "named" TRANSFER, hence the user will always enter the name of the cells as TRANSFER to complete the "external" reference. Once this is done, tab twice to the "linked" subsubcommand prompt and set it to NO. This completes the set up for copying the previous output data as initial starting data into the continuation spreadsheet, so press <return> to begin the transfer of data from EXAMPLE into WSNAT2.MP.

Once the transfer is complete, the user then enters the cross-section data for the next three cross-sections. This data input begins in row 56. The input requirements and location of data entry is exactly the same as that for cross-sections 1 through 3, except that one needs to enter the sequential cross-section number "Station distance from the starting station" in rows 58, 70, and 88. When all the cross-sectional entries are complete go to row 27, column 8 and iterate the water surface elevation for each of the three cross-sections in this

spreadsheet. This procedure is the same as that which was employed for the first three cross-sections.

After completing the spreadsheet for cross-sections 4 through 6, the user should save the file. If additional cross-sections are to be analyzed, make a note of the filename (include a coded reference to sections 4-6), load a copy of WSNAT2.MP again to repeat the data entry process for cross-sections 7-7. Now the data is copied from the file containing cross-sections 4-6. In this manner the process can be extended indefinitely. An example of a spreadsheet created to provide the summary output is shown in Figure 61.

2.2.4.3. <u>Reference</u>

Chow, Ven Te, <u>Open-Channel Hyraulics</u>, McGraw-Hill, Inc. New York, 1959, pp. 27-28, 249-289. Figure 57. Input of Administrative Data for WSNAT

2 1 З 4 5 6 7 8 2 WATER SURFACE PROFILES - NATURAL CHANNEL CROSS-SECTIONS з STARTER SHEET 5 ************ 6 Multiplan Microcomputer Spreadsheets for County + 7 Hydraulic and Highway Engineering Computations -ន Copyright by Rocky J. Keehn 9 All Rights Reserved, 1986 10 Version 1.1 11 ********************************** +++++ 12 13 Project Number: 14 Project Name : 15 Prepared By Date: 2 16 Checked By Date: 2 17 -----18 INPUT - constant variables 20 Energy coefficient, unitless 21 Design flow, cfs = 22 Starting water depth elevation, feet . 122



Figure 59. WSNAT Spreadsheet Format

	1	2	3	9	2		b	1	8	9	10	11	12	14
56			~~~~~											*****
-37 50	110117 BA1	FILUN L FA "DACT	c10						LKU55-5	EULIUN I Crocemene	tion inf			•
59	444444444	IM - DAU1 64444444	6°0 444						1115 U 1 -	01 U33-366 ********	11071 LILI 144644444	444 444		
60		Station	dist	ance	from							Distance	Elev	1
61		sta	rtina	BOIN	t (ft)) =	0			Data poi	nt	(feet)	(feat)	1
62		Minimum	elev	ation	(ft)		882			,	Mannin	q's		+
63		Naxiaum	elev	ation	(ft)	=	900			. 1 -	>	0	900.00	1
64		Slope (ft/mi)		= 4	42.24			2 -	-> 0.	03 20	890.00	1
65										, 3 -	-> 0.	03 80	882.00	:
65										4 -	-> 0.	03 220	890.00	:
67		Input o	n of	the f	ollovi	ing of	ptions	it		5 -	-> Q.	03 270	900.00	ł
68			Inpu	t (0-	·3)	>	0			6 -	->			1
69		0	- no	overb	ank fl	lov				7 -	->		. · ·	l
70		1	- ove	rbank	flow	both	banks	•		8 -	·->		•	
11		2	- ove	rbank	tiow.	left	bank			9 -	·>	· .		1
12		3	- ove	rbank	HOV	right	t bank		÷	. 10 -	·>	.'		ļ
13									·	11 ~	·->			i
/9 75										-12 -	·			1
76										- 13 -				+
77										15 -				
78	OUTPUT:									15 -	->			1
79	******									17 -	·->			i
80		Hydraut	ic ra	dius		#	3.0	feet		18 -				i
81		Water d	eoth			=	6.0	feet		19 -				
82		Water e	levat	ion		=	888	feet		20 -	- - > /			1.
83		Slope				= (0.008	ft/ft						t
84:		Weighte	d Han	ning'	5 N	= (0.030			Suss:)	
83	********													
80	CROSS-SEC	TION 2			(· · · · · · · · · · · · · · · · · · ·	CROSS-S	ECTION 2		****		
80 86 87 87	CROSS-SEC	TION 2 A - BASI	C'S		(••••••••••••••••••••••••••••••••••••••	. منه این خد س ده چه چه ده .	CROSS-S Input -	ECTION 2 Cross-sec	tion inf	078	- 440 Alexandro ang	•••••
85 86 87 88	CROSS-SEC INPUT DAT	TION 2 A - BASI	C'S			n m m m m e			CROSS-S INPUT -	ECTION 2 Cross-sec	tion inf	orn 	£1	·
80 86 87 88 89 90	CROSS-SEC INPUT DAT	TION 2 A - BASI Station	C'S dist	ance	fron		170		CROSS-S INPUT -	ECTION 2 Cross-sec	tion inf	orm Distance	e Elev (feat)	
85 86 87 88 89 90 91	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta	C'S dist rting	ance poin	from t (ft)) =	170		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi	tion inf	Distance (feet)	e Elev (feet)	
83 86 87 88 89 90 91 91	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum	C'S dist rting elev	ance poin ation	from 1t (ft) 1 (ft)) =	170 883 900		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi	tion inf nt Mannin	Distance (feet) 19's	Elev (feet)	
83 86 87 88 89 90 91 92 93	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum	C'S dist rting elev elev	ance poin ation	from it (ft) i (ft) i (ft)) = = =	170 883 900		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 -	tion inf nt Mannir	Distance (feet) 19's0 03 20	Elev (feet) 900.00	
83 86 87 88 89 90 91 92 93 94	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum	C'S dist rting elev elev	ance poin ation ation	from it (ft) i (ft) i (ft)) = = =	170 883 900		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 -	tion inf nt Mannir > > 0. > 0.	Distance (feet) 19's .03 20 .03 55	Elev (feet) 900.00 890.00 5 883.00	
85 86 87 88 90 91 92 93 94 95	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum	C'S dist rting elev elev	ance poin ation ation	from it (ft) i (ft) i (ft)) = = =	170 883 900		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 -	tion inf nt Hannir > 0. > 0. > 0. > 0.	Distance (feet) 19's 03 20 03 55 03 150	Elev (feet) 900.00 890.00 883.00 890.00	
80 86 87 88 90 91 92 93 94 95 96	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o	C'S dist rting elev elev	ance poin ation ation	from it (ft) i (ft) i (ft) i (ft)) = = =	170 883 900 ptions		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 -	nt Mannir >	Distance (feet) 9's0 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 89 90 91 92 93 94 95 96 97	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o	C'S dist rting elev elev n of Inpu	ance poin ation the f t (0-	from t (ft) (ft) (ft) (ft) ollovi 3)) = = = ing oj >	170 883 900 ptions 0	1	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 -	tion inf Mannir > 0. > 0. > 0. > 0. > 0.	Distance (feet) 99's0 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 94 95 95 97 98	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o	C'S dist rting elev elev n of Inpu - no	ance poin ation the f t (O- overb	from it (ft) i (ft)) = = = ing oj >	170 883 900 ptions 0	1	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 -	nt Hannir > 0. > 0. > 0. > 0. > 0. > 0. > 0.	Distance (feet) 9's0 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
83 86 87 88 90 91 93 94 95 96 97 98 99	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o 0 1	C'S dist rting elev elev n of Inpu - no - ove	ance poin ation the f t (O- overb rbank	from it (ft) i (ft) i (ft) i (ft) i (ft) i (ft) i (ft) i (ft) i (ft) i (ft)) = = = ing oj > low	170 883 900 ptions 0 banks		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 -	nt Mannir -> 0. > 0. > 0. > 0. > 0. > 0. > 0. > 0. > 0.	Distance (feet) 9's 03 20 03 55 03 150 03 200	e Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 94 95 97 98 99 9100	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2	C'S dist rting elev elev n of Inpu - no - ove - ove	ance poin ation the f t (O- overb rbank rbank	from it (ft) (ft) (ft) (ft) (ft) (ft) (ft) (ft)	ing oj > low left	170 883 900 ptions 0 banks bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 -	nt Mannir > 0. > 0.	Distance (feet) 19's 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 95 97 98 97 98 99 100	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2 3	dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) i () = = = low both left	170 883 900 ptions 0 banks bank t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 -	at Mannir > 0. > 0. > 0. > 0. > 0. > 0. > >	Distance (feet) 9's 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 94 95 97 99 90 100 101	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2 3	dist rting elev elev elev n of Inpu - no - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) i (ft)) = = = > low both left right	170 883 900 ptions 0 banks bank t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 -	at Hannir > 0. > 0. > 0. > 0. > 0. > > > > >	Distance (feet) 9's 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 93 94 95 97 99 91 00 101 102	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Naximum Input o 0 1 2 3	C'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation the f t (0- overb rbank rbank	from t (ft)) = = = low both left right	170 883 900 ptions 0 banks banks t bank		CROSS-S INPUT -	Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 -	tion inf Hannir > 0, > 0, > 0, > 0, > 0, >> >	Distance (feet) 9's0 03 20 03 55 03 150 03 200	e Elev (feet) 9 900.00 9 890.00 5 883.00 9 890.00 9 900.00	
83 86 87 88 90 91 93 95 97 99 90 100 101 102 103	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Maximum Input o 0 1 2 3	C'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation the f t (0- overb rbank rbank	from t (ft)) = = = low both left right	170 883 900 ptions 0 banks banks t bank		CROSS-S INPUT -	Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 10 - 11 - 12 - 13 - 10 - 11 - 11 - 12 - 13 - 13 - 14 - 14 - 15 - 16 -	tion inf Hannir > 0. > 0. > 0. > 0. > 0. >> >	Distance (feet) 9's0 03 20 03 55 03 150 03 200	e Elev (feet) 900.00 890.00 883.00 990.00 900.00	
85 86 87 88 90 91 92 93 95 96 97 98 99 90 100 101 102 103	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Maximum Input o 0 1 2 3	C'S dist rting elev elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) (ft) (ft) (ft) (ft) (ft) (ft) (ft)) = = = low both left right	170 883 900 ptions 0 banks banks t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 14 -	tion inf Mannir > 0. > 0. > 0. > 0. > 0. >> >> >	Distance (feet) 9's0 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 94 95 97 99 90 101 102 103 104 105	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Maximum Input o 0 1 2 3	C'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) (ft) (ft) (ft) (ft) (ft) (ft) (ft)) = = = low both left righ	170 883 900 ptions 0 banks banks t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 14 - 15 -	tion inf Hannir > 0. > 0. > 0. > 0. > 0. > 0. >> >> >>	0rm Distance (feet) 97's0 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 93 95 97 99 90 100 101 102 103 104 105 107	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o 0 1 2 3	C'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) i () = = = low both left right	170 883 900 ptions 0 banks bank t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 14 - 15 - 16 - 15 - 16 -	tion inf Hannir > 0. > 0. > 0. > 0. > 0. > 0. >> >> >> >	Distance (feet) 9's 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 93 95 97 98 90 101 102 103 104 105 107 108	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o 0 1 2 3	C'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank	from it (ft) i () = = = low both ieft	170 883 900 ptions 0 banks bank t bank		CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 11 - 12 - 13 - 14 - 15 - 16 - 17 -		Distance (feet) 9's0 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 95 97 99 90 101 102 103 104 105 107 108	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Maximum Input o 0 1 2 3 3	c'S dist rting elev elev n of Inpu - no - ove - ove - ove	ance poin ation ation the f t (0- overb rbank rbank rbank	from it (ft) (ft) (ft) (ft) (ft) (ft) (ft) (ft)) = = = = = = = = = = = = = = = = = = =	170 883 900 ptions 0 banks bank t bank	feet	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 14 - 15 - 16 - 17 - 18 - 17 - 18 -		Distance (feet) 9's 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 95 97 99 90 100 101 103 104 105 108 100 110	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2 3 3 Hydraul Water d	C'S dist rting elev elev n of Inpu - no - ove - ove - ove ic ra epth	ance poin ation ation the f t (0- overb rbank rbank dius	from it (ft) i () = = = = = = = = = = = = = = = = = = =	170 883 900 ptions banks bank t bank t bank	feet	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 11 - 12 - 13 - 14 - 15 - 16 - 17 - 18 - 19 -	nt Mannir > 0. > 0. > 0. > 0. > 0. > 0. > 0. > > > > > > > > > > > > > > > >	Distance (feet) 9's 03 20 03 55 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 95 97 99 90 100 101 102 103 105 107 108 100 111 112	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2 3 3 Hydraul Mater d Vater e Sion	C'S dist rting elev elev n of inpu - no - ove - ove - ove ic ra epth levat	ance poin ation the f t (O- overb rbank rbank rbank dius ion	from it (ft) i () = = = = = = = = = = = = = = = = = = =	170 883 900 ptions 0 banks bank t bank t bank t bank	feet feet feet	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 11 - 12 - 13 - 14 - 15 - 16 - 17 - 18 - 19 - 20 -	at Mannir > 0. > 0. > 0. > 0. > 0. > 0. > > > <tr< td=""><td>Distance (feet) 9's 03 20 03 150 03 200</td><td>Elev (feet) 900.00 890.00 883.00 890.00 900.00</td><td></td></tr<>	Distance (feet) 9's 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 890.00 900.00	
85 86 87 88 90 91 92 93 95 97 99 90 100 101 102 106 107 108 110 111 1112	CROSS-SEC INPUT DAT	TION 2 A - BASI Station sta Minimum Naximum Input o 0 1 2 3 3 Hydraul Mater d Vater e Slope Vaidbio	C'S dist rting elev elev n of inpu - no - ove - ove - ove - ove ic ra epth levat	ance poin ation the f t (0- overb rbank rbank dius ion	from it (ft) i () = = = = = = = = = = = = = = = = = = =	170 883 900 ptions banks bank t bank t bank t bank	feet feet feet ft/ft	CROSS-S INPUT -	ECTION 2 Cross-sec Data poi 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9 - 10 - 11 - 12 - 13 - 14 - 15 - 16 - 17 - 18 - 19 - 20 - Super	at Mannir > 0. > 0. > 0. > 0. > 0. > > > <t< td=""><td>Distance (feet) 9's 03 20 03 150 03 200</td><td>Elev (feet) 900.00 890.00 883.00 990.00 900.00</td><td></td></t<>	Distance (feet) 9's 03 20 03 150 03 200	Elev (feet) 900.00 890.00 883.00 990.00 900.00	

Figure 59.

	Í	2	34	5	6	7	- 8	9	10	11	12	13
115	CROSS-SEC	TION 3					CROSS-S	ECTION 3				
116	INPUT DAT	A - BASIC'S	3				INPUT -	Cross-sectio	n inform			1
117	*********	و کو کہ خو کہ یہ در در در در در عم عل کر در	Y				*****	• • • • • • • • • • • • • • • • • • • •	*****			1
118		Station di	stance	from					· · · · .	Distance	Elev	l
119		starti	ng poi n	t (ft)	= 360			Data point		(feet)	(feet)	ł
120		Minimum el	evation	(ft)	= 884			l I	lanning's	****		ţ
121		Maximum el	evation	(ft)	= 890			1>		0	900.00	ł
122								2>	0.03	40	890.00	ł
123								3>	0.03	70	884.00	ł
124								4>	0.03	110	890.00	1
125		Input on c	of the f	ollovi	na options:			5>	0.03	170	900.00	ł
126		In	out (0-	3)	> 0			5>		1		t
127		0 - n	o overb	ank fl	ov			7>				Ì
128		1 - 0	verbank	flow	both banks			8>				1
129		2 - 0	verhank	flow	left hank			9>				i
130		3 - 0	verbank	flow	right hank			10>				÷
131					cogine wome			11>				i
132					1			12 >				1
133								12				
124								14		÷		1
125	· .				·			17 ·····7	•			1
130		н. А. А.						10>				; ;
127	******	· · ·						10/				1
107		Nude and i.e.	radiur		- 174			17		L . 4		i
190 190		ulan yang ang ang ang ang ang ang ang ang ang	rauius.			184 		18 >		• •	1.	i
197		Water Dept	a a baran sa		- J,4 (6	181 - 1		13>				i
140	· · · · ·	waver elev	avion			et .		20>				I
191	2	210be			≈v.vv388 ft	/11		-				ł
142		Weighted N	lanning"	5 N	= 0.030			Sunst -)	ł

(Continued)

	t	2	3	4	5	6	7	8	9.	10	11
23 - 24 I 25	NPUT -	Self-inte	ratio	1		******					Transfer Cells
26		•		. C	ROSS-SE	CTIONS ~	- 1	2	3		3
27	**	Input you	rselt	++ 1.		CT) -	000	000	007 A	i	007 4
20 20		Wdser b	uriaci	. 616	VALUA	(r)) =	000	000	00/+4	1	00/.4
30	++	Halnful ()	utout	44					and the second	1	
31		Increas	a (+)	or d		(-)			$\{ (1,1), (1,1)$	1	
32		LINCE CALL	ter si	ir fac	a alav.	. , =	start at	(-)	(-)		(-)
33		Check v	alue (lok i	f <= +/-	.001)=	X-sectio	n 0.001	0.144	1	0.1436316
34					•••		~ #66114		****		
35 -				Ir dat oc da da		********			 A ser ala una ana ana ang Milana an		
36 C	ALCULA	TIONS					. •		· · ·	1	
37 ~	*****	****								i	
38		X accum	lative	e (FT)	:	= 0	170	360	1	360
39		Delta X	(FT)			:	= 0.0	170.0	190.0	ţ	190
40		Channel	botto	m el	evation	:	882.000	883.000	884.000	1	884
41		Channel	rise			:	= 0.000	1.000	1.000	ł	1
42		Accumla	tive o	:hann	el rise	:	= 0.000	1.000	2.000	1	2
43		Average	chann	iel s	lope (ft	:/ft) =	• 0.0059	0.0059	0.0053	1	0.0052632
44		Calcula	ted Fl	ov D	epth (F1) =	= 5,00	5.00	3,40	1	3.4
45		Flow ar	ea (so	į. ft	.)	:	= 450.0	232.1	67.4	i	67.433333
46		Hydr aul	ic Rad	lius	(FT)	3	= 3.0	2.5	1.7	1	1.6750746
47		Calcula	ted Ve	loci	ty (FPS)	i 1	- 1.1	2.2	7.4	1	7.4147306
48		alpha ¥	V^2 /	' 2g			= 0.0	0,1	0.9	~ 1	0.939828
49		Hi elev	ation	(FT)		1	888.021	888.079	888.340	1	888.33983
50		Hydraul	ic Rad	lius	^ 4/3	:	: 4.3	3.4	2.0	1	1.9893545
51		Weighte	d Nann	ing'	5 A	3	= 0.030	0.030	0.030	1	0.03
52		Frictio	n Slop	ie, S	f		0.00012	0.000560	0.011204	1	0.0112039
53		Average	Sf			=	0.00012	0.000338	0.005882	1	0.0058818
54		Frictio	n head	l 105	s, hi (f	4) ÷	• 0.000	0.057	0.118	· 1	0.1176357
55		H2 elev	ation	(FT)		:	888.021	888.079	888.196	1	888.1962

Figure 60. WSNAT Iteration Illustration

i	2	3	4	5	6	7	8	9	10	11	12	13	14	15
143				. Al 1 Al			a alah mga diper maip da							
145 *****	\$\$ RESUL	TS \$7			ł	Channel	1	Water	T	Energy	1	Water	1	Friction
146	Cross-				ł	Bottom	1	Sur face	· 1	Line	1	Depth	:	Loss
147	Sect. S	tatio	on		I.	Elevation	1	Elevation	1	Elevation	1	(feet)	1	(feet)
148	Number				ł	(feet)	f	(feet)	ł	(feet)	l		1	
149				*****	ł	****	1	میں این جب جب ہے جب خب خان خان	ł		1		ł	
150	1	0	ŧ	0.00	;	882.00	ł	888.00	ł	888.02	ľ	6.00	!	0.000
151	2	1	ŧ	70.00	E T	883.00	ţ	888.00		888.08	1	5.00	ł	0.057
152	3	3	÷	60.00	ł	884.00	1	887.40	ł	888.20	I	3.40	ł	0.118
153				****								ا الله ميد بيد ميد باد غاز هد الله ا		******
ه									· ·					-

Figure 61. Example Output for Summary of WSNAT

APPENDIX

USER REFERENCE INSTRUCTIONS FOR KERMIT

Public Domain Communication Software



URM: Users' Reference Memo

URM 142

Using KERMIT

March 1987 (revised)

By Jeff Balvanz and Ruth Schlotfeldt (Revised by Jeff Balvanz)

Overview

KERMIT is a communications protocol originally developed at Columbia University. This protocol has been incorporated into public domain communications programs for a wide variety of microcomputers, minicomputers, and mainframes. At ISU, versions of KERMIT are available for the NAS AS/9160, VAX, Apple //e, Zenith Z-100, IBM PC, TI PC, Commodore 64, and CP/M computers. Microcomputer versions may be acquired at the Microcomputer Product Center, 125 Computer Science. These diskettes include additional version-specific information which is not described in this publication.

KERMIT can be used as a terminal emulator allowing you to communicate with any host computer system. Two computers running KERMIT can exchange files over an RS-232 connection using an error-checking system. Such transfers are very reliable.

Copyright © 1987 by Iowa State University

Permission to reproduce all or part of this document for noncommercial purposes is granted, provided the author and Iowa State University are given credit. To copy otherwise requires specific permission.

Some material in this publication has been adapted from the KERMIT User's Guide prepared by Columbia University and the KERMIT-65 documentation prepared by Stevens Institute of Technology.

KERMIT is a registered trademark of Henson Associates, Inc., and is used in this context by permission.

URM 142 Page 2 ---- Using KERMIT

1. GETTING STARTED

Note: All commands must be followed by pressing the <return> key.

To run KERMIT on your microcomputer, enter the following command(s):

CP/M or MS-DOS:	KERMIT
Apple][:	RUN KERMIT
Commodore 64:	LOAD "KERMIT",8

The prompt "KERMIT-xx>" will appear on the screen, where "xx" depends on the version of KERMIT you are running.

Version	Prompt
MS-DOS	KERMIT-MS
CP/M-80	KERMIT-80
Apple //e	KERMIT-65
Commodore 64	KERMIT-65

At this point you are in local mode. You can enter commands or enter "? <return>" for a command list. To get help with commands, enter a question mark at any point in the command. KERMIT will display the options available. Commands can be abbreviated to any prefix that is unique. (Example: DIR is a unique prefix, so it may be used instead of DIRECTORY in KERMIT commands.) Refer to the section entitled "KERMIT Commands" for details on commonly-used commands.

If you are going to log in to VAX or WYLBUR via a dialup or the ISN, you will have to enter the command:

SET PARITY NONE

before connecting to the remote computer. Without this step, file transfers will not work. MS-DOS users communicating with WYLBUR should enter the commands:

SET HANDSHAKE NONE SET FLOW-CONTROL NONE

to get file transfers to work properly. KERMIT-MS allows you to put lists of commands into a TAKE file; see the KERMIT-MS documentation for more details.

To connect to VAX or WYLBUR, you must leave local mode and go into connect mode. To do this, enter CONNECT and press <return>. You can now dial the phone or give dialing commands to a direct-connect modem and log in as usual. For more details on logging in to WYLBUR or VAX, see URM 39 "Login Procedure for VAX, EVAX and WYLBUR".

URM 142 --- Page 3

Before you can transfer files, you must leave connect mode. Do this by entering a special character called an escape character, followed by the letter C. The default escape characters are as follows (hold the control key down, then press the appropriate character):

MS-DOS:	<ctrl]=""></ctrl>
Apple CP/M:	<ctrl]=""></ctrl>
Other CP/M:	<ctrl \=""></ctrl>
Apple][:	<ctrl @=""></ctrl>
Commodore 64:	<ctrl y=""></ctrl>

To leave connect mode on an MS-DOS machine, for example, you would press <ctrl/]>C. The escape character also performs other functions. To send a break, enter the escape character followed by the letter B. If you need to send the escape character to the remote computer, press the escape character twice.

2. TRANSFERRING FILES

To transfer files between two computers using KERMIT, both computers must be running a KERMIT program. There are two ways to transfer files. The first uses the SEND and RECEIVE commands, and the second uses the SERVER mode and the SEND and GET commands. Using the server mode is easier, but not all KERMITs can act as or work with a server.

2.1 Using KERMIT with the AS/9160 -- SEND and RECEIVE

KERMIT on the AS/9160 runs under the ORVYL file system. As a result, it cannot directly transfer WYLBUR edit format files, but can transfer ORVYL files and the active file. To run KERMIT on the AS/9160, enter:

KERMIT

which displays the "KERMIT-ORV>" prompt. You can still issue some WYLBUR commands by preceding the command with the word WYLBUR. To leave KERMIT and return to WYLBUR, enter EXIT.

Not all microcomputer files can be uploaded to WYLBUR. Files to be uploaded must have lines no more than 235 characters long. Also, ORVYL KERMIT cannot transfer non-text or binary files. **WARNING:** Because it runs under the ORVYL system, using ORVYL KERMIT is expensive. If there is another error-checking method of transferring files to WYLBUR available for your microcomputer (such as SAMSON) we recommend that you use it.

2.1.1 Downloading a WYLBUR File

To download a WYLBUR file, follow these steps:

1. Load the file to be downloaded into the WYLBUR active file by entering:

WYLBUR USE filename CLEAR

URM 142 Page 4 -

where "filename" is the WYLBUR filename.

2. Enter the ORVYL KERMIT command:

SEND filename

where "filename" is the name that you want the file to be stored under on your microcomputer diskette. (It does not have to be the same as the WYLBUR filename.)

3. Return to local mode by entering the escape sequence for your version of KERMIT. Then enter:

RECEIVE

The status screen on your microcomputer will display information about the number of packets transferred.

4. When the transfer is completed, enter CONNECT to return to connect mode.

2.1.2 Transferring a Microcomputer File

To transfer a microcomputer file to the WYLBUR active file, follow these steps:

1. You should be in connect mode with ORVYL KERMIT running. Enter the command:

WYLBUR CLEAR ACTIVE

to clear the active file. If you don't clear the active file before the transfer begins, the information transferred will be added to whatever is currently in the active file. (This can be used effectively to combine several small micro-computer files into one WYLBUR file.)

2. Enter:

RECEIVE

3. Exit to local mode and enter:

SEND filename

- where "filename" is the name of the microcomputer file to be transferred. You will see the status screen display information about the packets being transferred.
- 4. When the transfer is completed, enter CONNECT to return to connect mode. The text is in the WYLBUR active file and may be SAVEd or PUT as usual.

2.1.3 Transferring ORVYL Files Directly

ORVYL KERMIT can be used to transfer ORVYL files directly. Give ORVYL KERMIT the command:

SET FILE-MODE ORVYL

Now the KERMIT-ORV command "SEND filename" can be used to transfer the ORVYL file named "filename". The RECEIVE command stores the file as an ORVYL file with the same name as the microcomputer file. If your microcomputer's KERMIT accepts wildcards in file specifications, you can use "SEND *.*" to transfer many files with only one RECEIVE command.

2.2 Using KERMIT with VAX -- SERVER Mode

On VAX, KERMIT is located in TESTLIB:. To run it, enter:

RUN TESTLIB:KERMIT

at the VAX "\$" prompt. VAX KERMIT then displays the "KERMIT-32>" prompt. You can execute many VAX commands by preceding the command with the word "LOCAL". To leave KERMIT and return to VAX, enter EXIT.

WARNING: VAX KERMIT has not yet been updated to allow the extended filenames that can be used in VMS Version 4. As a result, files to be transmitted must have a filename no more than eight characters long and a file type no more than three characters long.

VAX KERMIT can act as a KERMIT server. You can SEND files to the server or GET files from the server without having to leave local mode. To activate VAX KERMIT's server mode, enter:

SERVER '

at the "KERMIT-32>" prompt. Now you can return to local mode and use server commands. To send files to VAX, enter:

SEND filename

To transfer VAX files to your microcomputer, enter:

GET filename

When you are finished transferring files, enter the microcomputer KERMIT command: FINISH. CONNECTing now returns you to the KERMIT-32 command prompt. Enter the EXIT command to return to the VAX "\$" prompt.

If your microcomputer's KERMIT is not capable of sending server commands, you can use SEND and RECEIVE commands to VAX KERMIT to transfer VAX files in the same way that ORVYL KERMIT transfers ORVYL files.

URM 142 - Page 5 URM 142 Page 6 ----

2.3 Microcomputer-to-Microcomputer Transfers

To send a file from one microcomputer to another, each must start in local mode. Issue the RECEIVE command at the receiving microcomputer. When the transfer status screen appears on the receiving computer, give the SEND command to the sending microcomputer by entering:

SEND filename

KERMIT displays a running total of the packets transferred along with any errors encountered. When the transfer is complete, both microcomputers return to local mode.

MS-DOS KERMIT can act as a server. Put KERMIT-MS into server mode by entering the SERVER command. You can then use the same commands to transfer files to and from that microcomputer that you would use with the VAX KERMIT server. You can either enter FINISH on the other microcomputer or press <ctrl/C> on the MS-DOS microcomputer to end server mode.

3. KERMIT COMMANDS

In addition to the commands discussed so far, other KERMIT commands can be used to set communications parameters or accomplish special tasks. The commands in the following list are some of the more useful KERMIT commands. They may not work on all versions of KERMIT. If you try to use commands that are not available, your KERMIT responds with "Illegal command" or "Not implemented." For a complete list of microcomputer KERMIT commands, see your microcomputer's KERMIT documentation.

- DIR [drive]: Displays the directory of the diskette in "drive". This is not available in Apple KERMIT. In C-64 KERMIT, you must enter "DIR *".
- HELP: Displays a summary of KERMIT commands.
- EXIT: Exits from KERMIT to your operating system. QUIT is a synonym for EXIT.
- SET: Modifies various file transfer and terminal parameters. The following parameters can be set:
 - DEFAULT-DISK parameter: Tells KERMIT which disk drive should be used for file transfers. Apple KERMIT allows you to set default SLOT and DRIVE.
 - DEVICE-DRIVER parameter: Tells Apple KERMIT-65 what type of communication card is being used. The following are valid parameters:

APPLE-COM-CARD	Apple communications card (or	compatible)
DC-HAYES	D. C. Hayes Micromodem II	
SUPER-SERIAL-CARD	Apple Super Serial Card	

URM 142 - Page 7

- FILE-BYTE-SIZE parameter: Sets the byte size (SEVEN-BIT or EIGHT-BIT) for file transfers with KERMIT-65.
- FILE-TYPE parameter: Tells KERMIT-65 what type of file is being transferred so it can do any character conversion necessary. Apple KERMIT accepts the following types:

TEXT	ASCII text file (the default)
APPLESOFT	Applesoft Basic program
INTEGER	Integer Basic program
BINARY	Binary image

C-64 KERMIT accepts the following types:

PETASCI	CBM ASCII file (the default)
ASCII	True ASCII file
SCRIPT	SpeedScript document file
BINARY	Program file (BASIC or machine language)

- FILE-WARNING ON or OFF: Tells KERMIT whether or not to warn you when incoming filenames conflict with existing files. When FILE-WARNING is ON, KERMIT tries to change the filename slightly to avoid the conflict.
- *DISPLAY parameter*: Tells Apple KERMIT-65 whether you have an Apple][+ (parameter = 2P) or Apple //e (parameter = 2E) monitor. Only the 40-column display is supported.
- KEYBOARD parameter: Same as DISPLAY command above for the Apple keyboard.
- LOCAL-ECHO parameter: Sets full duplex (LOCAL-ECHO ON) or half duplex (LOCAL-ECHO OFF).
- PARITY: Sets parity to NONE, EVEN, ODD, MARK, or SPACE.
- RECEIVE: Sets various parameters for receiving files.
- SEND: Sets various parameters for sending files.
- SLOT parameter: Tells Apple KERMIT-65 in which slot the communications card is located (normally 2). The range for the parameter is 1-7.
- SHOW parameter: Examines the current parameter values. You can SHOW the value of any parameter which can be SET. In addition, SHOW ALL shows the current settings of all parameters in KERMIT-65.
- STATUS: Gives statistics about the most recent file transfer (KERMIT-65), or shows the current parameter settings (MS-DOS).

URM 142 Page 8 ----- Using KERMIT

4. HELP

Sometimes KERMIT doesn't work. If your KERMIT can time out automatically, you'll see the number of retries increasing on the screen as it tries to send to the remote KERMIT and can't get a response; or, as the remote KERMIT repeatedly sends what your local KERMIT thinks are bad packets. If your KERMIT can't automatically time out (KERMIT-65 is like this) then you'll see the screen appear to go dead--nothing will happen. Press <return> or <space> to manually time out the transmission; after 16 retries the local KERMIT gives up and returns you to local mode.

There are several reasons why KERMIT doesn't work. Following are a number of possibilities and how to correct each.

• Parity Set Incorrectly:

VAX KERMIT, ORVYL KERMIT, and most of the microcomputer KERMITs expect no parity by default. The ISN system is an eight-bit, no parity system, and this normally works fine. However, if you are communicating with some other system (over TELENET, for example) even parity may be imposed by the communications system. Try the command SET PARITY EVEN on both the receiving and sending computers. Even parity, by the way, should work even in a no-parity environment as long as both KERMITs agree to use it.

Parity errors can also occur on micro-to-micro transfers (between two microcomputers), especially on KERMITs that cannot set parity and baud rates. In this case you must set the parity from the operating system; Apple and CP/M KERMITs are like this. Use SET PARITY to tell KERMIT about the parity the operating system has set.

Broken Connections:

You must have good connections from serial port to modem to telephone, or between microcomputers. In a micro-to-micro transfer, be sure you have a null modem connector if your computers need one. It sounds like a silly error, but folks do trip over cords, and cables can be wired wrong. Check and be sure!

• Message Interference:

If an ISN, VAX or WYLBUR message is transmitted during a file transfer, the microcomputer KERMIT may get confused and terminate the transfer. There is not much you can do about this except start over.

If an error occurs in VAX or ORVYL KERMIT, an error packet is transmitted to interrupt the transmission. Some microcomputer KERMITs know what to do with error packets and some don't. If you timeout manually and return to command mode, CONNECT and see if you receive the "KERMIT-xx>" prompt. If you do, this is what has happened. Entering STATUS displays a message telling you what happened.

• Transmission Delays:

Microcomputer KERMITs that timeout automatically may become impatient when VAX or WYLBUR is heavily loaded. If the microcomputer doesn't receive a packet in N seconds, it tells the host to resend the packet that hasn't been sent yet. This can confuse both sides and may result in termination. If this occurs, use SET DELAY on the microcomputer side to increase the time the local KERMIT will wait for the host to send a packet.

Noise Corruption.

If your phone connection is very noisy, you may see KERMIT requesting a lot of retries, and it may abandon the transmission altogether. If this happens, first try dialing a new connection. If that doesn't help, use SET PACKET_LENGTH on the transmitting end to decrease the packet size (normally 80 characters) and SET RETRY on both ends to increase the number of times KERMIT will try to send a packet. If your KERMIT permits it, try switching to a two or three-character checksum with SET BLOCK_CHECK.

• Extra Characters at End of File.

On microcomputers with block-oriented disk structures (like CP/M), KERMIT sends whole blocks to the remote system, not recognizing an end-of-file character (<ctrl/z>). When this occurs you may see an extra line of garbled characters at the end of the file when you edit it on the remote system. Remove these from the file with an editor,